

QUADREL

LABELING SYSTEMS

Operating & Maintenance
Manual
For

PUBLIX

TECHLINE ZDT

Automatic Labeling System

Labeler Model #: Q125 SERVO
Serial #: 84187-100

QUADREL LABELING SYSTEMS
7670 Jenther Drive
Mentor, Ohio 44060
440.602.4700

customerservice@quadrel.com
parts@quadrel.com

TERMS AND CONDITIONS OF SALE
QUADREL, INC
D/B/A Quadrel Labeling Systems Hereinafter Referred to as Quadrel

PERFORMANCE GUARANTEE:

If the surface of the product to be labeled is free from contamination so as to ensure proper label adhesion, the labels are manufactured in accordance with label specifications provided and the equipment is operated and maintained in accordance with the instructions contained in the Quadrel manual (two copies of the manual will be supplied by Quadrel with the labeling system; one printed copy, and one electronic copy). Quadrel guarantees the EQUIPMENT to perform after installation as stated.

1. Provided a sufficient amount of products are presented to the labeling system.
2. Dimensional inconsistency from one like product to be labeled to the other may result in additional label placement inaccuracy in direct relationship to the product inconsistency.
3. Slitting inconsistency within a given roll of labels or from one like roll to another may result in additional label placement inaccuracy in direct relationship to the slitting inconsistency.
4. If the Quadrel labeling system proposed herein does not include physical control of the product during label application, additional placement inaccuracy can occur in direct relationship to the product control inconsistency.
5. Label Placement Accuracy: Within Sigma 2 (approximately 95.5%) to be normal.

In the event of the failure if the Quadrel system to meet customer's specifications, as quoted by Quadrel or subsequently agreed to by Quadrel. Quadrel upon written notice from buyer shall, at its option, repair the system, or refund the purchase price upon return of the system. The warranty provided in this article and the obligations and liabilities of Quadrel thereunder are exclusive and in lieu of, and buyer hereby waived, other remedies warranties, guarantees or liabilities, express or implied arising by law or otherwise (including without limitation, any obligations of Quadrel with respect to fitness for a particular purpose, merchantability, specific performance, incidental and consequential damages) whether or not occasioned by Quadrel's negligence. This warranty should not be extended altered or varied except by written instrument signed by Quadrel and buyer.

EXCLUSIVE TERMS OF SALE: The proposal attached hereto or to which these Terms and Conditions of Sale apply (the "Proposal"), together with these Terms and Conditions of sale (collectively, the "Sale Agreement"), constitutes the complete and exclusive statement of the agreement between Quadrel and the purchaser specified in the Proposal ("Purchaser") concerning the equipment and other goods specified in the Proposal (collectively, the "Equipment"), as well as any and all services specified in the Proposal (collectively, the "Services"), and supersedes all prior contemporaneous agreements, representations and/or communications, either oral or written, between Quadrel and Purchaser or any representative such as parties with the respect to the subject matter of the Sale Agreement. No change to the Sale Agreement or waiver of any provision thereof will be binding on Quadrel unless made in writing and signed off by and authorized officer of Quadrel. Acceptance of the Equipment, in whole or part, or other express or implied assent by Purchaser to the terms hereof shall constitute Purchaser's agreement to the terms of the Sale Agreement. Acceptance of any purchase order or other document of Purchaser by Quadrel is expressly made conditional on the Purchaser's assent to the Sale Agreement. ANY ATTEMPTED MEMORIALIZATION OF THIS SALE BY A PURCHASE ORDER OR OTHER DOCUMENT CONTAINING TERM AND CONDITIONS INCONSISTANT WITH OR IN ADDITION TO THE CONDITIONS CONTAINED IN THE SALE AGREEMENT SHALL NOT BE BINDING UPON QUADREL AND QUADREL HEREBY EXPRESSLY OBJECTS TO AND REJECTS THE SAME.

GENERAL WARRANTY (EXCLUDES TABLETOP LABELERS)

Time from date of shipment	Covered Expenses
Up to 90 Days	All Parts , service time, living and travel expenses
UP to 12 Months	All parts

THE WARRANTIES PROVIDED ABOVE ARE IN LIEU OF ANY AND ALL OTHER WARRANTIES AND LIABILITIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. NO OTHER WARRANTIES ARE OFFERED BY QUADREL WITH RESPECT TO THE EQUIPMENT OR SERVICES AND QUADREL HAS NOT AUTHORIZED ANY EMPLOYEE OR AGENT TO OFFER ANY WARRANTIES EXCEPT THOSE PROVIDED ABOVE. PURCHASER AND QUADREL EXPRESSLY AGREE THAT THE WARRANTIES PROVIDED ABOVE SHALL SERVE AS PURCHASER'S SOLE AND EXCLUSIVE REMEDY WITH RESPECT TO THE EQUIPMENT AND SERVICES.

PURCHASER REQUIREMENTS. Purchaser must provide Quadrel descriptions and specifications of all labels and items to be labeled, including, without limitation, label material, product and label dimensions, and any other items required by Quadrel. Further, purchaser shall furnish Quadrel one (1) production size roll of each label and 100 samples of each item to be labeled for testing purposes. **Quadrel shall have no liability (whether under its Limited One-Year Warranty or otherwise) for labeling performance on labels or items to be labeled:**

- (a) Which were not specified or sufficiently described in the Proposal: or**
- (b) With respect to which Purchaser fails to provide Quadrel the samples specified herein, even if such labels or items to be labeled were specified in the Proposal. Further, Quadrel shall have no liability for delays caused by Purchaser's failure to furnish samples as specified herein.**

LIMITATION OF WARRANTIES. Quadrel shall have no obligation to honor its warranties and shall have no liability with respect to defective Equipment if:

- (a) The Equipment has been modified, altered, damaged, abused or used for any other than those purposes intended by Quadrel.
- (b) The Equipment has been changed without prior written consent from Quadrel.
- (c) The equipment has not been operated and maintained in accordance with generally accepted commercial practices for similar equipment and Quadrel's specifications and instructions, as published in the Quadrel manual.
- (d) The surface if the product to be labeled is not clean and free of contamination, including, but not limited to, mold release agents, condensation, dirt and oil.
- (e) Labels are not manufactured in accordance with label specifications provided by Quadrel, or are not from defects such as cracked edges, deep die strikes, *etc.*
- (f) Labels and items to be labeled are not set forth in the Proposal.
- (g) Samples of all products and labels were not provided to Quadrel for testing prior to Equipment shipment as required under "Purchaser Requirements" outlined above.
- (h) There is dimensional inconsistency from one like roll of labels to another.
- (i) *The Equipment does NOT include physical control of the product.*

LIMITATION OF REMEDIES. All warranty claims shall be subject to review and approval by Quadrel. Quadrel's obligation to honor warranties is in all cases limited to, at Quadrel's sole option:

- (a) Repair of defective Equipment or components: or
- (b) Providing a cash refund or credit, after Purchaser has returned Equipment to Quadrel.

Where warranty service is to be provided at the Quadrel facility, Purchaser shall return Equipment claimed to be defective to Quadrel, freight prepaid, for review. No Equipment shall be returned to Quadrel, whether for inspection, repair, refund, or any other reason, without prior return authorization from Quadrel. Quadrel may charge Purchaser cost resulting from testing, handling and disposition of Equipment claimed to be defective by Purchaser which is found by Quadrel to conform to Quadrel's warranties.

LIMITATION OF LIABILITY. QUADREL SHALL HAVE NO LIABILITY FOR ANY CONSEQUENTIAL, INCIDENTAL, PUNITIVE OR SPECIAL DAMAGES BY REASON OF ANY ACT OR OMISSION OR ARISING OUT OF OR IN CONNECTION WITH THE (a) EQUIPMENT OR ITS SALE, DELIVERY, INSTALLATION, MAINTENANCE, OPERATION, OR PERFORMANCE, OR (b) SERVICES. IN NO EVENT SHALL QUADREL'S LIABILITY EXCEED THE PRICE OF THE EQUIPMENT (OR THE PRICE OF THE SERVICES IF A CLAIM IS MADE WITH RESPECT TO THE SERVICES) WITH RESPECT TO WHICH A CLAIM IS MADE REGARDLESS OF WHETHER SUCH CLAIM IS BROUGHT

AT LAS OR IN EQUITY AND REGARDLESS OF WHETHER SUCH CLAIM IS BROUGHT UNDER CONTRACT, BREACH OF WARRANTY, TORT OR ANY OTHER THEORY OF LAW OR EQUITY.

ORDERS:

Orders entered, verbal or written, cannot be cancelled except upon terms that will compensate Quadrel against any and all claims

START-UP SERVICE:

Quadrel will provide, at standard installation rates, the number of normal eight-hour working days for the Quadrel Field Service Technician to start the EQUIPMENT and to train PURCHASER'S operating and maintenance personnel. EQUIPMENT is not uncrated and emplaced in desired location by PURCHASER prior to arrival of Quadrel Field Service Technician, or if the EQUIPMENT cannot be made operational due to non-availability of products, labels, appropriate utilities and/or related production equipment, PURCHASER shall pay Quadrel for additional service time required including travel expenses, if applicable, in accordance with Quadrel's Field Service rates. It is PURCHASER's obligation to schedule the start-up service at a time when PURCHASER'S engineering, maintenance and selected production personnel are available.

SERVICE AFTER INSTALLATION:

Quadrel Field Service Technicians are available to customers who do not maintain their own service departments. This can be handles on a per visit basis. Field Service rates are available on request.

PAYMENT TERMS:

Payment terms are as follows: 50% of purchase with purchase order, 40% of purchase at the time of shipment, 10% of purchase (plus freight charges) due net 30 days. If shipment is delayed beyond 30 days after the EQUIPMENT has been made ready for shipment, and the delay is caused directly or indirectly by the PURCHASER, then the total of the unpaid balance, at option of Quadrel, may become immediately due and payable upon written notice. Payments not paid when due shall thereafter bear monthly service charges at the rate of 1.5% per month on the unpaid balance until paid. If, in Quadrel's opinion, PURCHASER'S financial condition does not justify continuance of production or shipment on the terms of payment specified above, Quadrel may require payments in advance.

FINANCIAL IMPAIRMENT. Quadrel may, at its option, suspend performance if in its opinion the credit of the Purchaser becomes impaired until such time as Quadrel has received full payment, including any general price increases or surcharges, is satisfactory security for deliveries made and is satisfied as to Purchasers credit for future deliveries. Quadrel reserves the right to cancel Purchaser's credit at any time for any reason. In addition, Quadrel reserves the right by written notice to cancel any order or require full or partial payment or adequate assurance of performance from Purchaser without Liability to Quadrel in the event of:

- (a) Purchaser's insolvency
- (b) Filing of a voluntary petition in bankruptcy by Purchaser
- (c) Filing of an involuntary petition in bankruptcy against Purchaser
- (d) Appointment of a receiver or trustee for Purchaser
- (e) Execution by Purchaser of an assignment for the benefit of creditors

TAXES:

The amount of any present or future federal, state, local or other taxes applicable to the sale of EQUIPMENT shall be added to the price and paid by PURCHASER unless PURCHASER provides a valid exemption certificate acceptable to Quadrel and the appropriate tax authority.

GOVERNING LAW AND JURISDICTION. The sale agreement shall be governed and construed in accordance with the domestic laws of the State of Ohio without giving effect to any choice or conflict of law provision or rule that would cause the application of the laws of any jurisdiction other than the State of Ohio. Any legal action, suit or proceeding relating to the Sale Agreement shall be heard and determined exclusively in the United States District Court for the Northern District of Ohio or the Court of Common Pleas of Lake County, Ohio, and each party irrevocably submits to the jurisdiction of either such courts and waives any objection which such party may have to the laying of venue of any such legal action, suit or proceeding in any such court.

The Sale Agreement shall not be governed by the United Nations Convention on the International Sales of Goods. No actions arising out of the sale of Equipment or Services may be brought by either party more than one (1) year after shipment.

RETURNS:

EQUIPMENT sold by Quadrel is returnable only in accordance with the provisions hereof. Before returning of any EQUIPMENT or items thereof, PURCHASER must obtain Quadrel's written return authorization and instructions.

FORCE MAJEURE:

Quadrel shall not be liable for any loss, damage, delay, changes in shipment schedules or failure to deliver due to act of God, accidents, fires, strikes, riots, civil commotion, insurrection, war, the elements, embargoes, failure of carriers, inability to obtain electricity or other type of energy, transportation facilities, raw material, equipment or any problem or any similar or different contingency beyond its reasonable control which would make performance commercially impractical whether or not the contingency is of the same class as those above. Quadrel shall in no event be liable for any consequential damages.

TITLE AND RISK OF LOSS:

Title and risk of loss to EQUIPMENT shall pass to PURCHASER upon delivery by Quadrel to a common carrier, regardless of the freight terms stated or method of payment for transportation charges. Quadrel reserves the right to specify routing of shipments.

ENTIRE AGREEMENT:

This agreement embodies the entire agreement and understanding between the parties, is intended as complete and exclusive statement of terms of the agreement between the parties and supersedes any prior agreements or understandings between the parties relating to the subject matter hereof. PURCHASER acknowledges that Quadrel has not made any representations to PURCHASER other than those which are contained herein. Except as provided in this agreement, no change in or addition to the terms contained herein shall be valid as between the parties unless set forth in writing which is signed by an authorized representative of both parties and which specifically states that it constitutes an amendment to this agreement.

The parties may use their normal commercial forms in connection herewith: however, any such forms shall be used for convenience only and any terms or provisions which may be contained therein inconsistent with or in addition to those contained herein shall have no force or effect whatsoever between parties hereto.

EFFECTIVE:

This proposal is based upon the current cost of labor and materials and shall remain in effect for a period of sixty (60) days from the date hereof unless revoked by Quadrel in writing prior to acceptance.

INDEMNIFICATION:

The purchaser of this product ("Customer") hereby agrees to release, indemnify and hold harmless Quadrel and its agents, assignees and representatives for any and all liabilities, losses, costs, damages and expenses (including attorneys' fees and expenses) arising, directly or indirectly, from any and all manner of claims, demands, actions and proceedings that may be instituted against Quadrel on any grounds.

The Customer agrees to, at the Customer's own expense, promptly defend and continue the defense of any such claim, demands, actions or proceeding that may be brought against Quadrel, provided that Quadrel shall, within thirty (30) days of Quadrel receiving notice thereof, notify the Customer of such claims, demand, action or proceeding.

Quadrel shall at all times retain the right to defend itself and/or to otherwise participate in the defense of any such claim or action, and no settlement or other resolution of any such claims or action shall be finalized without Quadrel's written approval. Any failure by Quadrel to give prompt notice or provide copies of documents or furnish relevant data shall not constitute a defense in whole or in part to any claim by Quadrel against the Customer except to extend that such failure by Quadrel shall result in a material prejudice to the Customer.

The forgoing notwithstanding, if suit shall have been against Quadrel and the Customer shall have failed, after the lapse of a reasonable time after written notice to it of such suit, to take action to defend the same. Quadrel shall have the sole right to

defend the claim and shall be entitled to charge the customer with the reasonable cost of any such defense, including reasonable attorney’s fees, and Quadrel shall have the right, after notifying but without consulting the Customer, to settle or compromise such claim on any terms reasonably provided by Quadrel.

This release and indemnification is and shall be binding upon the Customer, as well as the Customer’s respective heirs, subsidiaries, affiliates, successors, assigns, agents and employees. If any provision or provisions of this release and indemnification shall be held to be invalid, illegal or unenforceable for any reason whatsoever, the validity, legality and enforceability of the remaining provisions of this Agreement shall not in any way be affected or impaired thereby. No supplement, modification or amendment of this Agreement shall be binding unless executed in writing by all of the parties hereto.

Any order put on hold or left dormant for any reason for 90 days will be considered cancelled. See Cancellation Policy below.

CANCELLATION POLICY:

In the event of order cancellation, the 50% down payment is non-refundable. Customer may also be responsible for additional charges covering engineering resources expended and committed materials depending upon the custom nature of the project and the point in the order process in which the cancellation occurs.

NOTE. No salesman, representative or agent of Quadrel is authorized to give a guarantee, warranty or make any representation contrary to above.

Please sign and acknowledge acceptance to these terms and conditions _____ Date _____




TABLE OF CONTENTS

1	MANUAL PREFACE
2	GENERAL DISCRIPTION
3	WARNING/CAUTION SAFETY INSTRUCTION
	3.1.1 SAFETY INTEGRATION
	3.1.2 GENERAL SAFETY INFORMATION
4	INSTALLATION / REASSEMBLY INSTRUCTIONS
5	HMI GUIDE
6	SET UP SHEETS
7	LABELING HEAD
	7.1.1 LABELING HEAD INFORMATION
	7.1.1.1 LOADING AND UNLOADING STOCK ROLL
	7.1.1.2 THREADING DIAGRAMS
	7.1.1.3 LABELER ADJUSTMENTS
	7.1.1.4 FUNCTION, OPERATION, & TROUBLESHOOTING
	7.1.2 SIDE PLATE ASSEMBLY
	7.1.2.1 ASSEMBLY WRITE UP
	7.1.2.2 DRAWING
	7.1.3 UNWIND ASSEMBLY
	7.1.3.1 ASSEMBLY WRITE UP
	7.1.3.2 DRAWING
	7.1.4 IMPRINTER MOUNT – (OPTIONAL)
	7.1.4.1 ASSEMBLY WRITE UP
	7.1.4.2 DRAWING
	7.1.5 PEEL PLATE ASSEMBLY
	7.1.5.1 ASSEMBLY WRITE UP
	7.1.5.2 DRAWING
	7.1.6 BRUSH IMPRESSER ASSEMBLY – (OPTIONAL)
	7.1.6.1 ASSEMBLY WRITE UP
	7.1.6.2 DRAWING
	7.1.7 DRIVE AND PINCH ROLL ASSEMBLY
	7.1.7.1 ASSEMBLY WRITE UP
	7.1.7.2 DRAWING
	7.1.8 STEPPER/SERVO MOTOR DRIVER ASSEMBLY
	7.1.8.1 ASSEMBLY WRITE UP
	7.1.8.2 DRAWING
	7.1.9 REWIND ASSEMBLY
	7.1.9.1 ASSEMBLY WRITE UP

- 7.1.9.2 DRAWING
 - 7.1.10 SLOT SENSOR ASSEMBLY
 - 7.1.10.1 ASSEMBLY WRITE UP
 - 7.1.10.2 DRAWING
- 7.2 LABELING HEAD FAULTS – **(OPTIONAL)**
 - 7.2.1 ASSEMBLY WRITE UP
 - 7.2.2 DRAWING
 - 7.2.3 END OF WEB / BROKEN WEB / LOW LABEL
- 8 MECHANICAL COMPONENTS
 - 8.1.1 FRAME ASSEMBLY
 - 8.1.1.1 ASSEMBLY WRITE UP
 - 8.1.1.2 DRAWING
 - 8.1.2 CONVEYOR ASSEMBLY
 - 8.1.2.1 ASSEMBLY WRITE UP
 - 8.1.2.2 DRAWING
 - 8.1.3 HEAD SUPPORT ASSEMBLY
 - 8.1.3.1 ASSEMBLY WRITE UP
 - 8.1.3.2 DRAWING
 - 8.1.4 PACING WHEEL/BELT ASSEMBLY/FEEDSCRW
 - 8.1.4.1 GENERAL INFORMATION
 - 8.1.4.2 ADJUSTMENTS
 - 8.1.4.3 ASSEMBLY WRITE UP
 - 8.1.4.4 DRAWING
 - 8.1.5 WRAP STATION ASSEMBLY
 - 8.1.5.1 GENERAL INFORMATION
 - 8.1.5.2 ADJUSTMENTS
 - 8.1.5.3 ASSEMBLY WRITE UP
 - 8.1.5.4 DRAWING
 - 8.1.6 BACK UP PLATE ASSEMBLY
 - 8.1.6.1 GENERAL INFORMATION
 - 8.1.6.2 ADJUSTMENTS
 - 8.1.6.3 ASSEMBLY WRITE UP
 - 8.1.6.4 DRAWING
 - 8.1.7 TOP HOLD DOWN ASSEMBLY
 - 8.1.7.1 GENERAL INFORMATION
 - 8.1.7.2 ADJUSTMENTS
 - 8.1.7.3 ASSEMBLY WRITE UP
 - 8.1.7.4 DRAWING
 - 8.1.8 PRODUCT DETECT ASSEMBLY
 - 8.1.8.1 ASSEMBLY WRITE UP
 - 8.1.8.2 DRAWING
 - 8.1.9 CHAIN ALIGNER / HUGGER BELT ASSEMBLY – **(OPTIONAL)**
 - 8.1.9.1 GENERAL INFORMATION
 - 8.1.9.2 ADJUSTMENTS
 - 8.1.9.3 ASSEMBLY WRITE UP

8.1.9.4 DRAWING

8.1.10 ROTARY ACTUATOR SQUEEGEE ASSEMBLY – **(OPTIONAL)**

8.1.10.1 GENERAL INFORMATION

8.1.10.2 ADJUSTMENTS

8.1.10.3 ASSEMBLY WRITE UP

8.1.10.4 DRAWING

8.1.11 STOP GATE ASSEMBLY / BLADDER – **(OPTIONAL)**

8.1.11.1.1 GENERAL INFORMATION

8.1.11.1.2 ADJUSTMENTS

8.1.11.1.3 ASSEMBLY WRITE UP

8.1.11.1.4 DRAWING

8.1.12 INFEED / OUTFEED BANK SENSORS – **(OPTIONAL)**

8.1.12.1.1 GENERAL INFORMATION

8.1.12.1.2 ADJUSTMENTS

8.1.12.1.3 ASSEMBLY WRITE UP

8.1.12.1.4 DRAWING

8.1.13 EJECT STATION ASSEMBLY – **(OPTIONAL)**

8.1.13.1.1 GENERAL INFORMATION

8.1.13.1.2 ADJUSTMENTS

8.1.13.1.3 ASSEMBLY WRITE UP

8.1.13.1.4 DRAWING

9 ELECTRONICS / SCHEMATICS

10 MAINTENANCE

10.1.1 GENERAL INFORMATION

10.1.2 BELTS

10.1.3 ROLLERS

10.1.4 SENSORS

10.1.5 CONVEYOR

10.1.6 CLEANING

10.1.7 WARRANTY



Quadrel Labeling Systems Quality Manual

Quality Statment:

Quadrel Labeling Systems strives to provide our customers with the highest quality labeling/sleeving solutions available on the market. In order to achieve total customer satisfaction, we shall adhere to the following objectives:

100% on-time delivery

zero defects

Value added service and support

Engineered solutions

Employee development and diversity

We will commit to continuously improve each facet of our business operations through implementation of, and compliance of this manual.

Chuck Wepler
General Manager / President

1 **MANUAL PREFACE**

Thank you for choosing Quadrel Labeling Systems. We have designed and manufactured this equipment with the upmost pride and care ensuring you the absolute best quality, maximum versatility and reliability.

This equipment is intended to be used only as described in this document. Quadrel Labeling Systems Inc. cannot be held responsible for the improper use or functioning of non-described functions of this machinery. Liability for any personal injury, loss of production or revenues, or property damage occasioned by the use of this manual in effect maintenance, operation, or repair of the equipment is in no way assumed by Quadrel Labeling Systems Inc. Anyone one using a procedure not recommended by the end user should first completely satisfy himself/herself that personal safety and equipment integrity will not be jeopardized in the method selected.

DO NOT attempt to install, operate, or adjust the labeling system without first reading and understanding the contents of this manual.

Only a trained person is to be permitted to operate this equipment. Training should include instruction in operation under normal conditions and emergency situations. Under no circumstances should an untrained person operate this machine.

This manual will provide operating instructions, parts listing and schematics. The information contained in this manual will help the user in his/her operations, troubleshooting, and maintaining the machine in good operating conditions. Information, illustrations and specifications contained in this manual are based on the latest product information available at the time of this manual release. Quadrel Labeling Systems Inc. reserves the right to alter and substitute information contained herein at any time.

Due to the customization it is also possible that you have received a different variation of this equipment, with several different options. Some pictures used in this manual may not totally reflect your configuration, although the labeling is completely the same.

All rights reserved while every precaution has been taken in the preparation of this manual, Quadrel Labeling Systems Inc. cannot be held responsible for errors, omissions, damages, loss of production, or revenues resulting from the use of the information contain herein.

2 GENERAL DISCRIPTION - TECHLINE

In-line labeling machines apply labels to a wide variety of container shapes. In addition to conventional cylindrical containers, the in-line labeler can be used with specially contoured, elliptical or flat-sided containers. In-line labelers are manufacturing in a variety of configuration. Diagrams illustrate standard in-line labeler arrangements for different container designs.

The Techline labeling system is a high performance, economically priced labeling system for front/ back, wrap or custom applications with production rates up to 275 ppm. Built with quality, versatility and durability from the bottom up. This system surpasses all equipment in its price range and is suitable for multi-shift operations where long-term reliability is important. All critical components are designed for 24/7 reliability. The versatility of Techline makes it ideal for contract packagers or companies requiring frequent changeovers on a wide variety of products. Features such as PLC control with color touchscreen and simple “no tool/ no change parts” operation provide maximum flexibility for today’s packagers. This system has a compact footprint, suitable for harsh/ multi-shift environments. Allen-Bradley PLC control with color touchscreen with 50 programmable product presets. Encoder-based speed compensation. AC inverter controlled product handling. Ideal for Pharmaceutical, Food, Personal Care, Automotive and other markets.

3 WARNING/CAUTION SAFETY INSTRUCTION

Where safety is dependent upon starting or stopping devices, or both, they are to be kept free of obstructions that could endanger personnel.

The areas around loading and unloading points are to be kept free of obstructions that could endanger personnel. Instruct personnel working on or near this equipment as to the location and operation of pertinent stopping devices.

This equipment is to be used only for the purpose for which it is constructed.

Under no circumstances are the safety characteristics of this equipment to be altered.

Conduct routine inspections and corrective / preventive maintenance measures to ensure that all guards are installed and function properly. Alert personnel to the potential hazards indicated by the safety labels on this equipment.

3.1 SAFETY INTEGRATION

The end user's safety risk assessment will be the guiding document for proper integration of the equipment provided. Consideration of the following guidelines is recommended in order to achieve a safe result:

- Open areas under the equipment are to be guarded by the end user to prevent entry.
- Where conveyor flight lugs or product enters or exits the equipment, proper guarding and interlock are put in place by the end user to ensure mitigation of shear/jam points.
- The end user is responsible for properly guarding drive components on equipment that requires mechanical drive integration.

3.2 GENERAL SAFETY INFORMATION

This Quadrel Labeling System is engineered to feed and apply labels on your products. In designing the device, Quadrel valued personal safety; however we would like to draw your attention to the following safety acknowledgments.



WARNING

Hazards or unsafe practices, which **COULD** result in severe personal injury or death.



CAUTION

Hazards or unsafe practices, which **COULD** result in minor injury



CAUTION

The presence of safety systems in these units does not exempt the operators to act cautiously, avoiding behaviors that could

endanger their health or the equipment. These models are engineered to feed and apply labels on your products. In designing this device, Quadrel valued personal safety; however we would like to draw your attention to the following safety acknowledgments.

- Operators should know the basic operations and setup procedures before operating this equipment.
- Safe operations should be maintained at all times.
- Know the location of E-stops and power switches prior to operating machinery such as this.

WARNING

To reduce risk of fire, electrocution, or other personal injury when operating. Follow basic safety precautions, including the following:

- This equipment must have an operator attending the machine at all times to monitor the operations. **DO NOT** leave this equipment unattended during maintenance or perform any maintenance unless the e-stop condition has been activated or power turned off.
- The electrical power to device is: __240__ Volts, __SINGLE (1)__ Phase, __60__ Hz, __30__ Amps. While installing make sure it's properly configured and connected by a qualified electrical technician.
- **DO NOT** by pass any of the safety circuits or safety features designed into this equipment.



- ALWAYS turn off **power and pneumatics** before performing repairs.
- The doors on all electrical enclosures must be closed. All covers on labeling heads must be on labeling heads. (if applicable)
- This device is built to perform in humid conditions, but must not be pressure washed. Wiping down the device is the recommended cleaning method.



- Do not stand, sit, or allow any personnel to be within reach of the tamp cylinder/ swing arm activation (if so equip).
- Report any malfunctions, or problems with the equipment to qualified maintenance personnel for repair or adjustments that may be required.
- Keep hands clear of moving parts. Do not place hands near labeling head when in operation.

For systems containing conveyors, you must be vigilant with loose clothing or bodily parts as they can get caught in the conveyor's belt or chains as direct injury or death can incur. **DO NOT** use the conveyor as a working platform or walkway.

TUCK IN ANY LOOSE CLOTHING. DO NOT WEAR TIES. PENDANTS, JEWELRY OR ANY OTHER ARTICLE OF CLOTHING OR ACCESSORY THAT MAY GET CAUGHT ON ANY PORTION OF THE SYSTEM.

FOR PROLINE SYSTEMS ONLY

CASTERS WERE IMPLEMENTED FOR EASE OF SHIPPING PURPOSES ONLY. PLEASE USE CAUTION WHEN MOVING PROLINE THROUGH FACILITY. THE PROLINE RECOMMENDED USE: SET IN PLACE/POSITION WITH LEVELING PADS DOWN TO SECURE.

WARNING

1. READ AND UNDERSTAND THE OPERATION MANUAL AND ALL SAFETY LABELS BEFORE OPERATING THIS MACHINE.
2. ONLY A TRAINED PERSON IS TO BE PERMITTED TO OPERATE THIS MACHINE. TRAINING SHOULD INCLUDE INSTRUCTION IN OPERATION UNDER NORMAL CONDITIONS AND EMERGENCY SITUATIONS.
3. THIS MACHINE IS TO BE SERVICED ONLY BY TRAINED AND AUTHORIZED PERSONNEL. FOLLOW LOCK-OUT PROCEDURES BEFORE SERVICING.
4. NEVER REACH INTO THE MACHINE FOR ANY REASON UNLESS THE MACHINE IS AT A COMPLETE STOP.
5. NEVER LEAVE THE MACHINE STOPPED IN SUCH A MANNER THAT ANOTHER WORKER CAN START THE MACHINE WHILE YOU ARE WORKING ON OR WITHIN THE MACHINE.
6. NEVER CHANGE OR DEFEAT THE FUNCTION OF ELECTRICAL INTERLOCKS OR OTHER MACHINE "SHUTDOWN" SWITCHES.
7. BEFORE STARTING THIS MACHINE, CHECK THAT: ALL PERSONS ARE CLEAR OF THE MACHINE; NO MAINTENANCE WORK IS BEING PERFORMED ON THE MACHINE, ALL GUARDS ARE IN PLACE.
8. ROUTINE INSPECTIONS AND CORRECTIVE/PREVENTATIVE MAINTENANCE MEASURES ARE TO BE CONDUCTED TO ENSURE THAT ALL GUARDS AND SAFETY FEATURES ARE RETAINED AND FUNCTION PROPERLY.

Using VFDs On GFCI Devices

By Bill Szatkiewicz, Senior Software Engineer

KB Electronics

for more information, email: info@kbelectronics.net

or visit: www.kbelectronics.com

The National Electrical Code, or NEC, continues to expand protection requirements for safety reasons resulting in an increase in Ground-Fault Circuit-Interrupter (GFCI) outlets being used in more environments. As a result, the Variable Frequency Drives (VFDs) industry is finding more instances of VFDs being powered from GFCIs. VFDs introduce high frequency harmonic content which may cause nuisance tripping on some GFCI devices. This paper is intended to assist anyone that needs to use a VFD on a circuit with GFCI protection. KB Electronics has developed special VFDs suitable for use with most GFCIs*.

* Please contact KB Electronics with information regarding your specific GFCI.

What is a VFD?

A VFD (also termed adjustable frequency drive, variable speed drive, AC drive, adjustable speed drive, micro drive, motor control, or inverter drive) is a power conversion device that will accept normal fixed branch circuit voltage of (115V or 230V) and frequency (50 Hz or 60 Hz) and allow the operator to control the speed of an induction motor (AC Motor) by varying the output voltage and frequency. A simplistic version of a typical VFD system is shown in Figure-1.

In addition to operator controllability, the VFD with soft start/stop features offers extended equipment life, increased performance, reduced maintenance, protection from excessive currents and voltages, as well as energy savings.




Figure-1: Typical VFD System

What is a GFCI?

A GFCI (shown in Figure-2) is a circuit breaker device which is designed to protect people from hazardous shock or electrocution by shutting off an electric power circuit when it detects current flowing in a way that it is not meant to, such as through water or a person.



Figure-2: Typical GFCI Outlet

The GFCI is intended to protect people from electrical shock, therefore, it is completely different from a fuse in the sense that it needs to shut off the electric power circuit at a low current, typically no more than 5 mA, in a quick amount of time (less than 1/10 of a second).

The GFCI does this by measuring and comparing the amount of current flowing in the ungrounded (hot) and grounded (neutral) conductors of the circuit. If the GFCI detects an imbalance in the circuit, it immediately shuts off the circuit.

Why Nuisance Trips Occur with Standard VFDs

Standard VFDs, when powered from GFCI outlets, can cause the GFCI to trip due to the leakage currents generated from the high switching frequency of the VFD's power devices and the harmonics associated with them. These high frequency leakage currents are not at the base frequency of the drive output which is normally 50 Hz or 60 Hz. These high frequency leakage currents, typically greater than 4 kHz, may cause the GFCI to trip because the GFCI is designed to work with 50 Hz or 60 Hz frequency inputs, not this higher value.

The high switching frequency of the VFD's power devices induce more capacitive-coupled currents, since a capacitor approximates a short circuit at high frequencies. This creates common-mode noise, referred to as leakage current, which travels through ground and can cause the GFCI to trip. The path to ground is made through the motor bearings or auxiliary equipment bearings.

In addition to the high switching frequency of the drive, there can be many other contributing factors which cause the GFCI to trip. Some drives have built-in filters which couple additional leakage current to earth ground. Other drives use external filters and replacing them with a low leakage filter may help.

One way to help determine if the GFCI tripping is occurring from the input filter or the VFD output is to remove either the input filter or the motor and observe if the GFCI still trips. For example, if the input filter is easily removed and doing so

prevents the GFCI from tripping, the source of the leakage currents tripping the GFCI was largely from the input filter.

Another method is to disconnect the motor. If doing so prevents the GFCI from tripping the contributing source of leakage current is most likely from the output stage of the VFD. However, most often than not, the GFCI is tripping from a combination of the two and improvements on both the input and output will help.

Long motor power cables can also create noise spikes. These long leads add more capacitance which increases noise spikes from the fast switching power devices of the VFD. Use a VFD rated cable with the shortest leads possible when connecting the motor power cables. A choke on the VFD's motor outputs may help reduce noise spikes.

In addition, ensure that motor cables are properly shielded, sized, routed, terminated, and grounded at both the motor and drive.

KB's GFCI Solution

KB's engineering team has studied VFDs powered from a variety of GFCI devices. A solution has been created which considers all contributing factors to get a best-case scenario that successfully works with most GFCIs.

KB investigated switching frequencies and developed custom switching frequency algorithms to reduce audible noise and leakage currents. High frequency noise spikes and ringing were reduced by modifying our proprietary power circuits for optimal results. In addition, output chokes, low leakage filters, and shielded cable were introduced, if needed, to find a GFCI solution.

Conclusion

KB has had great success providing VFDs that work with GFCIs for numerous original equipment manufacturers (OEMs). KB offers a full range of motor controls (shown in Figure-3) which can be customized to work with GFCIs. Let KB Electronics provide a solution for you.



Figure-3: VFDs Available from KB Electronics

Unboxing & Installation of your Quadrel Labeling Systems Machine

This section of your manual is aimed towards making the transition from Shipping Crate to Assembly line less Dramatic. If you have scheduled an install with one of our Professional Technicians the set-up of your machine will be a breeze. If not your manual as all of the information needed to get you going. In this section there may be some equipment shown that does not apply to the machine you purchased.

NOTE This is general instruction for all equipment (your equipment may vary slightly).

Let's get started...

First things first, check your crate/box/machine for damage. If there is damage please note the exception and contact Quadrel immediately. Any extra boxes or pallets will be either in your crate or tethered to the crate or pallet. Once you have inspected your shipment you can open the crate. Check packing slip Bill of lading against boxes received. Notify Quadrel of any discrepancies.



Carefully remove all banding on the legs, misc. boxes and assemblies in the crate or on the pallet. If your machine is



wrapped in bubble wrap or plastic wrap go ahead and carefully cut and remove that as well. Ensure you are wearing the appropriate safety gear when removing your machine from the crate.



Ensure all plastic wrap is removed from the assembly you are removing the support from before removing the support.

Remove the supports under your labeling heads, wrap station, top trap, HMI, Pacing wheel or belt. See images for various supported assemblies.



Most assemblies supported have a tool-less vertical adjustment using a knob or hand wheel.

The hand wheel may be wrapped to the assembly to prevent damage.


Remove the hand wheel from the wrap, then fasten the hand wheel to the square end on the lead screw using a 3/32 "L" handle Allen wrench.

Turn the handle/knob to raise the assembly this will take the weight off the supports so you can remove them.

Top Trap Support (top) Labeler Head Support (bottom) Plastic wrapped hand wheel (right)




All top and bottom labeling heads will be supported




similar to the image shown on the left.

Wrap stations will have supports similar to the image to the right. These supports do not require moving the assembly.

Pacing belt
assembly
supports can
be removed
will be
without raising
the assembly.




Pacing wheels
supported as shown





Often the head support will be moved in shipping or moved to be supported. When you are setting up your machine refer to your set up sheet in this manual. There are scales on the side of the assembly to line the carriage up to (as shown in the Image to the left and below).



Peel plates with or without the rods may be removed from the labeling head to move the head all the way in during shipping.

All assemblies removed will be bubble wrapped then plastic wrapped to the machine (as shown in image on the right) or in box on the pallet the machine is on (as shown in image below).



Mount the peel plate assembly using a 5/16 L handle Allen wrench (as shown in image on the left). The bolts are located in the assembly. You simply put the wrench in the quick change access holes to loosen or tighten the assembly.

NOTE When you are setting up your machine make sure the peel plate assembly is perpendicular to the conveyor. When the peel plate assembly is on the rods there is a small amount of play allowing you to make small adjustments to the assembly.

If you have the peel plate rods removed with the peel plate assembly and the label detect assembly (as shown below).

All assemblies removed will be bubble wrapped then plastic wrapped to the machine or in box on the pallet the machine is on.




First back the head out all the way. Locate your peel plate assembly and slide it into the holes in the drive roll assembly (as shown on the left of the image above). Make sure you take the bolts out of the end of the rods before putting them into the drive roll assembly.



Fasten the assembly to the drive roll with the bolts supplied using a 5/16 L handle Allen wrench. Make sure you have the lock washers on the bolts.

NOTE When you are setting up your machine make sure the peel plate assembly is perpendicular to the conveyor. When the peel plate assembly is on the rods there is a small amount of play allowing you to make small adjustments to the assembly.



When the peel plate rods are removed the label detect sensor is removed with it (show in image to the left). The sensor is locked into place so it won't move or need adjusted. All that will need done is simply reconnect the sensor to the zip port. To re-connect the sensor first locate the zip port (as shown in image on the right). The zip port is located under the head on the chassis or mounting plate. Take the cable coming from the sensor, route it neatly under the head, and screw it into the zip port where it says "label detect".



Some machines may have the unwind flange (shown in image to the right) removed to protect the flange during shipping do to the width of the machine.

All assemblies removed will be bubble wrapped then plastic wrapped to the machine or in box on the pallet the machine is on.

First, slide the unwind flange (with the collar facing towards you as shown in image to the right) over the unwind shaft. Make sure the top of the flange is 1 ¼ inches off the side plate.

Then, lock into place by tightening the collar with a 5/32 L handle Allen wrench.

Slide the quick lock collar over the shaft by lining the set screw up with the flat. The collar locks into place by rotating the collar 90 degrees.



Some machines may have the rewind flange (shown in image to the right) removed to protect the flange during shipping do to the width of the machine.

All assemblies removed will be bubble wrapped then plastic wrapped to the machine or in box on the pallet the machine is on.

First, slide the rewind flange (with the collar facing away from you as shown in image to the right) over the rewind hub make sure the flange just above the rubber bumper roughly 1/2 inch off the side plate.

Then, lock into place by tightening the collar with a 5/32 L handle Allen wrench.



Rails and transfers on the infeed and outfeed may be removed for shipping purposes. They will be wrapped in bubble wrap and wrapped to the machine. Carefully remove wrap and place in position as shown lock into place by tightening the knobs or ratchet handles.

NOTE Your machine may have a different rail system either adjustment is tool-less and fastened by a knob of ratchet handle.



End transfers will be wrapped in bubble wrap and plastic wrap. They will be located in a box on the pallet with your machine or wrapped to the machine itself.

Fasten the end transfer plate to the machine using a 5/32 L handle Allen wrench and the supplied 10-32 socket head screws. Ensure the transfer plate is both level with the conveyor and DOES NOT hit the conveyor chain.

Stack lamps are usually placed at the highest point of the machine and for that reason they are either removed or rotated 180 degrees. The stack lamp will be wrapped in bubble wrap and wrapped to the machine.

If the stack lamp is rotated then all you need to do is remove one of the bolts, rotate the stack lamp and put the screw back in. We use various screws on stack lamps you will need one of the following tools for the job.

- 3/32 L handle Allen wrench
- 1/8 L handle Allen wrench
- 5/32 L handle Allen wrench
- 3/16 L handle Allen wrench
- 1/2 open end wrench



HMI over head touch screen displays may be laid flat across the top of the enclosure wrapped in bubble wrap and plastic wrap.

Carefully remove the plastic wrap and bubble wrap.

Rotate the HMI 90 degrees and slide into the mount on the enclosure.

Fasten the pole in place by tightening the 2 set screws on the mount with a 6MM L handle Allen wrench.



The HMI may be enclosed in a wooden support off the enclosure to hold it in place during shipping.

If HMI is located remotely off the enclosure it will still be supported during shipping.

If so, carefully remove the supports and you are done.


All printers, printer controllers and lasers are removed from the machine when shipping and placed in the manufacturer's box. The cabling will remain on the machine for ease of installation.

The printer is mounted to the printer mount with 1 ¼-20 ratchet handle. Make sure you line up the indents in the plates with the brass nut on the threaded rod. Then slide the ratchet handle through the center of all of the blocks and tighten. Plug in the cables and you are done.



Table top printers with printer tables will ship in separate boxes or pallets (as shown to the left) the printer will be disconnected and placed in the manufacturer's box. The table will either get banded to the pallet with the machine or a separate pallet tethered to the machine pallet. Printer tables may be connected to the machine via weldment or a remote from machine. If you have a weldment connected table, refer to the lay out drawing of your machine in this manual. Fasten the weldment to the frame of the conveyor using the supplied hardware and an open end wrench. If the table is remote then move into the desired position referring to your layout drawing. Remove the printer from the box set on the table and plug in the pre-wired connectors.





Print and apply printers will be removed from the labeling head as well and placed in the manufacturer's box. Your labeling head will likely ship in its own boxes with a few of the assemblies or flanges removed. Occasionally your head on a stand will ship on a framed pallet which will requires little work to get started.

The unwind flange is installed like the previous one discussed previously.

Remove the printer from the box and place it into the opening of the labeling head (as shown in image to the right). Fasten the printer to the side plate of the labeling head using the supplied (5) 10-32 socket head screws and a 5/32 L handle Allen wrench. Then, plug the printer in.




The corner wrap modules will be removed for shipping purposes. They will be wrapped in bubble wrap, plastic wrap, and placed into the box with the labeler.

Take out of the box, carefully remove the wrapping.

Then mount to the labeling head with (4) ¼-20 bolts using a 3/16 L handle Allen wrench.



To prevent kinking of the air lines during shipping on our q34 print and apply labeling heads. All lines are pulled and labeled to the corresponding color. The hoses are color coded and marked. Simply plug in hose into the matching color (as shown in image to the right).



Rotary accumulation tables are banded to a pallet and wrapped.

These tables usually operate independently to the machine.

Carefully un-band and unwrap the table.

Line it up to the transfer plate on the conveyor.

Level the table using the leveling pads.

Plus in and adjust speed through the control box.



Sleeving applicators are typically on a stand and will ship on a pallet. They will be banded have many supports and be wrapped to protect the machine during the shipping process.

Carefully remove the banding and wrapping.

Raise the head and remove the supports.

The pallet will contain boxes with. Misc assemblies and or parts (ie mandrels).



Below is an image of the mandrel. The mandrel is the most precise and important part of the sleeve system. Always handle the mandrel extremely carefully.



Your mandrel will be located on the machine pallet tethered to the machine. It will be wrapped and in a box or tube (as shown below).



Carefully remove the mandrel from the packaging.

Rotate the black handle to move the throw down rollers apart far enough to slide the mandrel in.

Ensure each roller is between 2 bearings, the fin on the top is between the sensor, and the cutter blades are in line with the cut in the mandrel.

Rotate the black handle to move the throw down rollers closer to the mandrel pinching it in the middle. DO NOT OVER TIGHTEN THE THROW

DOWN ROLLERS INTO THE MANDREL. They need to be just tight enough that the bearing spins and a label feeds through.

Proline machines with guarding will either be left on the machine and have wooden supports to protect during shipping or the guards are removed and placed on a pallet.

If the guarding has supports carefully remove the supports from the guarding.

If the guarding is removed from the machine each panel will be labeled and the machine will be labeled to make it easy to figure out which door goes where.



The doors are fastened to the frame of the machine with the supplied hardware.

Line the hinges up to the holes on the frame put the bolt through.

Tighten a nut on the opposite end with the supplied flat and lock washer.





During shipment if the conveyor gets skewed you may need to re-square it. First check the conveyor with a square to verify (as shown in images below). If the conveyor needs adjusted, adjust the conveyor by slightly loosening the 4 bolts connecting the 2 sections on conveyor you would like to adjust (as shown in image to left).

Make your adjustments and check the top and side with a square. Placing a square across the top will check the squareness vertically. Placing a square along the side will check squareness horizontally.



When the conveyor is square tighten the bolts and you are all set.

When shipping a proline with an extended boom the dual swiveling elbows in the center of the boom get flipped 180 degrees to allow the machine to have enough over head clearance to ship safely (shown in image below).



Below are the instructions to flip the elbows to the correct configuration (as shown in image below)



Ensure the overhead controls are safely supported by a tow motor or at least 2 people so it does not fall when disconnecting the elbows.

Locate the 2 screws on the top and 2 screw on the bottom holding the prospective covers on.



With a t25 torx bit screw driver, loosen the 2 bolts holding the cover on the top and bottom.

With the cover off you can now access the 4 bolts holding each of the tubes in place.

Ensure the overhead enclosure is supported enough to hold for a few minutes while you loosen the bolts and flip the elbow.

Using a 6MM L handle Allen wrench loosen the 4 bolts on the top and bottom tube.



Quickly pull the tubes out and rotate the elbow as shown below.



BEFORE



AFTER

Slide the tubes in. the overhead enclosures elevation is going to change when flipping the elbows if you have it supported via tow motor you will have to raise it.

Fasten the 8 bolts with a 6MM L handle Allen wrench.

Fasten the covers to the top and bottom elbow using a T25 torx bit screw driver.



To the left shows the correct orientation of the dual elbow boom for the overhead enclosure.

If you have any questions please give our professional technicians a call.

FAMILY GUIDE



Operator Interface Guide

Techline Labeling System

84187_v000

Panelview touch screen with CompactLogix PLC

Table of Contents

Opening Splash Screen.....	3
System Menu Bar:.....	4
Main Screen:.....	5
Recipe Menu:.....	7
Labeler Menu:.....	9
Labeler Service Menu:.....	11
System Menus:.....	13
Speed Menu:.....	14
Calibration Menu:.....	15
Crossover Menu:.....	16
Changeover Settings:.....	17
Top Trap Menu:.....	18
Top Trap Confirmation Menu:.....	19
Product Flow Menu:.....	20
User Menu:.....	22
Password Menu:.....	23
Fault Menu:.....	24
Fault History:.....	25
System Counters:.....	26
Fault Messages and Indicators:.....	27
Warning Messages.....	27
Warning Messages, cont.....	28
Fatal Messages.....	28
Fatal Messages, cont.....	29

Opening Splash Screen

Upon initial power up, the terminal will initialize and display a splash screen. Once the screen and PLC boot up, the “Touch Screen to Continue” text will appear. Touch the screen to continue.



Button / Indicator Reference:

Menu Navigation Buttons: Navigation buttons will be purple circles with white outlines and icons of the target screen. Some buttons will have text below them to identify the target screen.

Standard Buttons: Standard buttons are used to turn features on/off, reset faults, clear counters, or various other functions that require operator control. Toggle buttons will typically have icons to reflect the status of the function that is being toggled while momentary buttons like Resets are circular and do not change images/colors. Many buttons and toggles may be password protected, which will appear differently if the current user does not have proper access.

Indicators: Status Indicators will be circular and will change color based on states. Mode indicators will be oval in shape and will change colors and texts based on states.


Numeric and Text Displays: Numbers or Text displays will have a light orange background with black text and be oval in shape.

Numeric and Text Inputs: If a number or text can be entered, the button will have a dark green background (typical, but colors can change) with white text. The right side of the button will have a touch icon signify that it is an entry box. All numeric entries will have the touch icon regardless of color.



System Menu Bar:

Pressing the System Menu button in the Top Left corner of the screen will cause the system menus to appear as pictured below.




Press any button to navigate to that menu, or the close button to make the system menu bar disappear.



Main Screen:

After touching the splash screen, the touch screen will display the Main screen. You can also get to the Main screen by pressing the Home icon (pictured left).



Fault/Message window:

Displays current alarms and status messages about the status of the labeling system.

The Faults Menu button can be used to display more messages or a history if needed. Pressing a reset button on the touch screen or physical button on the machine will clear these messages if the fault was remedied.

Labeler Run/Stop:

Each Labeler can be toggled between Run and Stop (pending fault conditions). The Run/Stop button will change colors and text based on the current status.



Green “Running” Button: This indicates the labeler is currently running and cannot be jogged. While running, the labeler will automatically apply labels to passing products. To **stop** the labeler, press this button.



Red “Stopped” Button: This indicates the labeler is currently stopped and may be jogged. While stopped, the labeler will ignore products passing by. To **run** the labeler, press this button.

Labeler Status Indicator:

The status indicator below the Run/Stop buttons will identify which fault state the labeler is in.

Green: Ready / OK. The labeler has no fault conditions and may operate normally.

Yellow: Warning. The labeler has a warning present (typically low on labels). The labeler may operate normally, but will require attention soon.

Red: Faulted. The labeler has a fault on it that will prevent it from dispensing labels.

Pink: Crossing. The listed crossover is in process

Grey: Disabled. The labeler is disabled. The Enable to the drive is turned off and all functions are bypassed.

Product Rate (Parts Per Minute):

This indicator will reflect how many parts per minute are being labeled by the system. This number will average out over a period of time and may need at least 10 products in order to start calculating a rate.

Current Recipe Description:

This display reflects the description for the currently selected recipe. Recipes are explained in the Recipe / Labeler Menu.

Target Rate:

This entry box will change the speed of the system. It is entered as Parts Per Minute.

Fault Reset:

Pressing this blue button with white “R” will clear and reset any active faults on the machine.

Product Flow Control:

The product flow system can be stopped independently of the main system in order to prevent products from flowing into the system. This can be useful during setup or to purge the system. A product flow system can be a feedscrew, pacing wheel, pacing belt, stop gate, or combination of those items.



Green “Automatic” Button: This indicates the product flow system will stop and start based on external conditions.

The Product Flow System will stop/close when:

- The system is stopped
- The optional infeed sensor is not blocked by products or “starved”.
- The optional outfeed sensor is blocked by products or “full”.
- The Product Flow button has been toggled to “Stopped”
- A Cycle Stop or Purge is active



Red “Stopped” Button: This indicates the product flow system is stopped and will not allow products into the system until toggled back to Automatic.

Product Flow Status Indicator:

The indicator below the Product Flow Control button identifies the actual status of the flow system.

Green: Running. The product flow system is currently allowing products into the system.


Yellow: Waiting. The system is running but the flow system is stopped because of a condition listed above.

Red: Stopped. The flow system has been stopped manually and will not function until placed in the Automatic Mode.



Recipe Menu:

The Recipe Menu allows the changing and saving of recipes.



System Recipe:

Recipes are presets that contain parameters unique to each product. Setting Recipes for different products expedites changeover times. A total of 50 system recipes can be stored and descriptions can be changed when logged in at a Supervisor Level.

System Recipes store the following information:

Description

Changeover Settings

Speed Parameters: Target Rate, Product Pitch, Product Width

Labeler Parameters: Product Delay, Label Stop, Max Feed, Labeler Speed Ratio

Crossover Parameters: Enables, Distances, Low Label Batch Count

Load Recipe:

By number: Changing the Recipe number at the left will load the newly entered recipe to the system. Recipes can only be changed while the system is stopped.

By description: The center table shows the stored description for each recipe. The navigation buttons to the right of the table can be used to select descriptions. When the desired recipe is highlighted, the “Load Selected” button must be pressed to load that recipe to the system.

Current Recipe Description:

The description display at the top of the screen reflects the stored description for the recipe currently loaded on the system. When logged in at a Supervisor level, the change description button will appear in the bottom right which is used to enter a new recipe description.



Save Recipe (Supervisor Level):

The Pink Save button must be pressed to save all current values to the currently selected recipe.



Save As Recipe (Supervisor Level):

The current settings can be saved to a new target recipe. First change the Recipe to Save As number (when logged in at a supervisor level) and then press the Save As Recipe button in the bottom left. The description will automatically be copied, but will start in “Copy_” to identify it’s a copied recipe.




Change Recipe Description (Supervisor Level):

This button can be used to change the current recipe’s description.

1

Labeler Menu:

The Labeler Menu contains the parameters and controls associated with dispensing labels. Labeler #1 is pictured, but all labeler menus are set up in the same fashion.



Labeler Run/Stop:

The Labeler can be toggled between Run and Stop (pending fault conditions). The Run/Stop button will change colors and text based on the current status.



Green “Running” Button: This indicates the labeler is currently running and cannot be jogged. While running, the labeler will automatically apply labels to passing products. To **stop** the labeler, press this button.



Red “Stopped” Button: This indicates the labeler is currently stopped and may be jogged. While stopped, the labeler will ignore products passing by. To **run** the labeler, press this button.

Labeler Jog:

When the Labeler is stopped, the Jog button becomes available. Pressing the Jog button will cause the labeler to dispense one label (pending proper threading and label gap detection). It is important to jog labels upon threading or changing over to verify the labeler is threaded and functioning properly.



Green “Jog” Button: This indicates the labeler can be jogged. Press this button to start a jog process. This button will be grey while the labeler is jogging.



Greyed out “Jog” Button: This indicates the labeler is currently running, and may not be manually jogged.

Product Count and Reset:

This counter reflects how many Products have passed the product detect sensor while any labeler is Running. The reset button below the counter will set this value to 0.

Label Count and Reset:

This counter reflects how many Labels have been dispensed when Jogging and Running. The reset button below the counter will set this value to 0.

Labeler Status Indicator:

The status indicator below the Run/Stop buttons will identify which fault state the labeler is in.

Green: Ready / OK. The labeler has no fault conditions and may operate normally.

Yellow: Warning. The labeler has a warning present (typically low on labels). The labeler may operate normally, but will require attention soon.

Red: Faulted. The labeler has a fault on it that will prevent it from dispensing labels.

Pink: Crossing. The listed crossover is in process

Grey: Disabled. The labeler is disabled. Power to the drive is turned off and all functions are bypassed.

Product Delay:

The Product Delay (in inches) is used to center the label on the product in the left/right direction. A higher value in the Product Delay parameter will move the label towards the infeed side of the conveyor.

Label Stop:

Label Stop (in inches) controls the label's stop position. Typically the label should stop with 1/8" to 1/4" sticking off of the peel plate. A higher Label Stop will result in more label off of the peel plate.

Max Feed Length:

The Max Feed Length (in inches) determines how much of the liner will advance when no label division is detected by the Label Sensor. If this value is lower than the physical length of the label, poor label stop will result. This value is typically set to a value at least 1/4" longer than the actual label length. The system also uses this distance to determine if a label is missing on the liner and warning message generation.


Speed Ratio:

This speed Ratio is the value that determines the actual dispensing speed of the labeler. A value of 1.00 means that the labeler will dispense the label at the speed of the conveyor.



Labeler Service Menu:

The Labeler Service Menu contains parameters and toggles related to the Labeler that are not typically accessed on a regular basis.



Printer Signal (Supervisor Level):

Enabled: The system will energize an output for 50ms upon every label stop to be used by a print and/or inspection system.

Disabled: The printer output will not energize

Enable Button:

The Labeler can be Enabled and Disabled by using the toggle button in the middle of the screen.

Green “Enabled”: This indicates the labeler drive is enabled. While Enabled, the labeler may be jogged, placed into run, and will be monitored for faults.

Red “Disabled”: This indicates the labeler is disabled. While disabled, the labeler drive roller will be free to spin so that any jams in the drive system can be cleared easily. Also while disabled, the labeler will not jog or dispense labels when running. It is necessary to disable the labeler when clearing jams or changing some settings found on this menu.

Settle Time (Maintenance Level):

When the label stops moving, the settle timer will start. After the settle timer expires, the printer output (if enabled) will then energize. This value is set in milliseconds and can help ensure the label is not moving and flat before printing.

Accel and Decel (Supervisor Level):

These are the ramp values used by the labeler drive when dispensing labels while running. A lower value results in a longer Accel or Decel rate.

Labeler Run Hours and Reset (Supervisor Level):

This counter will count the hours that the Labeler has been in the run mode while the conveyor is running. The reset button is only visible when logged in at the Supervisor Level.

Direction (Quadrel Level):

The Direction button sets the direction of the drive roller. This should be set at the factory and not need to be changed. Note that the drive must be re-enabled after changing the direction.

Polarity (Quadrel Level):

The polarity of the encoder count can be changed with this button. The encoder count must increment in a positive direction for the labeler to dispense labels while running. If the Encoder Count is counting in a negative direction, the Polarity button must be toggled (note that the Polarity may not match the actual counting direction).

Encoder Count:

This is the current encoder count as interpreted by the Labeler drive.


Inches per PPR (Quadrel Level):

This value reflects how many inches of conveyor will travel every xxxx encoder pulses, where xxxx is equal to the resolution of the encoder itself.



System Menus:

This menu will contain shortcuts to all of the various system menus.





Speed Menu:

The Speed Menu contains parameters directly related to the speed of the system.

The screenshot shows the 'SYSTEM SPEED MENU' interface for 'QUADREL LABELING SYSTEMS'. The top navigation bar includes 'System Menus' (gear icon), 'Home / Main Menu' (house icon), and the 'QUADREL LABELING SYSTEMS' logo. A 'Speed Calibration' gear icon is on the left. The main area is titled 'SYSTEM SPEED MENU' and contains a 'Current Recipe Description' field with a placeholder of 24 'S' characters. Below this are five adjustable parameters, each with a green button labeled '###' and a hand icon: 'Target Rate (Parts/Min)', 'Product Pitch (inch)', 'Product Width (inch)', 'Cycle Stop Mode' (which is currently set to 'ENABLED'), and 'Cycle Stop Distance (inch)' (with a placeholder of '###').

Target Rate:

This entry box will change the speed of the system. It is entered as Parts Per Minute.

Product Pitch (Supervisor Level):

This determines the spacing between products as they exit the pacing system and is used to determine the speed of the hugger/conveyor belts.

Product Width (Supervisor Level):

This should be set to the width of the product as it travels down the conveyor in inches. The system will use this distance to determine the speed of the pacing belt and conveyor.

Cycle Stop Mode (Supervisor Level):

Enabled: When the Cycle Stop Mode is enabled, the system will continue running for a set amount of conveyor travel when a fatal fault occurs or the stop button is pressed. This is used to purge products out of the system when stopping.

Disabled: When disabled, the system will immediately stop when requested.

Cycle Stop Distance (Maintenance Level):

The Cycle Stop Distance is entered in inches, and is the distance the conveyor will travel when a cycle stop is activated.



Calibration Menu:

The Calibration Menu contains the parameters and displays for making sure all motors are running at target speeds.

The screenshot shows a 'SPEED CALIBRATION' menu with a close button (X) in the top right corner. The menu contains eight parameters, each with a display box and a calibration button (a green button with a hand icon):

- Target Rate (Parts/Min):** Display shows '###'.
- Product Pitch (inch):** Display shows '##.##'.
- Product Width (inch):** Display shows '##.##'.
- Target Linear Speed (In/Min):** Display shows 'NNNN'.
- Conveyor Calibration:** Display shows '##.###'.
- Target Pacing Speed (In/Min):** Display shows 'NNNN'.
- Pacing Belt Calibration:** Display shows '##.###'.
- Encoder Count:** Display shows 'NNNNNNNN'.
- Enc Counts per Inch:** Display shows '#####'.

Target Rate:

This entry box will change the speed of the system. It is entered as Parts Per Minute.

Product Pitch (Supervisor Level):

This determines the spacing between products as they exit the pacing system and is used to determine the speed of the hugger/conveyor belts.

Product Width (Supervisor Level):

This should be set to the width of the product as it travels down the conveyor in inches. The system will use this distance to determine the speed of the pacing belt and conveyor.

Target Linear Speed:

This indicator shows the target linear speed of the huggers and conveyor in Inches per Minute. It is calculated by Target Rate x (Pitch + Width) .

Conveyor Calibration (Supervisor Level):

This is the voltage multiplier that allows the Conveyor to run at the Target Linear Speed. This is calibrated at the factory and should not need further adjustment.

Target Pacing Speed:

This display will reflect the target speed of the Pacing Belt in Inches per Minute. It is calculated by The Target Rate x Product Width.

Pacing Calibration (Supervisor Level):

This value allows the pacing belt to run at the target pacing speed. This value is calculated at the factory using a tachometer and should not need adjustment unless drive parameters are changed.

PLC Encoder Count:

This display shows the current encoder count in the PLC. Note that this rolls over at 1m and may not equal any of the Labeler Encoder Counts.

PLC Encoder Counts per Inch (Quadrel Level):

This value is how many PLC Encoder counts are received for every inch of conveyor travel. The system uses this for any distance tracking and functions like crossovers and cycle stops.



The screenshot shows the 'TOP TRAP MENU' interface. At the top, there are navigation links for 'System Menus', 'Home / Main Menu', and a 'Menu' icon. The main title 'QUADREL LABELING SYSTEMS' is prominently displayed. Below this, the 'TOP TRAP MENU' is highlighted in a dark blue bar. The central area shows the 'Current Recipe Description' as 'XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX' and 'XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX'. To the left, the 'Top Trap Current Value' is shown as 'Limit Reached!'. To the right, the 'Top Trap Target Value' is shown as 'NNNNNN'. Below these, there are three large buttons: 'Limit Reached!' (red), 'Change Target' (blue with an 'X' icon), and 'NNNNNN' (orange). At the bottom, there are three more buttons: 'Moving Up' (green with an upward arrow), 'Stop Signal to Move if Trap' (blue with an 'X' icon), and 'Move DOWN' (red with a downward arrow).

This display shows the current output from the Top Trap position sensor. If this value is within 1% of the Target Position, the box will be green. If the value is +/- 5% of the value it will be yellow. When the display box is red, the value is greater than 5% away from the Target Position.

This display shows the target position for the Top Trap, based on the sensor's output.


When logged in at a Supervisor level, pressing the Change button will take the Actual Position and copy that to the Target Position setting.

If the Current Position is not equal to the Target Position, the Auto Move button can be pressed to start the top trap movement. Note that pressing this button will pop up a movement confirmation page prior to actually moving. There is a 30s timeout value when the Top Trap begins moving. If moving from the extreme limits, it may be necessary to initiate two movements in the event the timeout is reached.

Press and hold these buttons to move the top trap up or down manually. Note that if the top trap reaches a limit sensor it will not travel any further in that direction.

Top Trap Confirmation Menu:

The Top Trap Confirmation will appear any time that the Top Trap is requested to move. The Top Trap will be requested to move when a Recipe is changed or the Auto Set Height button is pressed in the Position Menu.



Confirm Movement:

Press this button to start the Top Trap movement to the Target Height. This pop up screen will close automatically if the top trap reaches its target position after movement starts.

Cancel Movement:

Press this button to cancel any automatic movement. This pop up screen will close if the Cancel button is pressed.


Movement Timeout:

Note that there is a 30 second timeout for the Top Trap movement. If the top trap times out, this pop up screen will not close automatically. Close the screen by pressing the X button in the top right corner.



Product Flow Menu:

The Product Flow Menu contains timers and toggles that control products entering the system.



Product Flow Control:

The product flow system can be stopped independently of the main system in order to prevent products from flowing into the system. This can be useful during setup or to purge the system. A pacing system can be a feedscrew, pacing wheel, pacing belt, stop gate, or combination of those items.



Green “Automatic” Button: This indicates the product flow system will stop and start based on external conditions.

The Product Flow will stop/close when:

- The system is stopped
- The optional infeed sensor is not blocked by products or “starved”.
- The optional outfeed sensor is blocked by products or “full”.
- The Product Flow button has been toggled to “Manually Stopped”
- A Cycle Stop is active



Red “Stopped” Button: This indicates the Product Flow system is stopped and will not allow products into the system until toggled back to Automatic.

Product Flow Status Indicator:

The indicator below the Product Flow Control button identifies the actual status of the flow system.

Green: Running. The product flow system is currently allowing products into the system.

Yellow: Waiting. The system is running but the flow system is stopped because of a condition listed above.

Red: Stopped. The flow system has been stopped manually and will not function until placed in the Automatic Mode.

Pacing Start Delay (Maintenance Level):

After the product flow is requested to start, this timer will start. While this timer is active, an optional stop gate will allow product to enter but the screw/belt/wheel will remain stopped. This is to allow the system to come up to speed first or create backpressure if needed into the pacing device.

Infeed Starved / Empty Delay (Maintenance Level):

This timer will start when the Infeed sensor does NOT see products, which results in an Empty/Starved condition. After this timer expires, the product flow will stop.

Infeed Primed / Full Delay (Maintenance Level):

This timer will start when the Infeed sensor sees products, which results in a Primed/Full condition. After this timer expires, the product flow will start.

Outfeed Clear / Empty Delay (Maintenance Level):

This timer will start when the Outfeed sensor does NOT see products, which results in a Clear/Empty condition. After this timer expires, the product flow will start.


Outfeed Backup / Full Delay (Maintenance Level):

This timer will start when the Outfeed sensor sees products, which results in a Backed Up/Full condition. After this timer expires, the product flow will stop.



User Menu:

The full User Menu enables alternate login levels to access protected screens and buttons.



Password Input: Press this button to enter a user password. Passwords are user defined in the Password Manager Menu.



Log Out: Press this button log the current user out.



Password Manager: This will open up a security prompt before opening the password menu, where the passwords for the Maintenance and Supervisor levels are set.

Auto Log Out (Supervisor Level):

When Enabled (button will be Green), the logged in user will automatically be logged off at a set amount of time. Note that the system automatically enables the Auto Log Out feature upon startup.


Log Out Timer (Supervisor Level):

This timer (in minutes) determines the time it takes to log off a user if Auto Log Out is enabled.



Password Menu:

The Password Menu allows the creation and editing of the passwords for different security levels.



Maintenance:

There can be 3 user defined passwords for the Maintenance level. Note that there is one hard coded Maintenance Level password that cannot be viewed or changed.

Supervisor:

There can be 3 user defined passwords for the Supervisor level. Note that there is one hard coded Supervisor Level password that cannot be viewed or changed.


If a Maintenance and Supervisor password are the same, the system will log that user in at the Maintenance level.

The password(s) to open the Password Menu are stored in the HMI and cannot be modified. This will prevent any password loss in the event the PLC logic is altered.



Fault Menu:

The Fault Menu displays all fault messages, shows system level counters, and gives access to a Fault History. You can access this Menu by pressing the Alert icon (pictured left).



Fault Display:

The Fault dialog box will display all of the active faults on the machine.

Fault Reset:

Used to reset active faults displayed above.




Fault History: Press this button to have a Fault History list appear.



Fault History:

The Fault History will store the last 128 fault message events.




Note that Time and Date can be set from the HMI's shell utility.

The navigation buttons on the right are for highlighting or scrolling through the messages. Messages can only be cleared by cycling power to the screen (or system).



System Counters:

This menu contains various counters associated with the entire system.



Faulted Hours:

This counts how many hours the system has had an active fatal fault on it, preventing the system from running. The reset button next to the counter will reset this value to 0 and is only visible when logged in at a Supervisor Level.

System Run Hours:

This counts how many hours the system has been physically running. The reset button next to the counter will reset this value to 0 and is only visible when logged in at a Supervisor Level.

Product Count and Reset:

This counter reflects how many Products have passed the first product detect sensor while any labeler is Running. The reset button below the counter will set this value to 0.

Label Count and Reset:

This counter reflects how many Labels have been dispensed when Jogging and Running. The reset button below the counter will set this value to 0.

Fault Messages and Indicators:

Green Lamp:

Steady: The Green lamp will be steady while the system is running.

Amber Lamp:

Flash: The Amber lamp will flash while any warning is active on the system.

The light strips above the top trap bill be steady amber while any warning is active.

Red Lamp:

Flash: The Red lamp will flash while any fatal fault is active.

The light strips above the top trap bill be steady red while any fatal fault is active.

Buzzer: The Audible Alarm will long pulse (1 second) when a fatal fault is present.

The buzzer will short pulse before the system starts, before a labeler is moved up/down, or while the top trap is moving.

Warning Messages: Warning messages identify a status or event that may need action soon. The machine will not stop from a warning message, but a warning may turn into a fatal fault that will stop the machine. Many warning messages will automatically clear once the problem is remedied.

Events that trigger an automatic crossover will be followed by “Crossover Initiated”. These events would be fatal faults if the Crossover function was disabled.

Fatal Messages: Fatal messages will cause the system to stop immediately or initiate a cycle stop. Fatal faults are typically associated to events that prevent labels being applied properly, safety related faults, or other events that may prevent proper machine operation.



Messages	Cause/Solution
Warning Messages	
Labeler #x Drive Faulted / Turned Off Warning	The drive that controls the listed labeler is faulted or turned off. If pressing the reset button does not clear this message, verify that the drive is powered up.
Labeler #x Broken Web Warning	The Broken Web sensor (between the drive system and rewind) on the Labeler is active and the Labeler is Stopped. Placing the Labeler into Run will generate a Fatal Fault.
Labeler #x End of Web Warning	The End Of Web sensor (between the drive system and unwind) on the Labeler is active and the Labeler is Stopped. Placing the Labeler into Run will generate a Fatal Fault.
Labeler #x Low Label Supply	The label supply on the labeler has been determined low by the sensor fiber under the flange.
Labeler #X Program Stopped Warning. Reset / Re-Enable Drive	The internal program of the listed labeler drive is not executing logic. Pressing the Reset button or re-enabling the drive should remedy this problem.
Labeler #X Disabled Warning	The listed labeler has been disabled from its Service Menu. Re-Enable the drive before attempting to run it.
Labeler #x Torque Limit Reached / Drive Roll Jam. Clear Before Running	The listed labeler has reached its internal current limit, which typically indicates a jam at the drive roll area. Disable the labeler and clear any jams before continuing.
Labeler #x Out of Position Warning	The listed labeler is not in the “in” position. This can be due to the slide handle being in the out position, a loss of air, or the position sensor not being set properly.
Labeler #x Communications Loss Warning	The listed labeler drive has stopped communicating with the PLC. This can indicate the drive is not powered up, is faulted, or physically disconnected from the local network.
Cycle Stop in Progress. Please Wait or Press Stop Button	The machine is currently in a cycle stop and will stop once the cycle stop distance expires. Pressing the Stop button while a cycle stop is active will stop the machine immediately.
(motor) Drive (DRx) Faulted / Turned Off Warning	The drive that controls the listed motor is faulted or turned off. If pressing the reset button does not clear this message, verify that the drive is powered up.

Warning Messages, cont.	
Infeed Empty / Starved. Product Flow Stopped Outfeed Full / Blocked. Product Flow Stopped	The Product Flow has stopped because the Infeed and/or Outfeed sensors are not satisfied.
Screen Not Started Properly / PLC Power Cycled. Restart System	The PLC waits for a signal from the touch screen after power-up to verify communications before executing logic. If the PLC is cycled from power or downloading, the screen must be cycled as well.
Labeler #x Low Label Batch Count Started	The listed labeler encountered a low label fault and a label batch count down started before crossing over to the other labeler. This only occurs if Crossover and Batch modes are enabled.
Both Labelers Stopped Warning	When crossover is enabled, this message will alert the operator that one labeler must be placed into run before starting the system.
Setup Mode Active. Hold Start Button to Jog System	The Setup Mode is currently turned on. While on, the system can be jogged by pressing and holding the Start button.
Top Trap Movement Timed Out. Check for Jams or Re-Start Movement	The Top Trap was requested to automatically move to a position but it timed out. This can happen if the current value and target values are too far apart, an issue with the position sensor, or the top trap did not physically move.
Target Linear Speed Warning. Check Rate, Pitch, Width	The target conveyor speed has exceeded an internal limit. Check the Rate, Pitch, and Width and adjust as needed to lower the target linear speed of the conveyor before starting the machine.

Messages	Cause/Solution
Fatal Messages	
Labeler #x Drive Faulted / Turned Off	The drive that controls the listed labeler is faulted or turned off. If pressing the reset button does not clear this message, verify that the drive is powered up.
Labeler #x Broken Web Fault	The Broken Web sensor (between the drive system and rewind) on the Labeler is active and the Labeler was Running or placed into Run.
Labeler #x End of Web Fault	The End Of Web sensor (between the drive system and unwind) on the Labeler is active and the Labeler was Running or placed into Run.
Labeler #X Program Stopped Fault. Reset / Re-Enable Drive	The internal program of the listed labeler drive stopped executing logic while it was running or attempted to run. Reset the drive or re-enable the drive.
Labeler #X Disabled Fault. Navigate to Labeler #X Service Menu	The listed labeler has been disabled from its Service Menu while it was running or attempted to run. Re-Enable the labeler from its service menu.
Labeler #x Out of Position Fault	The listed labeler is not in the "in" position and the labeler was running or attempted to run. This can be due to the In/Out switch being in the "Out" position, something bound up in the slide, or a faulty home sensor.
Labeler #x Communications Loss Fault	The listed labeler drive has stopped communicating with the PLC. This can indicate the drive is not powered up, faulted, or physically disconnected from the local network.
(motor) Drive (DRx) Faulted / Turned Off	The drive that controls the listed motor is faulted or turned off. If pressing the reset button does not clear this message, verify that the drive is powered up.
Conveyor Speed Fault - Check Rate, Pitch, and Calibration Values.	The target conveyor speed has exceeded an internal limit. Check the Rate, Pitch, and Width and adjust as needed to lower the target linear speed of the conveyor before re-starting the machine.
Labeler #X Not Ready for Crossover	A crossover sequence was initiated, but the target labeler had a fault condition that prevented it from running. Clear the faults on both labelers.

Messages	Cause/Solution
Fatal Messages, cont.	
Both Labelers Stopped Fault	Both labelers are stopped and the machine was attempted to run. Place a labeler in run to start the system.
PLC Faulted.	The PLC has encountered a fault and must be reset.
Safety Relay Active: Check E-Stops & Doors then Reset	The Safety relay has been activated by an Emergency Stop. Unlatch all Emergency Stops, close all doors, and press the Reset button to reset the safety relay.
Crossover #x to #x Timed Out	The crossover sequence in the listed direction has timed out. This can be from a faulty encoder signal, an incorrect distance, or incorrect counts per inch entry.

To set user passwords during initial setup navigate to the passwords screen, then Log in using password "7670" Once logged in users can set passwords per HMI Guide.





USER MENU

Sunday

mm/dd/yy

HH:MM:SS


Passwords




Current User:

Default

Auto Logout

Disabled



Log Out
Timer:

12:34

Setup Sheets

Fuji Ace for Techlines & Master / Followers v.000

Job: 84187 Drive: DRI REAR BELT Motor: Bodine 3/4

SETUP AND ADJUSTMENTS: (Reference Fuji drive manual for detailed information)

Initial Power-Up:

The display will show "8.dES". Press the Func/Data Key.

"ASIA" will be displayed. Press the Stop and Up/Down keys until "ANer" is displayed.

Press the Func/Data Key to save the setting.

Set Primary Parameters:

Parameter	Fuji Default	Quadrel Default Value	Quadrel Final Value	Description
F01	0	1 (0-10V Terminals) 12* (PG Card)	1	Frequency Command
F02	2	1 (Terminals)	1	Operation
F03*	60.0	60.0	84.0	Max Frequency
F07**	6.0	3.0	3.0	Accel Time
F08**	6.0	3.0	3.0	Decel Time
F15	70	70	85	Upper Freq Limit
F42	0	2	2	Control Mode
H04	0	5	5	Auto Reset Attempts
H05	5.0	3.0	3.0	Auto Reset Delay
P99	0	1 (HP)	1	Motor Type
P02	Varies	See Motor Nameplate	1.38	Rated Capacity (HP)

*If Max Frequency exceeds 70.0, Adjust F15 first.

**Set to 0.0 for Following Top Trap / Hugger Drive

PG Card Parameters for Following Top Trap / Hugger Drive:

Following parameters required regardless if encoder installed:

D59	2	2	2	Command Encoder Type
D62	1	1		Command Scaling Factor 1
D63	1	1		Command Scaling Factor 2
F14	1	5	5	Restart Mode
F31	0	21	21	FM Terminal Output
H96	3	0	0	Stop/Start Check

Following parameters if encoder installed on Top Trap/Slave Hugger Drive Motor:

Parameter	Fuji Default	Quadrel Default Value	Quadrel Final Value	Description
D14	2	2	2	Feedback Encoder Type
D15*	400 (1024)	Check Encoder		Feedback Encoder PPR (HEX)
D16	1	1	1	Feedback Scaling Factor 1
D17	1	1	1	Feedback Scaling Factor 2
D41	0	2	2	Application Function
D60*	400 (1024)	Check Encoder		Command Encoder PPR (HEX)
F42	0	2	6	Control Mode

* 78 For Techline Top Trap (120 PPR Encoder to Motor Shaft)

* 7D For Techline Conveyor (1200 PPR Encoder to Conveyor Sidewall)

Initialize Parameters

- Navigate to Parameter H03
- Use the STOP and UP Arrow to change H03 to "2"
- H03 will revert back to "0" once the parameters are automatically set.

Set the Motor Current based on the Motor Nameplate value. Entered as Amps.

Parameter	Fuji Default	Motor Nameplate	Quadrel Final value
P03	Varies	1.40	1.40

Fuji Ace for Techlines & Master / Followers v.000

Job: 84187 Drive: DR2 Floor Belt Motor: Bedrock 38

SETUP AND ADJUSTMENTS: (Reference Fuji drive manual for detailed information)

Initial Power-Up:

The display will show "8.dES". Press the Func/Data Key.

"ASIA" will be displayed. Press the Stop and Up/Down keys until "ANEr" is displayed.

Press the Func/Data Key to save the setting.

Set Primary Parameters:

Parameter	Fuji Default	Quadrel Default Value	Quadrel Final Value	Description
F01	0	1 (0-10V Terminals) 12* (PG Card)	<u>12</u>	Frequency Command
F02	2	1 (Terminals)	<u>1</u>	Operation
F03*	60.0	60.0	<u>90</u>	Max Frequency
F07**	6.0	3.0	<u>0</u>	Accel Time
F08**	6.0	3.0	<u>0</u>	Decel Time
F15	70	70	<u>90</u>	Upper Freq Limit
F42	0	2	<u>2</u>	Control Mode
H04	0	5	<u>5</u>	Auto Reset Attempts
H05	5.0	3.0	<u>3.0</u>	Auto Reset Delay
P99	0	1 (HP)	<u>1</u>	Motor Type
P02	Varies	See Motor Nameplate	<u>38</u>	Rated Capacity (HP)

*If Max Frequency exceeds 70.0, Adjust F15 first.

**Set to 0.0 for Following Top Trap / Hugger Drive

PG Card Parameters for Following Top Trap / Hugger Drive:

Following parameters required regardless if encoder installed:

D59	2	2	<u>2</u>	Command Encoder Type
D62	1	1	<u>13</u>	Command Scaling Factor 1
D63	1	1	<u>415</u>	Command Scaling Factor 2
F14	1	5	<u>5</u>	Restart Mode
F31	0	21	<u>21</u>	FM Terminal Output
H96	3	0	<u>0</u>	Stop/Start Check

Following parameters if encoder installed on Top Trap/Slave Hugger Drive Motor:

Parameter	Fuji Default	Quadrel Default Value	Quadrel Final Value	Description
D14	2	2	<u>2</u>	Feedback Encoder Type
D15*	400 (1024)	Check Encoder	<u>120</u>	Feedback Encoder PPR (HEX!)
D16	1	1	<u>1</u>	Feedback Scaling Factor 1
D17	1	1	<u>1</u>	Feedback Scaling Factor 2
D41	0	2	<u>2</u>	Application Function
D60*	400 (1024)	Check Encoder	<u>120</u>	Command Encoder PPR (HEX!)
F42	0	2	<u>6 2</u>	Control Mode

* 78 For Techline Top Trap (120 PPR Encoder to Motor Shaft)

* 7D For Techline Conveyor (1200 PPR Encoder to Conveyor Sidewall)

Initialize Parameters

- Navigate to Parameter H03
- Use the STOP and UP Arrow to change H03 to "2"
- H03 will revert back to "0" once the parameters are automatically set.

Set the Motor Current based on the Motor Nameplate value. Entered as Amps.

Parameter	Fuji Default	Motor Nameplate	Quadrel Final value
P03	Varies	<u>1.70</u>	<u>1.70</u>

Fuji Ace for Techlines & Master / Followers v.000

Job: 84187 Drive: DR3 CONVEYOR Motor: LEESON 1HP

SETUP AND ADJUSTMENTS: (Reference Fuji drive manual for detailed information)

Initial Power-Up:

The display will show "8.dES". Press the Func/Data Key.

"ASIA" will be displayed. Press the Stop and Up/Down keys until "ANER" is displayed.

Press the Func/Data Key to save the setting.

Set Primary Parameters:

Parameter	Fuji Default	Quadrel Default Value	Quadrel Final Value	Description
F01	0	1 (0-10V Terminals) 12* (PG Card)	1	Frequency Command
F02	2	1 (Terminals)	1	Operation
F03*	60.0	60.0	90	Max Frequency
F07**	6.0	3.0	3.0	Accel Time
F08**	6.0	3.0	3.0	Decel Time
F15	70	70	90	Upper Freq Limit
F42	0	2	2	Control Mode
H04	0	5	5	Auto Reset Attempts
H05	5.0	3.0	3.0	Auto Reset Delay
P99	0	1 (HP)	1	Motor Type
P02	Varies	See Motor Nameplate	1	Rated Capacity (HP)

*If Max Frequency exceeds 70.0, Adjust F15 first.

**Set to 0.0 for Following Top Trap / Hugging Drive

PG Card Parameters for Following Top Trap / Hugging Drive:

Following parameters required regardless if encoder installed:

D59	2	2	2	Command Encoder Type
D62	1	1		Command Scaling Factor 1
D63	1	1		Command Scaling Factor 2
F14	1	5	5	Restart Mode
F31	0	21	21	FM Terminal Output
H96	3	0	0	Stop/Start Check

Following parameters if encoder installed on Top Trap/Slave Hugging Drive Motor:

Parameter	Fuji Default	Quadrel Default Value	Quadrel Final Value	Description
D14	2	2	2	Feedback Encoder Type
D15*	400 (1024)	Check Encoder		Feedback Encoder PPR (HEX!)
D16	1	1	1	Feedback Scaling Factor 1
D17	1	1	1	Feedback Scaling Factor 2
D41	0	2	2	Application Function
D60*	400 (1024)	Check Encoder		Command Encoder PPR (HEX!)
F42	0	2	6	Control Mode

* 78 For Techline Top Trap (120 PPR Encoder to Motor Shaft)

* 7D For Techline Conveyor (1200 PPR Encoder to Conveyor Sidewall)

Initialize Parameters

- Navigate to Parameter H03
- Use the STOP and UP Arrow to change H03 to "2"
- H03 will revert back to "0" once the parameters are automatically set.

Set the Motor Current based on the Motor Nameplate value. Entered as Amps.

Parameter	Fuji Default	Motor Nameplate	Quadrel Final value
P03	Varies	3.0	3.0

Fuji Ace for Techlines & Master / Followers v.000

Job: 84187 Drive: DRY Top Trap Motor: 1300w

SETUP AND ADJUSTMENTS: (Reference Fuji drive manual for detailed information)

Initial Power-Up:

The display will show "8.dES". Press the Func/Data Key.

"ASIA" will be displayed. Press the Stop and Up/Down keys until "ANEr" is displayed.

Press the Func/Data Key to save the setting.

Set Primary Parameters:

Parameter	Fuji Default	Quadrel Default Value	Quadrel Final Value	Description
F01	0	1 (0-10V Terminals) 12* (PG Card)	<u>12</u>	Frequency Command
F02	2	1 (Terminals)	<u>1</u>	Operation
F03*	60.0	60.0	<u>90</u>	Max Frequency
F07**	6.0	3.0	<u>6</u>	Accel Time
F08**	6.0	3.0	<u>6</u>	Decel Time
F15	70	70	<u>90</u>	Upper Freq Limit
F42	0	2	<u>2</u>	Control Mode
H04	0	5	<u>5</u>	Auto Reset Attempts
H05	5.0	3.0	<u>3.0</u>	Auto Reset Delay
P99	0	1 (HP)	<u>1</u>	Motor Type
P02	Varies	See Motor Nameplate	<u>1.38</u>	Rated Capacity (HP)

*If Max Frequency exceeds 70.0, Adjust F15 first.

**Set to 0.0 for Following Top Trap / Hugger Drive

PG Card Parameters for Following Top Trap / Hugger Drive:

Following parameters required regardless if encoder installed:

D59	2	2	<u>23</u>	Command Encoder Type
D62	1	1	<u>25</u>	Command Scaling Factor 1
D63	1	1	<u>418</u>	Command Scaling Factor 2
F14	1	5	<u>5</u>	Restart Mode
F31	0	21	<u>210</u>	FM Terminal Output
H96	3	0	<u>0</u>	Stop/Start Check

Following parameters if encoder installed on Top Trap/Slave Hugger Drive Motor:

Parameter	Fuji Default	Quadrel Default Value	Quadrel Final Value	Description
D14	2	2	<u>2</u>	Feedback Encoder Type
D15*	400 (1024)	Check Encoder	<u>120</u>	Feedback Encoder PPR (HEX!)
D16	1	1	<u>1</u>	Feedback Scaling Factor 1
D17	1	1	<u>1</u>	Feedback Scaling Factor 2
D41	0	2	<u>2</u>	Application Function
D60*	400 (1024)	Check Encoder	<u>120</u>	Command Encoder PPR (HEX!)
F42	0	2	<u>2</u>	Control Mode

* 78 For Techline Top Trap (120 PPR Encoder to Motor Shaft)

* 7D For Techline Conveyor (1200 PPR Encoder to Conveyor Sidewall)

Initialize Parameters

- Navigate to Parameter H03
- Use the STOP and UP Arrow to change H03 to "2"
- H03 will revert back to "0" once the parameters are automatically set.

Set the Motor Current based on the Motor Nameplate value. Entered as Amps.

Parameter	Fuji Default	Motor Nameplate	Quadrel Final value
P03	Varies	<u>1.40</u>	<u>1.40</u>

Fuji Ace for Techlines & Master / Followers v.000

Job: 84187 Drive: DES LIFT Motor: Bodipe

SETUP AND ADJUSTMENTS: (Reference Fuji drive manual for detailed information)

Initial Power-Up:

The display will show "8.dES". Press the Func/Data Key.

"ASIA" will be displayed. Press the Stop and Up/Down keys until "ANEr" is displayed.

Press the Func/Data Key to save the setting.

Set Primary Parameters:

Parameter	Fuji Default	Quadrel Default Value	Quadrel Final Value	Description
F01	0	1 (0-10V Terminals) 12* (PG Card)	0	Frequency Command
F02	2	1 (Terminals)	1	Operation
F03*	60.0	60.0	25	Max Frequency
F07**	6.0	3.0	1.50	Accel Time
F08**	6.0	3.0	1.50	Decel Time
F15	70	70	70	Upper Freq Limit
F42	0	2	2	Control Mode
H04	0	5	5	Auto Reset Attempts
H05	5.0	3.0	3.0	Auto Reset Delay
P99	0	1 (HP)	1	Motor Type
P02	Varies	See Motor Nameplate	1.38	Rated Capacity (HP)

*If Max Frequency exceeds 70.0, Adjust F15 first.

**Set to 0.0 for Following Top Trap / Hugger Drive

PG Card Parameters for Following Top Trap / Hugger Drive:

Following parameters required regardless if encoder installed:

D59	2	2	2	Command Encoder Type
D62	1	1		Command Scaling Factor 1
D63	1	1		Command Scaling Factor 2
F14	1	5	5	Restart Mode
F31	0	21	21	FM Terminal Output
H96	3	0	0	Stop/Start Check

Following parameters if encoder installed on Top Trap/Slave Hugger Drive Motor:

Parameter	Fuji Default	Quadrel Default Value	Quadrel Final Value	Description
D14	2	2	2	Feedback Encoder Type
D15*	400 (1024)	Check Encoder		Feedback Encoder PPR (HEXI)
D16	1	1	1	Feedback Scaling Factor 1
D17	1	1	1	Feedback Scaling Factor 2
D41	0	2	2	Application Function
D60*	400 (1024)	Check Encoder		Command Encoder PPR (HEXI)
F42	0	2	6	Control Mode

* 78 For Techline Top Trap (120 PPR Encoder to Motor Shaft)

* 7D For Techline Conveyor (1200 PPR Encoder to Conveyor Sidewall)

Initialize Parameters

- Navigate to Parameter H03
- Use the STOP and UP Arrow to change H03 to "2"
- H03 will revert back to "0" once the parameters are automatically set.

Set the Motor Current based on the Motor Nameplate value. Entered as Amps.

Parameter	Fuji Default	Motor Nameplate	Quadrel Final value
P03	Varies	1.40	1.40

Fuji Ace for Techlines & Master / Followers v.000

Job: 84187 Drive: DR6 PACE Motor: Bodipe

SETUP AND ADJUSTMENTS: (Reference Fuji drive manual for detailed information)

Initial Power-Up:

The display will show "8.dES". Press the Func/Data Key.

"ASiA" will be displayed. Press the Stop and Up/Down keys until "ANE" is displayed.

Press the Func/Data Key to save the setting.

Set Primary Parameters:

Parameter	Fuji Default	Quadrel Default Value	Quadrel Final Value	Description
F01	0	1 (0-10V Terminals) 12* (PG Card)	1	Frequency Command
F02	2	1 (Terminals)	1	Operation
F03*	60.0	60.0	90	Max Frequency
F07**	6.0	3.0	3.0	Accel Time
F08**	6.0	3.0	3.0	Decel Time
F15	70	70	90	Upper Freq Limit
F42	0	2	2	Control Mode
H04	0	5	5	Auto Reset Attempts
H05	5.0	3.0	3.0	Auto Reset Delay
P99	0	1 (HP)	1	Motor Type
P02	Varies	See Motor Nameplate	1.32	Rated Capacity (HP)

*If Max Frequency exceeds 70.0, Adjust F15 first.

**Set to 0.0 for Following Top Trap / Hugger Drive

PG Card Parameters for Following Top Trap / Hugger Drive:

Following parameters required regardless if encoder installed:

D59	2	2	2	Command Encoder Type
D62	1	1		Command Scaling Factor 1
D63	1	1		Command Scaling Factor 2
F14	1	5	5	Restart Mode
F31	0	21	21	FM Terminal Output
H96	3	0	0	Stop/Start Check

Following parameters if encoder installed on Top Trap/Slave Hugger Drive Motor:

Parameter	Fuji Default	Quadrel Default Value	Quadrel Final Value	Description
D14	2	2	2	Feedback Encoder Type
D15*	400 (1024)	Check Encoder		Feedback Encoder PPR (HEX)
D16	1	1	1	Feedback Scaling Factor 1
D17	1	1	1	Feedback Scaling Factor 2
D41	0	2	2	Application Function
D60*	400 (1024)	Check Encoder		Command Encoder PPR (HEX)
F42	0	2	6	Control Mode

* 78 For Techline Top Trap (120 PPR Encoder to Motor Shaft)

* 7D For Techline Conveyor (1200 PPR Encoder to Conveyor Sidewall)

Initialize Parameters

- Navigate to Parameter H03
- Use the STOP and UP Arrow to change H03 to "2"
- H03 will revert back to "0" once the parameters are automatically set.

Set the Motor Current based on the Motor Nameplate value. Entered as Amps.

Parameter	Fuji Default	Motor Nameplate	Quadrel Final value
P03	Varies	1.40	1.40

WARNING



- KEEP HAND CLEAR OF MOVING PARTS. DO NOT PLACE HANDS NEAR LABELING HEAD WHEN IN OPERATION



- DO NOT OPERATE EQUIPMENT WITHOUT GUARDS OR COVERS INSTALLED



6.1 LABELING HEAD INFORMATION

6.1.1 LOADING AND UNLOADING STOCK ROLL



CAUTION

To avoid injuries, you must keep the labeler stopped/paused. You can manually jog labels with the JOG button.

Look carefully at the diagram and follow the threading procedures indicated below.

You will also find the threading diagram directly on the labeling head.

- 1) Place the label stock roll on the unwind shaft. Press the roll firmly against the flange. Then slide the locking collar over the unwind shaft aligning the set screw with the shaft. Press into the roll and twist to lock the collar in place.



- 2) Pull Approximately 36-40" of stock from label stock roll.





- 3) Follow the threading diagram on the labeling head for routing the web.
- 4) Thread through the dancer to the peel plate.








- 5) Feed the label around the peel plate and under the pressure shoe if (if there is one). Feed the label up the head to the pull roll. Pull all the slack out.




- 6) Wrap labels around the rubber roller as shown, then around the knurled roller. Make sure the knurled roller is not locked in by turning the red knob to the left or right of the red dot on the drive roll. When you have the labels completely threaded you can turn the knob to the red dot.



- 7) Thread the labels through the rewind dancers to the rewind shaft. Place the end of the label through the clip and rotate the rewind hub to take up the slack.



- 8) The finished product should look similar to the pictures below. Some heads are threaded differently depending on the style head you have. See threading diagrams on the head itself or the manual.



- 9) To unload the rewind loosen (counter clockwise) the “clevis” bolt on the top of the rewind hub. this will collapse the rewind and you can pull the liner off the hub.




CAUTION


There are many pinch points on a labeler. to avoid injury read and understand the owner’s manual before operating.

6.1.2 THREADING DIAGRAMS


Here are the following threading diagrams for our standard labeling heads.




Q120/Q125/Q115/Q110



Q60/Q65



Q34



E100

6.1.3 LABELER ADJUSTMENTS

The vertical adjustment is to position the label on the container at different heights. It's practical if you have different size labels and/or containers. To adjust the height you simply rotate the handwheel at the top of the labeler counter clockwise to go down and clockwise to go up.



Horizontal adjustments are made the same way except you rotate the hand wheel under the labeler. Rotating the hand wheel counter clockwise will move the labeler in and rotating clockwise will move the labeler out.



To adjust the angle of the labeling head you first need to loosen the large $\frac{3}{4}$ -10 nut with a $1\frac{1}{4}$ " wrench and the $\frac{5}{16}$ -18 hex head bolt. The angular adjustment is very important to increase the repeatability of the process. A good adjustment is when the exit of the label is tangent with the surface of the application.



CAUTION

DO NOT remove the nut & bolt.



Now to adjust the tilt of the labeling head by tightening and loosening the jack screws.



Rotate adjustment is achieved by loosening the 2 ratchet handles under the labeling head. There is a jack screw holding the labeling head in place, but still use caution when loosening the ratchet handles the labeling head can rotate

freely when loose. This is a fine adjustment that increases the parallelism of the label to the shape of the container.



CAUTION

When loosening the labeling head, the head may rotate freely. Keep positive pressure against the head to prevent the head from rotating on its own.





QUADREL LABELING SYSTEMS

Q125

LABELING HEAD

GENERAL DESCRIPTION

- The Q125 has been developed as a heavy duty automatic labeling head system for integration into high speed, high rate production environments. The labeling head can be configured for either wrap or wipe on applications. The Q125 uses a servo drive and motor system that can be used independently or in conjunction with a PLC. All settings are controlled from a touch screen interface for easy setup and adjustments. In addition, a built in system of fault logic can easily interface with a host of optional sensors.

PRINCIPLE OF FUNCTION

- The Q125 labeling head applies pressure sensitive labels onto moving products. Various principles are involved to achieve accurate label application. In general, a labeling system integrates three (3) basic functions:
 - **Product Handling:** The most common product handling component is the conveyor. Conveyors allow the product to transport smoothly through the labeling station. The Q125 labeler can be supplied either as a stand alone head (head on a stand) or integrated into a complete conveying/product handling system. An encoder from the product handling system must be tied into the labeler's drive.
 - **Label Application:** Usually the label is "tacked" directly to the product during the label dispensing cycle. Secondary label applicators such as brushes, roller or wrap belts are used to finish the label application and to ensure good adhesion.
 - **Label Dispensing:** The Q125 utilizes two movement types to dispense labels. The first movement is a fixed speed, "jog" movement that is used during setup purposes. Jogging labels verifies proper label threading and labeler operation prior applying labels to products. The second movement is a synchronized "run" movement that is used to apply labels on passing products. The labeler's drive system will synchronize speed with the product handling system from an encoder. This eliminates the need to change settings based on system speed and allows for accurate and repeatable labeling.

SEQUENCE OF OPERATION:

- The electrical and mechanical operating sequence described below is intended only to acquaint the operator with the operation of the label dispensing head and its related control circuitry.
- The Jog function is used for manual set-up of label dispensing. Under proper conditions, a jog sequence will dispense one label. Labels must be threaded properly and the labeler stopped (indicated on the touch screen) before Jogging labels.
- The Jog cycle is described in the following manner:
 1. After verifying that labels are threaded properly and the labeler is stopped, a jog button (physical green button near the labeler or a button on the touch screen) must be pressed.
 2. The labeler will start dispensing labels at a fixed speed.
 3. The labeler's drive will monitor a label gap sensor input before finishing a dispensing cycle.
 4. Once the label's gap is detected by the sensor, the labeler will continue dispensing the label for a length defined by the "Label Stop" parameter on the touch screen. This distance is entered as inches.
 5. After the Label Stop distance is reached, the Jog cycle is complete and the labeler stops dispensing labels.
 6. If no label gap is detected, the labeler will only index a maximum distance which is set by the "Max Feed" parameter on the touch screen. This distance is entered as inches.
- When the labeler is in the "Run" mode it will automatically dispense labels on products that are passing by. Labels must be threaded properly and the labeler placed in the Run mode (indicated on the touch screen) to automatically dispense labels
 1. A product activates the Product Detect sensor.
 2. The labeler drive captures the position of the product on the product handling system and starts an internal delay, which is the "Product Delay" parameter on the touch screen.
 3. The Product Delay is equal to inches, so once the product travels the Product Delay distance from the product detect sensor, a label will be dispensed.
 4. The labeler dispenses a label at the speed of the product which is multiplied by the "Speed Ratio" parameter found on the touch screen. The ratio is a multiplier, so a value of 1.0 determines the labeler will dispense at the exact speed of the conveyor.
 5. The labeler monitors the label gap sensor in the same manner of the Jog movement before finishing the dispensing cycle.

ASSEMBLY TITLE: Q125 LABELING HEAD ASSEMBLY

DRAWING NO.: NONE

GENERAL FUNCTION:

- Applies labels to the front and/or back, top/bottom of the products
- Wraps labels around cylindrical products

SET-UP AND ADJUSTMENTS:

- Tighten all loose connections and screws
- As noted in each sub-assembly

MAINTENANCE:

- Remove glue residue and labels from all rollers and idlers
- As noted in each sub-assembly

TROUBLESHOOTING:

- As noted in each sub-assembly

ASSEMBLY TITLE:**Q125 LABELING HEAD - THREADING****GENERAL FUNCTION:**

- This section is used to guide the user through loading and feeding the label through the web path.

SET UP AND ADJUSTMENTS:

- Load label spool onto unwind hub. Secure unwind retainer onto hub and lock. Pull 3-4 feet of web from unwind and strip labels free of web.
- Unlock the drive roller locking handle.
- Using the threading diagram located on the labeling head, feed the web through the labeling head. Start at the unwind dancer assembly and work forward.
- Feed the web through the drive roller assembly.
- Feed the web around the rewind dancer assembly and onto the rewind hub. Wrap the web around the hub once. Lock the web in place with the rewind retaining bracket.
- Once the web has been threaded, lock down the drive roll assembly by rotating the drive roll locking arm into the locked position. (Towards the drive roller assembly)

MAINTENANCE:


- None this section.

TROUBLESHOOTING:PROBLEM

- Web break
- No Web Tension

WHAT TO DO

- Check web path and insure web routed correctly.
- Debris causing web tear and break. Clear as needed.
- Check web path through unwind and dancer assembly.
- Check drive roller lock position.




NOTES:

- 1) LABEL MATERIAL IS .003" ALUMINUM FOIL W/PERMANENT PRESSURE SENSITIVE ADHESIVE.
- 2) ALL LETTERING IS .125" HIGH EUROSTYLE 2, BOLD EXTENDED 2.
- 3) USE QUADREL STANDARD LOGO.
- 4) ALL LINES AND LETTERS ARE BLACK ON A SILVER BACKGROUND QUADREL AND (WEB PATH) ARE RED #(199c) LINES ARE DASHED LINES.
- 5) LABEL SIZE 3.0" X 3.0".

A	5-8-19	NEW DRAWING
REV	DATE	DESCRIPTION

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

<p>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE</p> <p>.X± .1 .XX± .01 .XXX± .005 ANGLES ± 30°</p> <p>SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030</p>		QUADREL LABELING SYSTEMS	SCALE: DRAWING SCALE
		7670 JENTHER DRIVE	DATE: 5-8-19
	MENTOR, OHIO 44060	DRW BY: TJS	
	(440) 602-4700	CHK BY:	
		APPR BY:	
Q110/120/125 R.H. THREADING DIAGRAM			
MAT'L		SEE NOTES	A26222-110RHP

ASSEMBLY TITLE: Q110 SIDE PLATE ASSEMBLY

DRAWING NO.: D24272-000

GENERAL FUNCTION:

- To provide a rigid mounting surface for outboard labeling components, electronic components, and system components.
- The side plate also supports the system mount

SET UP AND ADJUSTMENTS:

- None

MAINTENANCE:


- None

TROUBLESHOOTING:

- None







ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	00669-01	BRAKE BRUSH 2 x 7 nylon	22620SP-002
2	2	181062-000	BEARING, ROLL END	22620SP-002
3	4	181063-000	BEARING, ROLL END	22620SP-002
4	1	791459-000	RUBBER BUMPER	22620SP-002
5	1	A20654-001	ADJ. ROD	22620SP-002
6	2	A20928-013	ROLLER SHAFT	22620SP-002
7	1	A21259-113	IDLER ROLLER	22620SP-002
8	1	A21618-013	IDLER SHAFT	22620SP-002
9	1	A24905-006	PIVOT PIN MOUNTING PLATE	22620SP-002
10	1	A25912-000	MOUNTING PIN SPACER	22620SP-002
11	2	B20071-017	IDLER ROLLER (DANCER)	22620SP-002
12	1	B21495-83564	ROLLER TIE BAR	22620SP-002
13	1	D22800-006	SIDE PLATE, MOD.	22620SP-002



A	Aug-05-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
<div>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .00° SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°</div> <div>QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700</div>		SCALE: 9/16 DATE: Aug-05-25 DRW BY: TAZ CHK BY: APPR BY:	
		Q125 12"SIDE PLATE	
		MAT'L	
		22620SP-002	22620SP-002



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 7/16	
X ± .1		DATE: Aug-05-25	
XX ± .01		DRW BY: TAZ	
XXX ± .005		CHK BY:	
ANGLES ± .00°		APPR BY:	
SURFACE FINISH 125		Q125 12" SIDE PLATE	
BREAK ALL EDGES .005/ .015		MAT'L	
CORNER RADIUS .010/ .030		22620SP-002	
ALL ANGLES ARE 90°		22620SP-002	

ASSEMBLY TITLE:**Q120 UNWIND ASSEMBLY****GENERAL FUNCTION:**

- Unwind flange provides support for label rolls (side application)
- Dual flanges prevent roll and label movement (top application)
- Dancer arm prevents roll run-away.
- Idler roller with guide collars guides web through slot sensor.
- Brake brush prevents web buckling through slot sensor.

SET UP AND ADJUSTMENTS:

- Move flange to required height and tighten set screw in flange hub.
- For top labeling, add second flange and tighten ratchet knob.
- Adjust dancer tension by turning check nut so that dancer roll snaps back to braking position when labeling head is threaded.
- Slide brake brush so that center of brush lines up with center of web. Rotate brush to provide web tension, then lock into place using the locking knob.
- Position guide collars on idler roll, one slightly above, the other slightly below the web.

DANCER TENSION ADJUSTMENT LOCATION:

- The unwind tension adjustment is located on the middle underside of the Q120 head. Use the knurled ring to adjust the dancer tension.

MAINTENANCE:

- Clean all the parts that may acquire glue residue

TROUBLESHOOTING:**PROBLEM**

- Unwind roll run-away
- Unwind roll not stopping
- Drive roll stalling
- Brush taking fixed shape

WHAT TO DO

- Tighten dancer spring, check nut or replace dancer spring, if necessary.
- Replace brake ring-belt if broken, or unevenly worn.
- Release web tension produced by brake brush.
- Turn brush around



ASSEMBLY TITLE: Q120 LABELING HEAD - DANCER ARM ASSEMBLY

DRAWING NO.: None Applicable

GENERAL FUNCTION:

- The dancer arm and braking mechanism are used to control the unwind unit which will only advance a few inches of web at any time
- The position of the dancer arm affects the advancement of the web off the label roll.

SET UP AND ADJUSTMENTS:

- The dancer normal position of the dancer arm is reached when the dancer arm locks the supply reel.
- The spring tension can be adjusted to correctly locate the dance arm
- The spring may be adjusted by turning the threaded tensioner located near the unwind unit.
- The spring should be tight enough to bring the dancer arm back to its normal position and hold it with some force, but not tight enough to tear the web during label feed.
- Spring adjustment is also possible by rotating the spring mounting pin on the spring take up pulley around the mounting shaft.
- While in its normal position, the dancer arm roller should not interfere with the supply reel flange.

MAINTENANCE:

- Replace dancer spring if final spring tension is too soft.

TROUBLESHOOTING:

PROBLEM

- Web break
- Too much web slack
- Dancer arm hits supply flange position by loosening the brake cam.

WHAT TO DO

- Lower spring tension on dancer arm
- Increase spring tension
- Correct dancer arm final

ASSEMBLY TITLE:**Q120 LABELING HEAD - BRAKE BRUSH
ASSEMBLY****GENERAL FUNCTION:**

- The brake brush establishes web tension and controls backlash

SET UP AND ADJUSTMENTS:

- For accurate label feeds, the web must establish proper tension.
- Loosen the holding set screw in the brake brush body. The brake brush assembly can now be rotated on axis.
- Turn brush body into the web and tighten. To check for proper web tension, jog a label and check for web slack. If the web is tight and the label feeds correctly, the brush tension is set correctly.
- If backlash persists, continue to increase brake brush tension.

MAINTENANCE:

- Replace brake brush when brush body contour no longer viable or bristles are worn down.

TROUBLESHOOTING:PROBLEM

- Web break

- Motor stall

- Too much web slack





WHAT TO DO

- Too much brake tension. Decrease until no slack in web.


- Debris or brake flaw causing web tear

- Decrease brake tension


- Increase brake tension



SHEET 2 OF 2

A		Aug-05-25		NEW DRAWING		TAZ	
REV		DATE		DESCRIPTION		BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY							
<div>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030 ALL ANGLES ARE 90°</div>		<div> QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700</div>				SCALE: 5/16 DATE: Aug-05-25 DRW BY: TAZ CHK BY: APPR BY:	
		Q125 12" UNWIND					
		MAT'L		21754B-117		21754B-117	

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	6	181073-000	BEARING, ROLL END	22620HS-84187
2	3	A25695-313	ROLLER SHAFT	22620HS-84187
3	3	A25696-313	IDLER ROLLER	22620HS-84187
4	2	A25750-014_00	PEEL PLATE MTG. ROD	22620HS-84187
5	1	B22301-111	RAIL HOLDER MTG PLATE	22620HS-84187
6	1	B22301-117	RAIL HOLDER MTG PLATE	22620HS-84187
7	2	B22531-313	RAIL MTG BAR	22620HS-84187






A	Aug-05-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .00°		SCALE: 7/16 DATE: Aug-05-25 DRW BY: TAZ CHK BY: APPR BY:	
SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		HOT STAMP KIT	
MATERIAL		22620HS-84187	22620HS-84187




7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700




THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 7/16	
XX ± .1		DATE: Aug-05-25	
XXX ± .005		DRW BY: TAZ	
ANGLES ± .00		CHK BY:	
SURFACE FINISH 125		APPR BY:	
BREAK ALL EDGES .005/ .015		HOT STAMP KIT	
CORNER RADIUS .010/ .030		MATERIAL	
ALL ANGLES ARE 90°		22620HS-84187	
		22620HS-84187	





ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	A20583-100	QUICK LOCK COLLAR	22604-001
2	1	A21775-000	WHITE NYLON SLUG	22604-001
3	1	B20980-200	UNWIND FLANGE	22604-001



A	5-13-16	NEW DRAWING	ATT
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030	 QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	SCALE: 1/1 DATE: 5-13-16 DRW BY: ATT CHK BY: 03/09/2024-SEM APPR BY:
		16" OUTSIDE FLANGE 1" bore MAT'L 22604-001



.74

SHEET 2 OF 2

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE

XX

±

.1

XXX

±

.005

ANGLES

±

90°

SURFACE FINISH 125

BREAK ALL EDGES .005/ .015

CORNER RADIUS .010/ .030

ALL ANGLES ARE 90°

QUADREL LABELING SYSTEMS

7670 JENTHER DRIVE

MENTOR, OHIO 44060

(440) 602-4700

SCALE: 3/4

DATE: 5-13-16

DRW BY: ATT

CHK BY: 03/09/2024-SEM

APPR BY:

16" OUTSIDE FLANGE 1" bore

MAT'L

22604-001

A	5-13-16	NEW DRAWING	ATT
REV	DATE	DESCRIPTION	BY

ASSEMBLY TITLE: MOUNTING BRACKET ASSEMBLY

DRAWING NO.: D21825-000

GENERAL FUNCTION:

- The bracket assembly is the main mounting assembly to mount the imprinter to the head .
- Adjustments are provided to set the imprinters location on the label.

SET UP AND ADJUSTMENTS:

- Loosen the locking handle on top of assembly use the adjusting knob to make the correction of the imprinter head.
- Re-tighten each handle when the correct angular position is set.

NOTE: Make sure each handle is secure, the imprinter head is heavy and could rotate if the locking handles are not firmly secured.

MAINTENANCE:

- No scheduled maintenance for this assembly.


TROUBLESHOOTING:

Problem

- Labeler angular position moves





What To Do

Secure locking tension by turning locking handles clockwise



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	131074-000	BEARING, FLANGED	21928-82552
2	1	141095-000	SLEEVE BEARING	21928-82552
3	2	791531-000	SPRING PLUNGER, 1/4-20	21928-82552
4	1	801274-000	KNOB, 1/4-20	21928-82552
5	1	801312-000	CLAMPING LEVER	21928-82552
6	4	801327-000	KNOB	21928-82552
7	4	801601-000	CHECK NUT	21928-82552
8	1	801836-000	CLAMPING LEVER	21928-82552
9	1	A21008-000	LOCKING CLAMP (THREADED)	21928-82552
10	1	A21009-000	LOCKING CLAMP (CLEARANCE)	21928-82552
11	1	A21154-001	PRINTER MTG. PLATE - LOCKING (7" WEB)	21928-82552
12	1	A21155-001	PRINTER MTG. PLATE (7" WEB)	21928-82552
13	4	A24438-001	SPACER, ROD	21928-82552
14	1	A24440-000	BRASS, NUT	21928-82552
15	1	A24442-013	THREADED ROD	21928-82552
16	1	A25075-013	IMPRINTER PAD	21928-82552
17	1	A25140-013	IMPRINTER PLATE	21928-82552
18	1	B21565-013	END PLATE, MOUNTING	21928-82552
19	1	B21566-013	TOP PLATE, MOUNTING	21928-82552
20	1	B21568-000	SLIDING PLATE, MOUNTING	21928-82552
21	1	B21569-000	INDEX PLATE, MOUNTING	21928-82552
22	1	B21570-000	BLOCK, MOUNTING SMART DATE	21928-82552
23	3	RHN010		21928-82552
24	4	SYE616		21928-82552


THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY		QUADREL LABELING SYSTEMS	
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XXX ± .005 ANGLES ± .00° SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
SCALE: 3/8 DATE: 5-31-18 DRW BY: ATT CHK BY: 08/08/2025-SEM APPR BY:		CODER MOUNT	
SHEET 1 OF 2		21928-82552	



SHEET 2 OF 2

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED	
DIMENSIONAL TOLERANCE	
X ± .1	
XX ± .01	
XXX ± .005	
ANGLES ± .50°	
SURFACE FINISH .125	
BREAK ALL EDGES .005/ .015	
CORNER RADIUS .010/ .030	
ALL ANGLES ARE 90°	



QUADREL LABELING SYSTEMS
7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

SCALE: 1/2	
DATE: 5-31-18	
DRW BY: ATT	CHK BY: 08/08/2025-SEM
APPR BY:	

CODER MOUNT	
MAT'L	21928-82552

Items: 22240-000 Thru 22240-000

Location: 01 QUADREL WHSE

Activity Codes: Active Items Only

1 Levels With No Blow Through

No Selection On Basis Of Effectivity Date

No Selection On Basis Of Obsolete Date

Level	Seq	Component-Item	Component-Description	Loc	Opr	UOM	Scrap	Act	Stk	B/I	Qty On-Hand	Qty-Per-Parent
					LLC	Draw	REV	P/M	Ctl	B/F	Qty-Allocated	Qty-On-Order

```

=====
Parent Item: 22240-000      "ALLEN" HOT STAMP 50/30      Loc: 01  LLC: 1
                        WITH ACCESSORIES
1          5 770156-000      ALLEN HOT STAMP IMPRINTER LH      0  EA      .0  A  Y  N      1.000000
                        NORWOOD P/N 50-30      01      2      P  Y  N
1          10 771341-000      PRINTER,HOT STAMP,ELEC CONTROL      0  EA      .0  A  Y  N      1.000000
                        "ALLAN" 8705      01      2      P  Y  N
1          15 771342-000      PRINTER,HOT STAMP,POWER PACK      0  EA      .0  A  Y  N      1.000000
                        "ALLAN" 8540      01      2      P  Y  N
1          20 771343-000      PRINTER,HOT STAMP,AIR SERVICE      0  EA      .0  A  Y  N      1.000000
                        "ALLAN" 2440      01      2      P  Y  N
1          25 770022-000      TYPE HOLDER 8PT FIXED ROW      0  EA      .0  A  Y  N      1.000000
                        ALLEN P/N 2391      01      3      P  Y  N
1          30 392802-000      FEMALE FITTING, 1/4 TO 6mm      0  EA      .0  A  Y  N      1.000000
                        "SMC" KQH06-UO2 ****      01      4      P  Y  N
1          35 391240-000      FILTER/REGULATOR GAUGE & BRK      0  EA      .0  A  Y  N      1.000000
                        "SMC" AWG20-N02BG1-CZ-B *      01      5      P  Y  N
1          45 391811-000      DISCONNECT, SLEEVE, 1/4 NPT      0  EA      .0  A  Y  N      1.000000
                        FOSTER 3W-250, TOMCO S2      01      7      P  Y  N
1          50 392046-000      90 DEGREE STREET ELBOW      0  EA      .0  A  Y  N      1.000000
                        ANDERSEN P/N 116A-B ****      01      7      M  Y  N
1          55 391954-000      COUPLING 1/4"NPT HOSE DISCONN.      0  EA      .0  A  Y  N      1.000000
                        AIR CHIEF# DCP21B      01      7      P  Y  N
1          60 392803-001      AIR FITTING REDUCER, 6mm-5mm      0  EA      .0  A  Y  N      1.000000
                        McMaster-Carr #5449K353      01      3      P  Y  N

```

ASSEMBLY TITLE: Q120 PEEL PLATE ASSEMBLY

GENERAL FUNCTION:

- The peel plate separates the label from the liner and puts the label in a "Flag" position.
- The mounting rods support the slot sensor assembly.
- The guide collars and the idler roller guide the web position over the peel plate
- The pivot pin provides for yoke mounting of the labeling head.

SET UP AND ADJUSTMENTS:

- On machines so equipped, the peel plate may be pivoted at various angles relating to the product by loosening the peel plate mounting bar. (The peel plate of all other models is mounted at a fixed angle and cannot be adjusted)
- To advance label flag on peel plate, move the slot sensor towards the peel plate. To decrease label flag, move slot sensor away from the peel plate.
- Position guide collars on idler roll, one slightly above and the other slightly below the web.

MAINTENANCE:

- Clean all the parts that may acquire labels or glue residue.

TROUBLESHOOTING:

PROBLEM


- Too much label flag at peel plate
- Too little label flag at peel-
- Web moving up and down peel plate

WHAT TO DO


- Move slot sensor away from peel edge
- Move slot sensor towards peel plate edge
- Make sure guide collars are properly positioned on idler roll.







ITEM	QTY	PART NO.	DESCRIPTION
1	6	181063-000	BEARING, ROLL END
2	4	361198-000	COLLAR, GUIDE, 1 IN. ID
3	2	A22065-000	PEEL PLATE MOUNTING PLATE
4	2	A22066-000	WASHER
5	1	A22094-013	PEEL PLATE ROD MTG BAR
6	3	A22102-013	P.P. IDLER SHAFT
7	1	A24534-013	PEEL PLATE MOUNTING BAR, 10"
8	3	B20740-013	IDLER ROLLER-(PEEL PLATE)
9	1	B21629-013	PEEL PLATE, 10"




A	5-20-10	NEW DRAWING
REV	DATE	DESCRIPTION

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY		
<div>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .015 ANGLES ± 30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030</div>	<div><div>QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700</div></div>	SCALE: 1/2
	DATE: 5-20-10	
	DRW BY: DC	
	CHK BY:	
	APPR BY:	
13" PIVOTING PEEL PLATE ASSEMBLY		
MAT'L	21720-013	D23341-000



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY		
QUADREL LABELING SYSTEMS		
7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700		
13" PIVOTING PEEL PLATE ASSEMBLY		
MAT'L 21720-013		
D23341-000		
SCALE: 1/2		
DATE: 5-20-10		
DRW BY: DC		
CHK BY:		
APPR BY:		
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		
XX ± .1		
XXX ± .01		
XXX ± .005		
ANGLES ± 30°		
SURFACE FINISH .125		
BREAK ALL EDGES .005/.015		
CORNER RADIUS .010/.030		
A 5-20-10 NEW DRAWING		
REV DATE DESCRIPTION		





ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	801857-000	ADJUSTABLE HANDLE	22919-000
2	1	A28459-000		22919-000
3	1	A28460-000	V-BLOCK SUPPORT	22919-000
4	1	A28460-001	V-BLOCK SUPPORT	22919-000
5	1	A28460-002	V-BLOCK SUPPORT	22919-000
6	1	A28460-003	V-BLOCK SUPPORT	22919-000



A	Nov-04-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
QUADREL LABELING SYSTEMS		SCALE: 2/1	
7670 JENTHER DRIVE		DATE: Nov-04-25	
MENTOR, OHIO 44060		DRW BY: TAZ	
(440) 602-4700		CHK BY:	
		APPR BY:	
PEEL PLATE SUPPORT			
MAT'L		22919-000	22919-000

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE
XX ± .01
XXX ± .005
ANGLES ± .00°
SURFACE FINISH 125
BREAK ALL EDGES .005/ .015
CORNER RADIUS .010/ .030
ALL ANGLES ARE 90°





THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/1	
X ± .1		DATE: Nov-04-25	
XX ± .01		DRW BY: TAZ	
XXX ± .005		CHK BY:	
ANGLES ± .00°		APPR BY:	
SURFACE FINISH 125		PEEL PLATE SUPPORT	
BREAK ALL EDGES .005/ .015		MATERIAL	
CORNER RADIUS .010/ .030		22919-000	
ALL ANGLES ARE 90°		22919-000	

ASSEMBLY TITLE: FIXED BRUSH IMPRESSER

DRAWING NO.: D21651-000

GENERAL FUNCTION:

- The fixed roller impresser is an option used in applications where a secondary wipe down or label wipe is necessary.

SET UP AND ADJUSTMENTS:

- When installed, the brush assembly will be mounted by an adjustable clamp. The mounting assembly is fastener to the option rail located on the peel plate side wall.
- Four axis of adjustment is available by loosening the set screw locking the roller arm in place.
- Locate the brush as necessary and re-tighten the clamping screws.
- Run a product through the brush area and insure the brush layed on the product but do not impede product travel. The brush can be adjusted too close to the product which will prevent the product from smoothly traversing through the brush area.

MAINTENANCE:

- Keep the brush free of label flash, glue and debris. This will prevent jamming and web tears.

NOTE: Exercise caution when removing bad labels from brush. Careless removal can result in brisals being pull out which may leave the labeler inoperable until the brush is replaced!


TROUBLESHOOTING:

PROBLEM

- Product jams at brush area
- Bubbles in label
- Label edge curling
- Wipedown inadequate

WHAT TO DO



- Increase brush spacing.
- Decrease labeling speed
- Decrease product delay
- Decrease brush spacing.




ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	362186-000	COLLAR, 3/8 IN. ID ONE-PIECE CLAMP	10228-011
2	1	801868-000	CLAMPING LEVER	10228-011
3	1	A21264-018	CROSS ARM	10228-011
4	1	A21693-301	IMPRESSOR MOUNTING BLOCK	10228-011
5	3	A23463-100	BRUSH HOLDER	10228-011

A	May-08-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
<div>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .00° SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°</div>		SCALE: 19/32	
		DATE: May-08-25	
		DRW BY: TAZ	
		CHK BY:	
<div>QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700</div>		12" SQUEEGEE IMPRESSOR	
		MAT'L 10228-011	10228-011



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY		
<div> <div> UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE $\begin{matrix} X \pm .1 \\ XX \pm .005 \\ XXX \pm .001 \\ ANGLES \pm .90 \end{matrix}$ </div> <div>  </div> <div> 7670 JENTER DRIVE MENTOR, OHIO 44060 (440) 602-4700 </div> </div>		
QUADREL LABELING SYSTEMS		SCALE: 1/32 DATE: May-08-25 DRW BY: TAZ CHK BY: APPR BY:
12" SQUEEGEE IMPRESSOR		
MAT'L	10228-011	10228-011

SHEET 2 OF 2

ASSEMBLY TITLE:**Q120 DRIVE AND PINCH ROLL ASSEMBLY****GENERAL FUNCTION:**

- The drive roll pulls the liner through the entire labeling head. As the liner is pulled over the peel edge, the label dispenses.
- The spring-loaded pinch roll squeezes the liner against the drive roll to provide positive drive.
- The primary roll is the pull or drive roll as shown. The knurl roll provides a constant pressure against the pull roll.

SET UP AND ADJUSTMENTS:

- When threading the labeling head, use the pinch roll lever to release the pinch roll from the drive roll.
- Use the spring plunger adjustment screws to adjust the contact pressure between the knurl and pull rollers.
- The pressure should be adjusted as tight as necessary to prevent a loose liner, while still allowing full rotation of the pressure release arm.

MAINTENANCE:

- Clean all parts that may have acquired label or glue residue


TROUBLESHOOTING:**PROBLEM**

- Meter pulley rubbing against side plate
- Web slips
- Drive roll not rotating when stepping motor rotates
- Pinch roll not providing enough pressure against drive roll
- Drive roll unevenly worn causing tracking problem

WHAT TO DO

- Center pulley on motor shaft and tighten two (2) set screws in pulley.
- Drive roller not closed. Turn drive roll arm to closed position.
- Replace timing belt from motor to drive roll
- Replace pinch roll spring
- Increase tension on drive roll by adjusting spring loaded locking pins.
- Replace drive roll










ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	00301-17	SPRING, .275 x .052 x .94	22620D-LHH-12
2	2	111052-000	BEARING	22620D-LHH-12
3	2	111072-000	BEARING, BALL	22620D-LHH-12
4	3	151004-000	BEARING, THRUST WASHER	22620D-LHH-12
5	1	362161-000	COLLAR, SETSCREW, 1/2 IN. ID	22620D-LHH-12
6	2	A20567-000	WHITE NYLON SLUG	22620D-LHH-12
7	1	A20929-012	PINCH POINT GUARD ROD 12" WEB	22620D-LHH-12
8	1	A23751-000	SPACER	22620D-LHH-12
9	2	A23752-000	SPACER	22620D-LHH-12
10	1	A25249-000	INDEX DOT	22620D-LHH-12
11	1	A25250-000	IND KNOB	22620D-LHH-12
12	1	B20126-002	KNURLED ROLL	22620D-LHH-12
13	1	B20342-012	PULL ROLL, 10"	22620D-LHH-12
14	1	B20346-014	KNURLED ROLL SHAFT, 12"	22620D-LHH-12
15	1	B21614-000	YOKE OUTSIDE PLATE	22620D-LHH-12
16	1	B21615-000	YOKE INSIDE PLATE	22620D-LHH-12
17	1	B21616-113	YOKE FILLER BAR	22620D-LHH-12



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 5/8	
X ± .1 XX ± .01 XXX ± .005 ANGLES ± .00°		DATE: Mar-07-25	
SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		DRW BY: TAZ	
		CHK BY: 03/25/2025-SEM	
		APPR BY:	
		12" DRIVE ROLL ASSEMBLY	
		MAT'L	
		22620D-LHH-12	



A	Mar-07-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
<div>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .00° SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°</div>		SCALE: 3/4	
		DATE: Mar-07-25	
		DRW BY: TAZ	
		CHK BY:03/25/2025-SEM	
		APPR BY:	
		QUADREL LABELING SYSTEMS	
		7670 JENTHER DRIVE	
		MENTOR, OHIO 44060	
		(440) 602-4700	
		12" DRIVE ROLL ASSEMBLY	
MAT'L		22620D-LHH-12	22620D-LHH-12



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	111044-000	BEARING, 3/4 ID CLAMP TYPE	22620DR-07R
2	2	111072-100	BEARING BALL, LOCKING COLLAR .5"IDx1.574"OD	22620DR-07R
3	2	111075-000	BEARING, BALL	22620DR-07R
4	2	151008-000	BEARING, THRUST WASHER	22620DR-07R
5	1	191592-000	BELT, TIMING, 1/2P	22620DR-07R
6	1	192503-150	TIMING BELT	22620DR-07R
7	1	363159-002	SERVO COUPLING-1/2"BORE & KEY 1/2"x1/2" BORE	22620DR-07R
8	1	412088-000	SERVO MOTOR	22620DR-07R
9	1	A20595-120	COLLAR REWORK	22620DR-07R
10	1	A21421-001	DRIVE PULLEY (MODIFIED)	22620DR-07R
11	1	A26003-100	DRIVE PULLEY	22620DR-07R
12	1	A26004-120	SERVO MOTOR PULLEY	22620DR-07R
13	1	B22842-100	BEARING PLATE	22620DR-07R
14	1	B22842-101	BEARING PLATE	22620DR-07R
15	2	B22844-100	SPACER	22620DR-07R
16	1	B22844-220	SPACER	22620DR-07R
17	1	B22844-320	SPACER	22620DR-07R
18	1	B22847-200	MOTOR MOUNTING PLATE	22620DR-07R
19	1	B22848-120	TENSION ROLLER	22620DR-07R
20	1	B22849-120	TENSIONER SHAFT	22620DR-07R
21	2	B22850-100	COVER	22620DR-07R
22	1	B22850-120	COVER	22620DR-07R
23	1	B22850-122	COVER	22620DR-07R
24	1	C20097-121	PULL ROLL DRIVE SHAFT	22620DR-07R



⚠ WARNING





Avoid injury.
Do not operate with
guard removed.
Replace guard before
operating machine.



⚠ WARNING

**Keep hands
clear.**
Moving parts.

		B	09/22/25	REVISED: #7 363159-002	SEM
		A	Aug-05-25	NEW DRAWING	TAZ
		REV	DATE	DESCRIPTION	BY
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		QUADREL LABELING SYSTEMS			SCALE: 5/16
X ± .01 XX ± .01 XXX ± .005 ANGLES ± 30°		7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700			DATE: Aug-05-25 DRW BY: TAZ CHK BY: APPR BY:
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030 ALL ANGLES ARE 90°		Q125 12" SERVO DRIVE			
MAT'L		22620DR-07R			22620DR-07R



B	09/22/25	REVISED #7	SEM
A	Aug-05-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

<div>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE $X \pm .1$ $XX \pm .01$ $XXX \pm .005$ ANGLES $\pm .30^\circ$ SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°</div>	<div>QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700</div>	SCALE: 5/16	
		DATE: Aug-05-25	
		DRW BY: TAZ	
		CHK BY:	
		Q125 12" SERVO DRIVE	
		APPR BY:	
MAT'L	22620DR-07R	22620DR-07R	

Servo Belt Removal & Installation

Remove the clear cover on the side of the coupling of the servo motor. Then loosen the 4 5/16-18 socket heads holding the motor mounting plate to the spacer blocks. (Shown in image on the right)



Loosen the 2 bolts on the coupling. Then remove the motor and coupling assembly. (Shown in image on the left)


Loosen the tension on the servo belt by removing loosening the 2 jam nuts on the set screws shown and removing the set screws. (Shown in image on the right)





Loosen set screw in the collar on the end of the drive shaft. Then remove the collar. (Shown in image on the left)

Remove the 4 5/16-18 socket head bolts that hold the bottom plate to the spacer blocks. Then remove the two button head screws holding the lexan cover on and remove cover. (Shown in image on the right)



Remove the set screw on the eccentric collar then spin the collar to loosen from shaft. (Shown in image on the left)

Once the bolts are removed, remove the bottom plate. This may take some prying and finessing, be careful to not bend the plate, shafts, or ruin the bearings during the removal of the plate. Once removed clean the plate and bearings. (Shown in image on the right & bottom)



If Equipped

Remove the cover over the rewind kinetrol and other side of the servo belt. (Shown in image on the left)

Remove the tensioner, belt and smaller diameter shaft with the pulley teeth on it. (Shown in image on the right)



Once removed clean all surfaces shafts bearing and check the rewind belt for cracks or uneven wear. You can use a scotch brite pad the clean up the shafts and ect. (Shown in image on the left)

Check the lock collar on the shaft with the pulley grooves ensure the collar is tight and the stack up is correct. The washer goes on top of the collar and shall be flush with the end of the pulley grooves as shown in the image below. Slide the collar over the end of the shaft as shown. This stack up is extremely important.



Ensure your belt is riding properly on the kinetrol pulley. The belt should be running in the middle of the pulley of as close to centered as you can get. Spin the kinetrol and ensure the belt is tracking well. (Shown below)



To adjust this rotate the pulley until you see the set screw. Loosen the set screws and slide the pulley accordingly. Slide the larger pulley down or up as well these pulleys should be together. (Shown in image on the right)




After you have cleaned everything up, checked the rewind belt and properly checked alignment of the pulleys. It is now time to re-assemble. Start by putting the belt in then the tensioner. Ensure the idler has the oil lite washers installed on the top and bottom of the idler. (Shown in the image to the left)

NOTE Blue Loctite is recommended on all fasters.


Place the eccentric collar over the smaller diameter shaft and slide the bottom servo plate on. Ensure the tensioner is positioned properly in the slot on the bottom plate with the oil lite washer in place. Fasten the plate to the spacer blocks. Once fastened rotate the eccentric collar to lock it into place make sure it is tight this is very important. Lock into place with set screw. (Shown in image below)


NOTE Blue Loctite is recommended on all fasteners.



Thread in the set screws evenly to set tension on the belt the belt should not be too tight if you reach around the back you can push against the belt as you tighten it. This is more of a touch setting you do not want the belt to be solid to the touch more like 1/8th - 1/4th inch of travel when you push on the belt. If it is too loose it can skip teeth. When the tension is set lock into place using the jam nuts. (Shown in image below)

NOTE Do NOT loctite set screws for the tensioner.





Fasten the collar to the end of the larger diameter shaft as shown.

NOTE Blue Loctite is recommended on all fasteners.



Place the lexan covers on the 2 sides of the servo belt assembly and the cover over the rewind kinetrol assembly. Make sure the fasteners has blue Loctite and rubber grommets. (Shown in image on the left)

Place the servo motor coupling over the end of the smaller diameter shaft. Fasten the motor mounting assembly to the bottom plate using blue Loctite. Align the coupling centered between the shafts so the coupling has enough to fasten to on each of the shafts. Fasten the coupling to the shafts. Mount the lexan covers make sure the fasteners has blue Loctite and rubber grommets. (Shown in image on the right)

NOTE Blue Loctite is recommended on all fasteners.



ASSEMBLY TITLE:**Q120 REWIND ASSEMBLY****GENERAL FUNCTION:**

- The rewind drum rolls up the liner
- The rewind pin, when pulled out, allows the liner to be released from the rewind drum.
- The rewind flange supports and guides the liner.
- The friction clutch allows for slippage to accommodate for varying speeds between the drive roll and rewind drum.
- The adjusting knob controls the torque adjustment of the drum.

SET UP AND ADJUSTMENTS:

- Position the rewind flange slightly below the web path and lock with the set screw in the hub.
- When threading liner to the rewind, place the liner between the drum and pin.
- Tighten adjusting knob just enough to allow the rewind drum to keep up with the drive roll.

NOTE: Excessive tightening will cause the web to be wound very tight, causing difficulty in removal and possible step motor stall.

MAINTENANCE:

- Clean all parts that have acquired label or glue residue
- Replace friction disc when worn out.


TROUBLESHOOTING:**PROBLEM**

- Rewind drum not rotating when stepping motor rotates
- Rewind drum not keeping up with drive roll
- Web winding too tight on hub
- Grinding in rewind hub

WHAT TO DO

- Replace timing belt from motor to rewind
- Tighten adjusting knob
- Loosen adjusting knob
- Replace friction disc by removing knob and sliding off rewind drum








ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	20499-001	DASHPOT & SHAFT ASSEMBLY	22620R-LH-12
2	1	22189-113	COLLAPSIBLE REWIND	22620R-LH-12
3	3	111075-000	BEARING, BALL	22620R-LH-12
4	1	121067-000	BEARING, NEEDLE	22620R-LH-12
5	1	151008-000	BEARING, THRUST WASHER	22620R-LH-12
6	1	151017-000	BEARING, THRUST WASHER	22620R-LH-12
7	4	181063-000	BEARING, ROLL END	22620R-LH-12
8	1	181081-000	BEARING, NEEDLE ROLLER	22620R-LH-12
9	2	181082-000	BEARING, THRUST WASHER	22620R-LH-12
10	1	801601-000	CHECK NUT	22620R-LH-12
11	1	811216-000	EXTENSION SPRING, STAINLESS	22620R-LH-12
12	2	A20931-113	IDLER ROLLER TUBE 12"	22620R-LH-12
13	2	A20932-113	DANCER ROLL SHAFT 12"	22620R-LH-12
14	1	A21479-000	SPRING ADJUSTMENT BLOCK	22620R-LH-12
15	1	A22120-000	REWIND PULLEY ASSEMBLY	22620R-LH-12
16	1	A23009-001	DANCER ARM ROLLER SUPPORT	22620R-LH-12
17	1	A23131-000	STUD	22620R-LH-12
18	1	B20004-120	REWIND BEARING PLATE	22620R-LH-12
19	1	B20005-120	GUARD	22620R-LH-12
20	1	C20894-004	REWIND DANCER ARM	22620R-LH-12




A		Mar-21-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY				
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 5/16		
XX ± .01		DATE: Mar-21-25		
XXX ± .005		DRW BY: TAZ		
ANGLES ± 30°		CHK BY: 03/25/2025-SEM		
SURFACE FINISH 125		APPR BY:		
BREAK ALL EDGES .005/0.15		Q120 REWIND & DANCER ASSEMBLY w/KINETROL, 12"		
CORNER RADIUS .010/0.50		MAT'L		
		22620R-LH-12		



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/2"	
X ± .1 XX ± .01 XXX ± .005 ANGLES ± .50°		DATE: Mar-21-25	
SURFACE FINISH: 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		DRW BY: TAZ	
		CHK BY: 03/25/2025-SEM	
		APPR BY:	
		Q120 REWIND & DANCER ASSEMBLY w/KINETROL, 12"	
		MATERIAL	
		22620R-LH-12	

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	22597-000	COLLAPSIBLE REWIND LOCKING HANDLE	22189-113
2	1	841145-000	1/4 X 1/2 LG. SHOULDER BOLT	22189-113
3	1	A21226-000	REWIND FLANGE HUB COLLAR	22189-113
4	1	A22085-001	COLLAPSIBLE REWIND REEL	22189-113
5	1	B22103-113	10" COLLAPSIBLE REWIND DRUM	22189-113
6	1	B22141-013	SHAFT ASSEMBLY	22189-113
7	2	CSEE253	10-32 X 3/8 LG. FLAT HEAD	22189-113
8	1	SYE103	1/4-20 X 5/8 LG. SET SCREW	22189-113







	A	Jun-06-17	NEW DRAWING	CRT
	REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE	QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	SCALE 3/4"	Date Jun-06-17
X± .1		DRAWN BY CRT	
XX± .01			
XXX± .005			
ANGLES ± .3°			


COLLAPSIBLE REWIND

SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030	MAT'L	22189-113	22189-113
--	-------	-----------	-----------







A	Jun-06-17	NEW DRAWING	CRT
REV	DATE	DESCRIPTION	BY
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE 3/4	
X± .1		DATE	Jun-06-17
XX± .01		DRAWN BY	CRT
XXX± .005			
ANGLES ± .30°			
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030			
QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700			
COLLAPSIBLE REWIND			
MAT'L		22189-113	22189-113

ITEM	QTY	PART NO.	DESCRIPTION
1	1	871352-000	DOWELL,PIN 1/8" x 1/2" SS.
2	1	A26128-000	CLEVIS
3	1	A26129-000	HANDLE
4	1	SYE601	1/4-20 X 1-1/4 LG. SET SCREW



		A		12-11-14	
				NEW DRAWING	
		REV		DATE	
				DESCRIPTION	
				BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X± .1 XX± .01 XXX± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/015 CORNER RADIUS .010/030	QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700			SCALE	4/1
				DATE	12-11-14
				DRAWN BY	ATT
COLLAPSIBLE REWIND LOCKING HANDLE					
MAT'L		22597-000		22597-000	



A	12-11-14	NEW DRAWING		
REV	DATE	DESCRIPTION		BY
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY				
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X± .1 XX± .01 XXX± .005 ANGLES ± .30°	QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700		SCALE	4/1
			DATE	12-11-14
			DRAWN BY	ATT
COLLAPSIBLE REWIND LOCKING HANDLE				
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		MAT'L	22597-000	22597-000

ASSEMBLY TITLE: Q60 KINETROL REWIND

GENERAL FUNCTION:

- The rewind drum rolls up the liner
- The collapsible rewind shaft when closed allows the liner to be removed easily. The normal running position for the shaft is in the open position
- The rewind flange supports and guides the liner
- The Kinetrol clutch allows for slippage to accommodate for varying speeds between the drive roll and rewind drum
- The adjusting knob controls the torque adjustment of the drum and is set at the factory.

SET UP AND ADJUSTMENTS:

- Position the rewind flange slightly below the web path and lock with the set screw in the hub
- When threading liner to the rewind, place the liner between the drum and pin
- Tighten adjusting knob just enough to allow the rewind drum to keep up with the drive roll.
- Loosen set screw before adjustment and re-tighten after adjustment

NOTE: Excessive tightening will cause the web to be wound very tight, causing difficulty in removal and possible step motor stall.

MAINTENANCE:

- Clean all parts that have acquired label or glue residue

TROUBLESHOOTING:

PROBLEM

- Rewind drum not rotating when stepping motor rotates
- Rewind drum not keeping up with drive roll
- Web winding too tight on hub
- Grinding in rewind hub

WHAT TO DO

- Replace timing belt from motor to rewind
- Adjust clutch dial (1 being loosest & 10 being tightest)
- Loosen adjusting knob
- Replace Kinetrol

Set screw location



ASSEMBLY TITLE: SLOT SENSOR ASSEMBLY

GENERAL FUNCTION:

- The slot sensor detects the separation between labels. This signals the electronics to stop the drive motor.
- The two (2) liner support rods prevent the liner from wearing out the slot sensor.
- The knob and thumbscrew lock the sensor firmly on the mounting rods.
- The male connector provides quick connection to the labeling head.

SET UP AND ADJUSTMENTS:

- See attached cut sheet


MAINTENANCE:

- Keep the sensor optical area clean from label and glue residue

TROUBLESHOOTING:





<u>PROBLEM</u>	<u>WHAT TO DO</u>
- No power to the sensor	- Check male connector and tightly secure connection to the head.
- Liner dragging over the slot	- Loosen knob and rotate slot sensor slot sensor surface liner rests on both support rods
- Too much slack through slot sensor	- Adjust brake brush tension
- Slot sensor moving with web	- Tighten all three (3) adjusting knobs

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	201444-300	TRITRONICS MODEL LERC	20033-344
2	2	801297-000	THUMB SCREW PLSTC HEAD 8-32x1	20033-344
3	2	801299-000	KNOB W/STUD, 1/4-20 UNC X 1/2" LG	20033-344
4	1	A21391-301	SLOT SENSOR ADAPTER	20033-344
5	4	A21749-300	SLOT SENSOR SUPPORT ROD MTG BLOCK	20033-344
6	2	A21770-343	14.7" SUPPORT ROD WITH FLAT	20033-344
7	1	B20852-343	12 IN. WEB SLOT SENSOR MTG. BAR	20033-344



A	Mar-25-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY


THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .00°		SCALE: 1/1 DATE: Mar-25-25 DRW BY: TAZ CHK BY: 03/25/2025-SEM APPR BY:	
SURFACE FINISH: 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		12" STD LABEL DETECT ASSEMBLY	
MATERIAL		20033-344	20033-344



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/1	
XX ± .01		DATE: Mar-25-25	
XXX ± .005		DRW BY: TAZ	
ANGLES ± .00°		CHK BY: 03/25/2025-SEM	
SURFACE FINISH 125		APPR BY:	
BREAK ALL EDGES .005/ .015		12" STD LABEL DETECT ASSEMBLY	
CORNER RADIUS .010/ .030		MAT'L 20033-344	
ALL ANGLES ARE 90°		20033-344	

A	Mar-25-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

QUADREL LABELING SYSTEMS	
7670 JENTHER DRIVE	
MENTOR, OHIO 44060	
(440) 602-4700	



LABEL•EYE

Set-Up Instructions

Standard LABEL•EYE

Normal Label Opacity AUTOSET Button

This category includes most paper or metallized film labels adhering to paper or transparent backing materials. To implement the one button AUTOSET routine, utilize the external alignment guides to position the gap between labels in line with the dot shown in the center of the detection zone. Then push the AUTOSET button marked "Normal."

An alternative set up procedure would be to remove a label and the push the "Normal" AUTOSET button.


On rare occasions, when the light is unable to penetrate the backing materials, both the red and green led indicators will blink four times. When this indication occurs, the sensor will be unable to detect the presence of the labels.

Translucent Label Opacity AUTOSET Button

This category includes translucent labels adhering to transparent or paper backing materials. To implement the one button AUTOSET routine, utilize the external alignment guides to position the gap between labels in line with the dot shown in the center of the detection zone. Then push the AUTOSET button marked "Translucent".

Note: This sensor cannot detect transparent labels.

INVERT OUTPUT: The status of the red LED and output transistors can be inverted by pressing both buttons simultaneously. When the output status has been inverted, the red LED and the output transistors will turn off when the label comes into view.



SPECIFICATIONS



SUPPLY VOLTAGE

- 10 to 30Vdc
- Polarity Protected
- Intended for use in class two circuits

CURRENT REQUIREMENTS

- 45 milliamps (exclusive of load)

OUTPUT TRANSISTORS

- (1) NPN and (1) PNP output transistors
- Sensor outputs can sink or source up to 150 milliamps (current limit)
- All outputs are continuously short circuit protected

REMOTE AUTOSET INPUT

- opto isolated momentary sinking input (10 milliamps)
- Note: Remote models only*

RESPONSE TIME

- Light state response = 100 microseconds
- Dark state response = 100 microseconds

LED LIGHT SOURCE

- High intensity red LED
- Pulse modulated

PUSH BUTTON CONTROL

- Automatic set-up routines based on web opacity
- One push button set-up
- Simultaneously pushing both buttons inverts the output

HYSTERESIS

- Minimal hysteresis promotes the detection between the backing material and the label depending on the settings

LIGHT IMMUNITY

- Responds to sensor's pulsed modulated light source ... immune to most ambient light

INDICATORS

- Green LED flashes when AUTOSET routine is activated and stays illuminated when AUTOSET is completed
 - Red LED illuminates when sensors output transistors are ON.
- Note: The status of the output transistors can be inverted by pushing both buttons simultaneously. If Output LED flashes, a short circuit condition exists.*

AMBIENT TEMPERATURE

- -40°C to 70°C (-40°F to 158°F)

RUGGED CONSTRUCTION

- Chemical resistance to harsh cleaners such as detergents, alcohols, and ketones
- Type 1 Enclosure
- Conforms to heavy industry grade CE and UL requirements



RoHS Compliant
Product subject to change without notice.


Model Numbers:

Label•Eye	Description
LER	Red LED, 4 Conductor 6ft Cable
LERC	Red LED, 4-pin M8 Connector
LERR	Red LED, 5 Conductor, 6ft Cable
LERRC-M12	Red LED, 5-Pin M12 Pigtail Connector
LERC-M12	Red LED, 4-Pin M12 Pigtail Connector

Nano Cable (M8) Selection Guide

P/N	Length	Thread Coupling
GEC-6	6ft (1.8m)	Straight Female
GEC-15	15ft (4.6m)	Straight Female
RGEC-6	6ft (1.8m)	90° Female
RGEC-15	15ft (4.6m)	90° Female

DIMENSIONS



P.O. BOX 25135, TAMPA, FL 33622-5135
 813-886-4000 / 800-237-0946
 ttc.com / info@ttco.com

070-0150 Rev 5

ASSEMBLY TITLE: LOW LABEL FAULT ASSEMBLY

DRAWING NO.:

GENERAL FUNCTION:

- The low label supply fault indicates a depleting supply of labels. It consists of a fiber optic sensor that is set at the desired position on the roll of labels.
- When the label supply passes below the sensor range, a signal is generated this will light the yellow stack lamp and enunciate a low label condition on the operator's touch screen display.
- The male connector provides quick connection to the labeling head.

SET UP AND ADJUSTMENTS:

- Set the sensor eye just before the cardboard inner core, approximately $\frac{1}{4}$ " below the supply reel flange and lined up with the sensing hole in the flange.

MAINTENANCE:


- Keep the sensor optical area clean from label and glue residue

TROUBLESHOOTING:

<u>PROBLEM</u>	<u>WHAT TO DO</u>
- No power to the sensor	- Check male connector and tightly secure connection to the head.

NOTE: The labeler will continue to operate until the operator pauses the labeler or the label supply completely depletes past the broken web sensor.








To reset the fault condition, replenish the label supply and press the labeler run button from run to pause and back to run.



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	202201-000	DUAL DIGITAL FIBER AMPLIFIER	20776-006
2	1	202201-001	DUAL DIGITAL FIBER AMPLIFIER	20776-006
3	1	203170-000	CABLE,FIBER , REFLECTIVE, KEYENCE #FU-67V	20776-006
4	1	A23727-000	LOW LEVEL BRACKET	20776-006
5	1	A23728-000	LOW LEVEL SENSOR TUBE	20776-006

*NOT SHOWN
252019-000 CONNECTOR


A		Apr-07-21		NEW DRAWING	
REV		DATE		DESCRIPTION	
				BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .01 XXX ± .005 ANGLES ± 30° SURFACE FINISH .125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700		SCALE	
				DATE	
				DRAWN BY	
		LOW LABEL			
MAT'L		20776-006 & 20776-006P		20776-006	



A		Apr-07-21	NEW DRAWING		TJS
REV		DATE	DESCRIPTION		BY
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± 30°		QUADREL LABELING SYSTEMS		SCALE 1/1	
		7670 JENTHER DRIVE		DATE Apr-07-21	
		MENTOR, OHIO 44060		DRAWN BY TJS	
		(440) 602-4700			
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		LOW LABEL			
MAT'L		20776-006 & 20776-006P		20776-006	



Digital Fiberoptic Sensor FS-N40 Series Instruction Manual



Read this manual before using the product in order to achieve maximum performance. Keep this manual in a safe place after reading it so that it can be used at any time.

For detailed FS-N40 Series setting methods and for details on the functions of the FS-N40 Series, see the "FS-N40 Series User's Manual".

■ Symbols

The following symbols are used in this instruction manual to enable the recognition of important information at a glance. Be sure to read these messages carefully.

	It indicates a hazardous situation which, if not avoided, will result in death or serious injury.
	It indicates a hazardous situation which, if not avoided, could result in death or serious injury.
	It indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
	It indicates a situation which, if not avoided, could result in product damage as well as property damage.

1 Before Operation

Safety Precautions

	<ul style="list-style-type: none"> This product is only intended to detect objects. Do not use this product for the purpose of protecting a human body or a part of a human body. This product is not intended for use as an explosion-proof product. Do not use this product in a hazardous location and/or potentially explosive atmosphere.
	<ul style="list-style-type: none"> This is a direct current (DC) power supply type sensor. Application of an alternating current may result in explosion or fire.
	<ul style="list-style-type: none"> Use separate conduits for power lines and high-voltage lines. Use of a common conduit may result in device malfunction due to noise or damage to the sensor. Always ground the frame ground terminal when using an off-the-shelf switching regulator. Do not use this product outdoors.

Precautions on Regulations and Standards

■ CE Marking

KEYENCE Corporation has confirmed, on the basis of the following specifications, that this product complies with the essential requirements of the applicable EU Directive(s). Be sure to consider the following specifications when using this product in the member states of the European Union.

● EMC Directive, applicable standard: EN60947-5-2, Class A

Ensure that the cable length is 30 meters or less. These specifications do not give any guarantee that the end-product with this product incorporated complies with the essential requirements of the EMC Directive. The manufacturer of the end-product is solely responsible for confirming the compliance of the end-product itself according to the EMC Directive.

■ UL Certificate

This product is a UL/c-UL certified product.

- UL File No.: E301717
- Category: NRKH/NRKH7(NRKH2/NRKH8: FS-N42N(P))
- Enclosure Type 1 (based on UL50)

Be sure to consider the following specifications when using this product as a UL/c-UL certified product.

- Use a power supply with Class 2 output defined in NFPA70 (NEC: National Electrical Code).
- Connect the power supply, external input, and control output to a single power supply with Class 2 output.
- Use OP-73864, OP-73865 or OP-85498 cable with FS-N41C when the field wiring is required.

■ FCC Regulations

This product complies with the following regulations specified by the FCC.

- Applicable regulation FCC Part 15 Subpart B Class A
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

• FCC Caution

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Package Contents


- Main unit
- Instruction manual

2 Installation and Wiring

Mounting the Main Unit


■ Mounting the Main Unit on a DIN rail

- Align the claw at the bottom of the main unit with the DIN rail, as shown in the figure. While pushing the main body in the direction of arrow 1, push down in the direction of arrow 2.
- To remove the sensor, raise the main body in the direction of arrow 3 while pushing the main body in the direction of arrow 1.



■ Installation on a wall (main unit only)

- Attach the main unit to the optional mounting adapter (OP-88245), and then insert M3 screws into the two locations shown in the figure to secure the main unit in place.




Connecting Multiple Amplifiers


Up to 16 expansion units can be connected to 1 main unit. However, each dual output type will be treated as 2 expansion units.

	When connecting to multiple amplifiers or when mounting main units together, mount the units on a DIN rail installed on a metal surface.
	<ul style="list-style-type: none"> Be sure to turn the power off before connecting multiple expansion units. Do not touch the expansion connector.


- Remove the protection covers from the main unit and expansion unit(s).




- Install the amplifiers on the DIN rail one at a time.



- Slide the main unit and expansion unit(s) together. Mate the two claws of the expansion unit with the recesses on the main unit side until a click is heard/felt.



- Attach the end units (optional, sold separately: OP-26751) to the DIN rail on both sides of the amplifiers in the same way as step (2).




- Secure the amplifiers between the end units. Tighten the screws from the top (two screws x two units) with a Phillips screwdriver to fix the end units in place.

OP-26751 (a set of two)

Fiber Unit Installation

■ Using a fiber cutter


- Insert the fiber into the cutter hole.
- Bring down the blade in a single, swift motion to cut the fiber. (Do not use a hole that has already been used.)




Always insert fiber from the side with writing

■ Connecting to the amplifier unit

- Open the cover (1), and then lower the lever in the direction indicated by (2).
- Insert the fiber unit into the installation holes (approximately 14 mm). (3)
- Move the lever back in the direction indicated by (4).




	When installing a coaxial reflective fiber in the main unit, install the single-core fiber in the transmission installation hole and the multi-core fiber in the reception installation hole.
--	---




Wiring (Cable Type)

● FS-N41N/N42N/N43N/N44N



- *1 FS-N41N/N43N only
- *2 FS-N43N/N44N only

● FS-N41P/N42P/N43P/N44P



- *1 FS-N41P/N43P only
- *2 FS-N43P/N44P only

Wiring (M8 Connector Type: FS-N41C)

Select NPN or PNP and the function of I/O pin (2) during the initial settings.


Sensor pin layout




FS-N41C supports "IO-Link: Specification V.1.1/COM2 (38.4 kbps)".
The setting file (IODD) can be downloaded from Keyence's web site
(<http://www.keyence.com>).

When using the sensor in PNP mode

OUT1 + OUT2




OUT1 + INPUT




When using the sensor in NPN mode

OUT1 + OUT2




OUT1 + INPUT



The wire colors indicate the colors when using an OP-73864/73865 M8 connector cable (sold separately).

3 Basic Settings


Names and functions



- *1 On dual output types (including the FS-N41C), the indicator operates according to the output channel selected with the output channel selection switch.
- *2 On dual output types (including the FS-N41C), this becomes the output indicator. It displays the current output status of channels 1 and 2.
- *3 On dual output types (including the FS-N41C), this becomes the output channel selection switch. It is not present on zero line types (FS-N40).

Initial settings (FS-N41C only)

When turning on the sensor for the first time, or when the sensor has been initialized, select the initial settings shown below.



Basic settings

Switching the output style (Light ON/Dark ON)


- 1 Press **[M]** once. Switch L-On/D-On
- 2 Use **[←]** **[→]** to switch the output style.
- 3 Press **[M]** three times.

Switching the display language

- 1 Press **[M]** twice. Language / 语言
- 2 Use **[←]** **[→]** to select the language.
- 3 Press **[M]** twice.

Fine-tuning the setting value (threshold)

Use **[←]** **[→]** to adjust the value. Hold down the button to make adjustments more quickly.




Basic calibration methods

2-point calibration (the most basic setting method)

- 1 Press **[SET]** with no object to detect present.




- 2 Press **[SET]** with an object to detect present.



This sets the setting value to the midpoint between the received light intensities of points 1 and 2. If "----" blinks for 2 seconds on the display, the difference between the received light intensities is small, and detection may be unstable.

Maximum sensitivity calibration


Through model: With an object to detect present



Reflective model: With no object to detect present



- 1 With the items arranged as shown in the figures on the left, hold down **[SET]** for 3 seconds or more. When SET blinks, release this button.



The setting value is set slightly higher than the received light intensity when the setting was configured.

4 Useful Functions

● Initialization

Initialize all the settings and return the sensor to its factory default state.

- 1 Hold down and for 3 seconds or more.
- 2 Press once.
- 3 Press once.
- 4 Press once.

● Key lock

Disable button operations.

- 1 Hold down and for 3 seconds or more.

Cancel: Use the same procedure.



● Saturation avoidance function

Use this function when the received light intensity does not change from the maximum displayed value.

- 1 Press and simultaneously.

Cancel: Use the same procedure.




● Zero shift function

Use this function to change the received light intensity display to zero.

- 1 Press and simultaneously.

Cancel: Hold down and for 3 seconds or more.



● Active receiver (ACT-R)

This function makes the fiber unit's receiver blink in green.

Operation when the sensor is shipped from the factory

When the sensor output is ON, the fiber unit's receiver lights in green. (This is linked to the output.)

To change the normal lighting status of the receiver (change the settings)

- 1 Press three times.
- 2 Use to select the status from those shown below.
Output Link: The receiver will light when the output is ON.
Reversed Op: The receiver will light when the output is OFF.
Always On: The receiver will be lit always.
Disable: The receiver will be off always.
- 3 Press twice to return to the normal status.


To force the receiver to blink in green (pairing mode)

- 1 Press once.
- 2 Press .
- 3 The light-receiving side blinks in green.
- 4 Press four times to return to the normal status.

To make it easy to perform optical-axis alignment (optical-axis alignment assist mode)

- 1 Press twice.
- 2 Press to make the light-receiving side blink in green.
- 3 Move the tip of the fiber unit within the movable range.

The light-receiving side lights in green near the peak light intensity within the range in which the tip moved.
Align the optical axis within the middle of the range in which the light-receiving side lights.



- 4 When you finish the alignment, press three times.
The sensor returns to the normal status.

5 Specifications

The response times are listed on the following page.

Model	NPN output PNP output	FS-N41N FS-N41P	FS-N42N FS-N42P	FS-N43N FS-N43P	FS-N44N FS-N44P	FS-N41C ¹ (selectable output) FS-N44P	FS-N40
Cable/connecter	Cable Main unit/Expansion unit						MS connector ²
Number of control outputs	1	1	2	2	2	2 ³	None ⁴
Number of external inputs	-	-	1	1	1	1 ³	-
Light source LED	Transmitter side: Red, four-element LED (wavelength: 660 nm)						
Control output	Open-collector, 30 V or less 100 mA or less per output, 100 mA or less total for 2 outputs (when used as a solitary unit) 20 mA (when used as an expansion unit)						-
	Residual voltage NPN 1.4 V or less (output current: 10 mA or less) 2 V or less (output current: 10 to 100 mA) PNP 1.6 V or less (output current: 10 mA or less) 2.2 V or less (output current: 10 to 100 mA)						-
External input	Input time: 2 ms (ON)/20 ms (OFF) or longer ⁵						-
Unit expansion (excluding the FS-N41C)	Up to 16 units (17 units connected in total including the main unit). However, each two output type will be treated as two expansion units.						-
Protection circuit	Protection against reverse power connection, output overcurrent, output surge, and reverse output connection						-
Mutual interference prevention	S-HSPD/HSPD: 0 units, FINE: 4 units, TURBO/SUPER/ULTRA/MEGA/TERA: 8 units (The mutual interference prevention values are twice those shown here when Double is set.)						-
Power supply	Power supply voltage						10 to 30 VDC (including 10% ripple (P-P) or less), class 2 or LPS ⁶
	Power consumption ⁷	NPN FS-N40					
		During normal operation: 870 mW or less (34 mA or less at 24 V/62 mA or less at 12 V) ECO ON: 800 mW or less (31 mA or less at 24 V/56 mA or less at 12 V) ECO FULL: 710 mW or less (28 mA or less at 24 V/49 mA or less at 12 V)					
		One output type (FS-N41P/N42P) and FS-N41C During normal operation: 910 mW or less (36 mA or less at 24 V/65 mA or less at 12 V) ECO ON: 840 mW or less (33 mA or less at 24 V/60 mA or less at 12 V) ECO FULL: 750 mW or less (30 mA or less at 24 V/52 mA or less at 12 V)					
Power supply	Power consumption ⁷	PNP FS-N41C					
		Two output type (FS-N43P/N44P) During normal operation: 990 mW or less (39 mA or less at 24 V/72 mA or less at 12 V) ECO ON: 920 mW or less (38 mA or less at 24 V/66 mA or less at 12 V) ECO FULL: 830 mW or less (33 mA or less at 24 V/59 mA or less at 12 V)					
Ambient light	Incandescent lamp: 20,000 lx or less, sunlight: 30,000 lx or less						-
Ambient temperature	-20°C to +55°C (no freezing) ⁸						-
Vibration resistance	10 to 55 Hz; double amplitude 1.5 mm, 2 hours each for X, Y, and Z axes						-
Shock resistance	500 m/s ² ; 3 times each for X, Y, and Z axes						-
Case material	Main unit and cover: polycarbonate						-
Weight	Approx. 79 g	Approx. 48 g	Approx. 83 g	Approx. 73 g	Approx. 25 g	Approx. 23 g	-

¹ IO-Link Specification V1.1 MCOM2 (38.4 kbps) is supported.
² Ensure the cable length is 30 m or less for the MS connector type. In case of connecting with IO-Link, set it to 20 m or less.
³ Output 2 and the external input are selectable.
⁴ This counts as 1 output when connecting multiple units to the FS-MCBNP, NU Series.
⁵ The input time becomes 25 ms (ON)/25 ms (OFF) when external calibration input is selected.

⁶ When expanding the system to 9 or more units, use a power supply voltage of 12 V or higher.
⁷ The load current is excluded. The power consumption including the load when the maximum number of units are connected is 38 W max.
⁸ When expanded by 1 to 2 units: -20°C to +55°C. When expanded by 3 to 10 units: -20°C to +50°C. When expanded by 11 to 16 units: -20°C to +45°C. When using 2 outputs, 1 unit is counted as 2 units. Note that all the temperature prescriptions assume that the sensor has been mounted on a DIN rail installed on a metal surface. Exercise special care when installing the product in an airtight space.

WARRANTIES AND DISCLAIMERS

- (1) KEYENCE warrants the Products to be free of defects in materials and workmanship for a period of one (1) year from the date of shipment. If any models or samples were shown to Buyer, such models or samples were used merely to illustrate the general type and quality of the Products and not to represent that the Products would necessarily conform to said models or samples. Any Products found to be defective must be shipped to KEYENCE with all shipping costs paid by Buyer or offered to KEYENCE for inspection and examination. Upon examination by KEYENCE, KEYENCE, at its sole option, will refund the purchase price of, or repair or replace at no charge any Products found to be defective. This warranty does not apply to any defects resulting from any action of Buyer, including but not limited to improper installation, improper interfacing, improper repair, unauthorized modification, misapplication and mishandling, such as exposure to excessive current, heat, coldness, moisture, vibration or outdoors air. Components which wear are not warranted.
- (2) KEYENCE is pleased to offer suggestions on the use of its various Products. They are only suggestions, and it is Buyer's responsibility to ascertain the fitness of the Products for Buyer's intended use. KEYENCE will not be responsible for any damages that may result from the use of the Products.
- (3) The Products and any samples ("Products/Samples") supplied to Buyer are not to be used internally in humans, for human transportation, as safety devices or fail-safe systems, unless their written specifications state otherwise. Should any Products/Samples be used in such a manner or misused in any way, KEYENCE assumes no responsibility, and additionally Buyer will indemnify KEYENCE and hold KEYENCE harmless from any liability or damage whatsoever arising out of any misuse of the Products/Samples.
- (4) OTHER THAN AS STATED HEREIN, THE PRODUCTS/SAMPLES ARE PROVIDED WITH NO OTHER WARRANTIES WHATSOEVER. ALL EXPRESS, IMPLIED, AND STATUTORY WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF PROPRIETARY RIGHTS, ARE EXPRESSLY DISCLAIMED. IN NO EVENT SHALL KEYENCE AND ITS AFFILIATED ENTITIES BE LIABLE TO ANY PERSON OR ENTITY FOR ANY DIRECT, INDIRECT, INCIDENTAL, PUNITIVE, SPECIAL OR CONSEQUENTIAL DAMAGES (INCLUDING, WITHOUT LIMITATION, ANY DAMAGES RESULTING FROM LOSS OF USE, BUSINESS INTERRUPTION, LOSS OF INFORMATION, LOSS OR INACCURACY OF DATA, LOSS OF PROFITS, LOSS OF SAVINGS, THE COST OF PROCUREMENT OF SUBSTITUTED GOODS, SERVICES OR TECHNOLOGIES, OR FOR ANY MATTER ARISING OUT OF OR IN CONNECTION WITH THE USE OR INABILITY TO USE THE PRODUCTS, EVEN IF KEYENCE OR ONE OF ITS AFFILIATED ENTITIES WAS ADVISED OF A POSSIBLE THIRD PARTY'S CLAIM FOR DAMAGES OR ANY OTHER CLAIM AGAINST BUYER. In some jurisdictions, some of the foregoing warranty disclaimers or damage limitations may not apply.



BUYER'S TRANSFER OBLIGATIONS:

If the Products/Samples purchased by Buyer are to be resold or delivered to a third party, Buyer must provide such third party with a copy of this document, all specifications, manuals, catalogs, leaflets and written information provided to Buyer pertaining to the Products/Samples.

E 1101-3


6 Detailed Settings

Hold down **[M]** for 3 seconds or more to enter the settings menu. Then, press **[M]** to change the item and press **[← →]** to switch the setting value. Press **[M] + [END]** when an item is being set to return to the previous item.



■ Output 2 setting

1 **[1] [2]** When using a dual output type, if the output channel selection switch is set to the "2" side, output 2 can be set.



- ^{*1} When S-HSPD is selected for Power Modes, Output 2 of dual output types is fixed to OFF.
^{*2} This is 65535 when connected to an NU Series unit.
^{*3} When S-HSPD is selected for Power Modes, Area detection, Area % Mode, DATUM, Rising edge, or Falling edge cannot be selected.
^{*4} This cannot be used when S-HSPD is selected for Power Modes.
^{*5} This cannot be used when S-HSPD or HSPD is selected for Power Modes.
^{*6} When S-HSPD is selected for Power Modes, FULL cannot be selected for the ECO function.
^{*7} The IO-Link communication cannot be used when FULL is selected for ECO (FS-N41C).
^{*8} This item is not displayed on the FS-N41C.

KEYENCE CORPORATION

1-3-14, Higashi-Nakajima, Higashi-Yodogawa-ku,
 Osaka, 533-8555, Japan
 PHONE: +81-6-6379-2211

www.keyence.com

AUSTRIA Ph: +43 22 36-3782 66-0	HONG KONG Ph: +852-3104-1010	NETHERLANDS Ph: +31 40 20 66 100	TAIWAN Ph: +886-2-2721-8080
BELGIUM Ph: +32 1 528 1222	HUNGARY Ph: +36 1 802 73 60	PHILIPPINES Ph: +63-(0)2-981-5000	THAILAND Ph: +66-2-369-2777
BRAZIL Ph: +55-11-3045-4011	INDIA Ph: +91-44-4963-0900	POLAND Ph: +48 71 36861 60	UK & IRELAND Ph: +44-1908-696900
CANADA Ph: +1-905-366-7655	INDONESIA Ph: +62-21-2966-0120	ROMANIA Ph: +40 269-232-808	USA Ph: +1-201-930-0100
CHINA Ph: +86-21-3357-1001	ITALY Ph: +39-02-6688220	SINGAPORE Ph: +65-6392-1011	VIETNAM Ph: +84-24-3772-5555
CZECH REPUBLIC Ph: +420 222 191 483	KOREA Ph: +82-31-789-4300	SLOVAKIA Ph: +421 2 5939 6461	
FRANCE Ph: +33 1 56 37 78 00	MALAYSIA Ph: +60-3-7883-2211	SLOVENIA Ph: +386 1-4701-666	
GERMANY Ph: +49 6102 36 89-0	MEXICO Ph: +52-55-8850-0100	SWITZERLAND Ph: +41 43-45577 30	

Specifications are subject to change without notice.

A6VW1-MAN-1097

Copyright (c) 2017 KEYENCE CORPORATION. All rights reserved.
 14746E 1127-2a [96M14746] Printed in Japan



ASSEMBLY TITLE:**BROKEN WEB / END OF WEB****DRAWING NO:****GENERAL FUNCTION:**

- The broken web fault indicates that the labeler label stock has broken after the labeler pull roll. It consists of a reflective sensor and a reflector. The sensor is capable of reading clear or opaque label liner.

-When the broken web passes through the sensor, a signal is generated, that signal will shut the conveyor system down and light the red lamp on the stack lamp assembly.

-To reset the fault condition, rethread labels and press labeler run/pause to turn off the red light and place the labeler in run mode. The conveyor will restart and the labeling process will continue.

SET-UP AND ADJUSTMENTS:

- The sensor is set in light on operation mode. It is a retro-reflective operation. To set the sensor, refer to the following manufacture's instruction sheet.

- Ensure that all label material is removed from the sensor and reflector area for proper set up.


MAINTENANCE:

- See Maintenance Section

TROUBLESHOOTING:




- See Troubleshooting Section

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	202192-002	CLEAR PRODUCT SENSOR	21606-013
2	1	203161-000	REFLECTOR	21606-013
3	1	252019-000	4 PIN MALE CONNECTOR	21606-013
4	1	A24241-000	MOUNTING BLOCK	21606-013
5	1	A24242-000	SENSOR MTG. BLOCK	21606-013
6	1	A24243-000	REFLECTOR MTG. BLOCK	21606-013
7	2	A24244-000	SUPPORT ROD WITH FLAT	21606-013



A	11/11/24	NEW DRAWING	SEM
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 2/1	
XX ± .01		DATE: 11/11/24	
XXX ± .005		DRW BY: SEM	
ANGLES ± .30°		CHK BY: &CREO.CHK	
SURFACE FINISH 125		APPR BY:	
BREAK ALL EDGES .005/.015		BROKEN WEB/END OF WEB, PNP SINGLE BASE, USE PZ-G62P	
CORNER RADIUS .010/.030		MAT'L	21606-013



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
		SCALE: 3/2	
		DATE: 11/11/24	
		DRW BY: SEM	
		CHK BY: CREO.CHK	
		APPR BY:	
		BROKEN WEB/END OF WEB, PNP SINGLE BASE, USE PZ-G62P	
		MAT'L	
		21606-013	

PZ-G Series

Instruction Manual

Read this manual thoroughly before using the product.
Keep this manual readily available for future reference.

Safety precautions

- Avoid running the PZ-G cable along with power and high voltage lines, as this may cause interference and/or permanent damage.
- When using a commercially available switching regulator, ground its chassis grounding and earth grounding terminals.
- Do not use in locations where direct ambient light or external light directly shines on the light receiving surface.
- With retro-reflective type sensors, when detecting highly reflective materials (such as mirrored surfaces), stabilization may be difficult. To correct this, change the angle of the sensor head, or adjust the sensitivity.
- Avoid using power which exceeds the specifications for ripple (10% max)
- Avoid using excess force when rotating the operation mode selector switch (Light-on, Dark-on) and the sensitivity adjustment trimmer.
- This product is just intended to detect the object(s). Do not use this product for the purpose to protect a human body or a part of human body.
- This product is not intended for use as explosion-proof product. Do not use this product in a hazardous location and/or potentially explosive atmosphere.

Precautions on Regulations and Standards

UL Certificate

This product is an UL/C-UL Listed product.


- UL File No. E301717
- Category NRKH,NRKH7
- Enclosure Type 1 (Based on UL50)

Be sure to consider the following specifications when using this product as an UL/C-UL Listed Product.


- Use the power supply with Class 2 output defined in NFPA70 (NEC: National Electrical Code).
- Power supply/ Control input/ Control output circuits shall be connected to a single Class 2 source only.
- Use with the over current protection device which is rated 30V or more and not more than 1A.

Part Names


PZ-G5xN/G5xP




PZ-G5xB



PZ-G4xN/G4xP/G10xN/G10xP/G6xN/G6xP



PZ-G4xB/G10xB/G6xB




* The model name with "C" (PZ-GxxCx) is the connector type, and the model name with "E" (PZ-GxxEx) is the pigtail quick disconnect type.


Mounting Method

Side Mounting (Prepare M3 screws)

Tightening torque: 0.5 N·m or less




Tightening torque: 0.5 N·m or less



Mounting with the M18 nut (includes nut type)


The M18 nut is also available separately as OP-84225 (2 pcs. supplied).
Tightening torque: 1.0 N·m or less

Panel (5 mm or less)



Panel cut size

$\phi 18.5 \pm 0.2$ mm



Note


- Mount the M18 nut (supplied) straight in. If mounted at an angle it cannot be tightened properly.
- When tightening the M18 nut (supplied), firmly hold the main body down. The case of the main body may be damaged if held in place with a tool such as pliers.
- When tightening the M18 nut (supplied), if excess force is applied to the nut with a tool such as pliers, it may bend it out of shape. Therefore, do not apply excess force.

Sensitivity Adjustment Method

Caution



Avoid using excess force when rotating the sensitivity adjustment trimmer and operation mode selector switch as it may cause damage.



Operation mode selector switch

With the operation mode selector switch, you can select either the LIGHT-ON mode (L) or the DARK-ON (D) mode.



LIGHT-ON setting



DARK-ON setting

Reflective type (PZ-G41/G42/G101/G102/G10R/G10G/G10B Series)

The following assumes LIGHT-ON (L) is set.

Sequence	Adjustment method	Sensitivity adjustment trimmer
①	Position target in place. Slowly rotate the sensitivity trimmer from the MIN position towards the MAX position until the (orange) output indicator turns on (Position "A"). If the output indicator does not turn off, even at MIN, then MIN is considered Position "A".	
②	Remove the target. Adjust the sensitivity trimmer from MIN towards MAX until the (orange) output indicator turns on (Position "B"). If the output indicator does not light up, the MAX position is considered Position "B".	
③	Adjust the sensitivity trimmer to the midpoint between "A" and "B". Verify that the (green) stable operation light turns on with and without a target in place.	

Reference To use the sensor in DARK-ON mode, adjust the mode selector switch to "D".

Thrubeam type (PZ-G51/G52 Series) / Retro-reflective type (PZ-G61/G62 Series)


The following assumes DARK-ON (D) is set.

Sequence	Adjustment method	Sensitivity adjustment trimmer
①	Remove the target. Adjust the sensitivity trimmer to MAX. Mount the sensor heads in place so the (orange) output indicator turns off (on thrubeam models, the red light on the receiver face will turn on).	
②	Position target in place. Verify that the orange output indicator turns on (on thrubeam models, the red light on the receiver face will turn off). Adjust sensitivity lower if the output indicator does not turn on (or if the red light on the receiver face does not turn off on thrubeam models).	


Reference To use the sensor in LIGHT-ON mode, adjust the mode selector switch to "L".

I/O Circuit Diagram


PZ-G5xN/G5xP/G5xB (Transmitter side)




PZ-G5xN (Receiver side)/ G4xN/G10xN/G6xN



PZ-G5xP (Receiver side)/ G4xP/G10xP/G6xP



PZ-G5xB (Receiver side)/ G4xB/G10xB/G6xB




* The pin numbers represent those of the connector type / pigtail quick disconnect type.
The model name with "C" (PZ-GxxCx) is the connector type, and the model name with "E" (PZ-GxxEx) is the pigtail quick disconnect type.

[PZ-GxxCN/GxxCP..... M8 connector
PZ-GxxCB/GxxEN/GxxEP..... M12 connector]

Indicators

The following describes each ON/OFF condition of indicator when LIGHT-ON (L) is set.

When the DARK-ON (D) is set, the output indicator ON/OFF will reverse.



* For PZ-G62, the upper limit is 107% and the lower limit is 93%.

If the stable operation indicator turns off during operation, readjust or fine-adjust the sensitivity.

Mutual interference

- For reflective type / retro-reflective type sensors, mutual interference protection can be set for up to 2 units. However, when the sensors are mounted facing each other, change the angle of the sensor head to prevent light being emitted into each unit.(The mark detection type does not include the mutual interference function.)
- Mutual interference prevention can be set when mounting a polarizing filter attachment (optional with thrubeam type sensors) (If operation is unstable even after mounting the polarizing filter, slightly lower the sensitivity.)
- For more detailed information about mutual interference or attachment, see the PZ-G Series catalog or contact your nearest KEYENCE office.

Specifications

Type			Thrubeam		Reflective				Retro-reflective		Mark detection		
Configuration	Cable shape	Output mode	Normal	High-power	Diffuse-reflective Long-detecting distance	Diffuse-reflective Short-detecting distance	Narrow-view reflective	Definite reflective	Long detecting distance (with P.R.O. function)	transparent target detection (without P.R.O. function)	Red	Green	Blue
Rectangular	Cable	NPN	PZ-G51N	PZ-G52N	PZ-G41N	PZ-G42N	PZ-G101N	PZ-G102N	PZ-G61N	PZ-G62N	-		
		PNP	PZ-G51P	PZ-G52P	PZ-G41P	PZ-G42P	PZ-G101P	PZ-G102P	PZ-G61P	PZ-G62P			
	M8 connector	NPN	PZ-G51CN	PZ-G52CN	PZ-G41CN	PZ-G42CN	PZ-G101CN	PZ-G102CN	PZ-G61CN	PZ-G62CN	PZ-G10RCN	PZ-G10GCN	PZ-G10BCN
		PNP	PZ-G51CP	PZ-G52CP	PZ-G41CP	PZ-G42CP	PZ-G101CP	PZ-G102CP	PZ-G61CP	PZ-G62CP	PZ-G10RCP	PZ-G10GCP	PZ-G10BCP
	M12 pigtail quick disconnect	NPN	PZ-G51EN	PZ-G52EN	PZ-G41EN	PZ-G42EN	PZ-G101EN	PZ-G102EN	PZ-G61EN	PZ-G62EN	-		
		PNP	PZ-G51EP	PZ-G52EP	PZ-G41EP	PZ-G42EP	PZ-G101EP	PZ-G102EP	PZ-G61EP	PZ-G62EP			
Nut	Cable	Bipolar	PZ-G51B	PZ-G52B	PZ-G41B	PZ-G42B	PZ-G101B	PZ-G102B	PZ-G61B	PZ-G62B	-		
M12 connector	(NPN+PNP)	PZ-G51CB	PZ-G52CB	PZ-G41CB	PZ-G42CB	PZ-G101CB	PZ-G102CB	PZ-G61CB	PZ-G62CB				
Detecting distance*1			20 m	40 m	1 m (30 x 30 cm white mat paper)	300 mm (10 x 10 cm white mat paper)	200 mm	5 to 45 mm	0.1 to 4.2 m (when R-2L reflector is used)	0.1 to 1 m (when R-2L reflector is used)	8 to 15 mm		
Spot diameter			-	-	-	-	Approx. φ 5 mm (when the detecting distance is 100 mm)	Approx. φ 2 mm (when the detecting distance is 40 mm)	-	-	Approx. 1.5 x 4 mm (when the detecting distance is 10 mm)		
Light source (LED)			Red LED	Infrared LED x 2	Red LED					Infrared LED	Red LED	Green LED	Blue LED
Sensitivity adjustment			1-turn trimmer (230 degrees)										
Response time			500 μs										
Operation mode			LIGHT-ON/DARK-ON, trimmer-selectable										
Indicator (LED)			Transmitter: power (orange) Receiver: output (orange), stable operation (green), light (red)		Output (orange), stable operation (green)								
Control output			Open-collector 100 mA max. (30 V max.), Residual voltage 1 V max.										
Protection circuit			Reverse-polarity protection, over-current protection, output surge absorber										
Ratings	Power voltage		10 to 30 VDC, Ripple (P-P): ±10% max, Class 2.										
	Current consumption		Transmitter: 20 mA max. Receiver: 28 mA max.	Transmitter: 25 mA max. Receiver: 28 mA max.	34 mA max.								
Environmental resistance	Enclosure rating		IEC,JEM: IP67 / NEMA: 4X,6,12 / DIN: IP69K										
	Ambient light		Incandescent lamp: 5,000 (lx) max, Sunlight: 20,000 (lx) max.										
	Ambient temperature		-20 °C to +55°C (No freezing)										
	Relative humidity		35 to 85 % RH (No condensation)										
	Vibration resistance		10 to 55 Hz, 1.5 mm double amplitude in X, Y, Z directions, 2 hours each										
	Shock resistance		1000 m/s ² in X, Y, Z directions, 6 times each										
Interference prevention			2 units (when polarizing filter attachment is used)		2 units (with the automatic different cycle function)							-	
Material			Case, M18 nut (nut type only): reinforced glass polybutylene terephthalate (PBT), Trimmer: reinforced glass polyamide (PA) Cable (Cable type / pigtail quick disconnect type only): Polyvinyl chloride (PVC), Screw (Case connection): Steel, zinc-nickel plated, Packing (Case connection): Nitrile-butadiene rubber (NBR) Connector (pigtail quick disconnect type only): Brass-nickel plated, Polybutyleneterephthalate (PBT), Polyvinyl chloride (PVC)										
	Lens cover		Polyarylate (PAR)						Acrylic plastic (PMMA)		Polyarylate (PAR)		
Tightening torque			Rectangular type (side screw part): 0.5 N·m max. Nut type (front M18 part): 1.0 N·m max., (side slot part): 0.5 N·m max.										
Accessory*2			Instruction manual, M18 nut x 2 (nut thrubeam type), M18 nut x 1 (other nut types)										
Weight			Rectangular cable type: Approx. 60 g (Approx. 50 g for thrubeam transmitter), Rectangular M8 connector type: Approx 10 g, rectangular M12 pigtail quick disconnect type: Approx. 30 g Nut type cable type: Approx. 65 g (Approx. 55 g for thrubeam transmitter), Nut type M12 connector type: Approx 15 g										

*1 The detection distance is measured with the maximum sensitivity.

*2 The cable for the connector type / pigtail quick disconnect type is sold separately. The reflector for the retro-reflective type is sold separately.

WARRANTY

KEYENCE products are strictly factory-inspected. However, in the event of a failure, contact your nearest KEYENCE office with details of the failure.

1. WARRANTY PERIOD

The warranty period shall be for one year from the date that the product has been delivered to the location specified by the purchaser.

2. WARRANTY SCOPE

- (1) If a failure attributable to KEYENCE occurs within the abovementioned warranty period, we will repair the product, free of charge. However, the following cases shall be excluded from the warranty scope.
- Any failure resulting from improper conditions, improper environments, improper handling, or improper usage other than described in the instruction manual, the user's manual, or the specifications specifically arranged between the purchaser and KEYENCE.
 - Any failure resulting from factors other than a defect of our product, such as the purchaser's equipment or the design of the purchaser's software.
 - Any failure resulting from modifications or repairs carried out by any person other than KEYENCE staff.
 - Any failure that can certainly be prevented when the expendable part(s) is maintained or replaced correctly as described in the instruction manual, the user's manual, etc.
 - Any failure caused by a factor that cannot be foreseen at a scientific/technical level at the time when the product has been shipped from KEYENCE.
 - Any disaster such as fire, earthquake, and flood, or any other external factor, such as abnormal voltage, for which we are not liable.
- (2) The warranty scope is limited to the extent set forth in item (1), and KEYENCE assumes no liability for any purchaser's secondary damage (damage of equipment, loss of opportunities, loss of profits, etc.) or any other damage resulting from a failure of our product.

3. PRODUCT APPLICABILITY

KEYENCE products are designed and manufactured as general-purpose products for general industries.

Therefore, our products are not intended for the applications below and are not applicable to them. If, however, the purchaser consults with us in advance regarding the employment of our product, understands the specifications, ratings, and performance of the product on their own responsibility, and takes necessary safety measures, the product may be applied. In this case, the warranty scope shall be the same as above.

- Facilities where the product may greatly affect human life or property, such as nuclear power plants, aviation, railroads, ships, motor vehicles, or medical equipment
- Public utilities such as electricity, gas, or water services
- Usage outdoors, under similar conditions or in similar environments

E 1040-1

KEYENCE CORPORATION

1-3-14, Higashi-Nakajima, Higashi-Yodogawa-ku,
Osaka, 533-8555, Japan

PHONE: +81-6-6379-2211 www.keyence.com

Specifications are subject to change without notice.

A7WW1-MAN-0069

Copyright (c) 2010 KEYENCE CORPORATION. All rights reserved.

11227E 1070-1 96M11227

Printed in Japan



ASSEMBLY TITLE: BROKEN WEB / END OF WEB

DRAWING NO:

GENERAL FUNCTION:

- The broken web fault indicates that the labeler label stock has broken after the labeler pull roll. It consists of a reflective sensor and a reflector. The sensor is capable of reading clear or opaque label liner.

-When the broken web passes through the sensor, a signal is generated, that signal will shut the conveyor system down and light the red lamp on the stack lamp assembly.

-To reset the fault condition, rethread labels and press labeler run/pause to turn off the red light and place the labeler in run mode. The conveyor will restart and the labeling process will continue.

SET-UP AND ADJUSTMENTS:

- The sensor is set in light on operation mode. It is a retro-reflective operation. To set the sensor, refer to the following manufacture's instruction sheet.

- Ensure that all label material is removed from the sensor and reflector area for proper set up.


MAINTENANCE:

- See Maintenance Section

TROUBLESHOOTING:


- See Troubleshooting Section






ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	202192-002	CLEAR PRODUCT SENSOR	21606-012
2	1	203161-000	REFLECTOR	21606-012
3	1	252019-000	4 PIN MALE CONNECTOR	21606-012
4	1	A24242-000	SENSOR MTG. BLOCK	21606-012
5	1	A24243-000	REFLECTOR MTG. BLOCK	21606-012
6	2	A25772-000	POST, SENSOR	21606-012




A	11/11/24	NEW DRAWING	SEM
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .01 XX ± .01 XXX ± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		QUADREL LABELING SYSTEMS		SCALE: 2/1	
		7670 JENTHER DRIVE		DATE: 11/11/24	
		MENTOR, OHIO 44060		DRW BY: SEM	
		(440) 602-4700		CHK BY: CREO.CHK	
		BROKEN WEB/END OF WEB, PNP DUAL POSTS, USE PZ-G62P			
		APPR BY:			
MAT'L		21606-012			



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/1	
XX ± .1		DATE: 11/11/24	
XXX ± .005		DRW BY: SEM	
ANGLES ± 90°		CHK BY: CREO.CHK	
SURFACE FINISH 125		APPR BY:	
BREAK ALL EDGES .005/.015		BROKEN WEB/END OF WEB, PNP DUAL POSTS, USE PZ-G62P	
CORNER RADIUS .010/.030		MATERIAL	
ALL ANGLES ARE 90°		21606-012	



QUADREL LABELING SYSTEMS

7670 JENTHER DRIVE

MENTOR, OHIO 44060

(440) 602-4700

REV

DATE

DESCRIPTION

BY

A

11/11/24

NEW DRAWING

SEM

PZ-G Series

Instruction Manual

Read this manual thoroughly before using the product.
Keep this manual readily available for future reference.

Safety precautions

- Avoid running the PZ-G cable along with power and high voltage lines, as this may cause interference and/or permanent damage.
- When using a commercially available switching regulator, ground its chassis grounding and earth grounding terminals.
- Do not use in locations where direct ambient light or external light directly shines on the light receiving surface.
- With retro-reflective type sensors, when detecting highly reflective materials (such as mirrored surfaces), stabilization may be difficult. To correct this, change the angle of the sensor head, or adjust the sensitivity.
- Avoid using power which exceeds the specifications for ripple (10% max)
- Avoid using excess force when rotating the operation mode selector switch (Light-on, Dark-on) and the sensitivity adjustment trimmer.
- This product is just intended to detect the object(s). Do not use this product for the purpose to protect a human body or a part of human body.
- This product is not intended for use as explosion-proof product. Do not use this product in a hazardous location and/or potentially explosive atmosphere.

Precautions on Regulations and Standards

UL Certificate

This product is an UL/C-UL Listed product.


- UL File No. E301717
- Category NRKH,NRKH7
- Enclosure Type 1 (Based on UL50)

Be sure to consider the following specifications when using this product as an UL/C-UL Listed Product.


- Use the power supply with Class 2 output defined in NFPA70 (NEC: National Electrical Code).
- Power supply/ Control input/ Control output circuits shall be connected to a single Class 2 source only.
- Use with the over current protection device which is rated 30V or more and not more than 1A.

Part Names


PZ-G5xN/G5xP




PZ-G5xB



PZ-G4xN/G4xP/G10xN/G10xP/G6xN/G6xP



PZ-G4xB/G10xB/G6xB




* The model name with "C" (PZ-GxxCx) is the connector type, and the model name with "E" (PZ-GxxEx) is the pigtail quick disconnect type.


Mounting Method

Side Mounting (Prepare M3 screws)

Tightening torque: 0.5 N·m or less




Tightening torque: 0.5 N·m or less



Mounting with the M18 nut (includes nut type)


The M18 nut is also available separately as OP-84225 (2 pcs. supplied).
Tightening torque: 1.0 N·m or less

Panel (5 mm or less)



Panel cut size

$\phi 18.5 \pm 0.2$ mm



Note


- Mount the M18 nut (supplied) straight in. If mounted at an angle it cannot be tightened properly.
- When tightening the M18 nut (supplied), firmly hold the main body down. The case of the main body may be damaged if held in place with a tool such as pliers.
- When tightening the M18 nut (supplied), if excess force is applied to the nut with a tool such as pliers, it may bend it out of shape. Therefore, do not apply excess force.

Sensitivity Adjustment Method

Caution



Avoid using excess force when rotating the sensitivity adjustment trimmer and operation mode selector switch as it may cause damage.



Operation mode selector switch

With the operation mode selector switch, you can select either the LIGHT-ON mode (L) or the DARK-ON (D) mode.



LIGHT-ON setting



DARK-ON setting

Reflective type (PZ-G41/G42/G101/G102/G10R/G10G/G10B Series)

The following assumes LIGHT-ON (L) is set.

Sequence	Adjustment method	Sensitivity adjustment trimmer
①	Position target in place. Slowly rotate the sensitivity trimmer from the MIN position towards the MAX position until the (orange) output indicator turns on (Position "A"). If the output indicator does not turn off, even at MIN, then MIN is considered Position "A".	
②	Remove the target. Adjust the sensitivity trimmer from MIN towards MAX until the (orange) output indicator turns on (Position "B"). If the output indicator does not light up, the MAX position is considered Position "B".	
③	Adjust the sensitivity trimmer to the midpoint between "A" and "B". Verify that the (green) stable operation light turns on with and without a target in place.	

Reference To use the sensor in DARK-ON mode, adjust the mode selector switch to "D".

Thrubeam type (PZ-G51/G52 Series) / Retro-reflective type (PZ-G61/G62 Series)


The following assumes DARK-ON (D) is set.

Sequence	Adjustment method	Sensitivity adjustment trimmer
①	Remove the target. Adjust the sensitivity trimmer to MAX. Mount the sensor heads in place so the (orange) output indicator turns off (on thrubeam models, the red light on the receiver face will turn on).	
②	Position target in place. Verify that the orange output indicator turns on (on thrubeam models, the red light on the receiver face will turn off). Adjust sensitivity lower if the output indicator does not turn on (or if the red light on the receiver face does not turn off on thrubeam models).	


Reference To use the sensor in LIGHT-ON mode, adjust the mode selector switch to "L".

I/O Circuit Diagram


PZ-G5xN/G5xP/G5xB (Transmitter side)




PZ-G5xN (Receiver side)/G4xN/G10xN/G6xN



PZ-G5xP (Receiver side)/G4xP/G10xP/G6xP



PZ-G5xB (Receiver side)/G4xB/G10xB/G6xB




* The pin numbers represent those of the connector type / pigtail quick disconnect type.
The model name with "C" (PZ-GxxCx) is the connector type, and the model name with "E" (PZ-GxxEx) is the pigtail quick disconnect type.

[PZ-GxxCN/GxxCP..... M8 connector
PZ-GxxCB/GxxEN/GxxEP..... M12 connector]

Indicators

The following describes each ON/OFF condition of indicator when LIGHT-ON (L) is set.

When the DARK-ON (D) is set, the output indicator ON/OFF will reverse.



* For PZ-G62, the upper limit is 107% and the lower limit is 93%.

If the stable operation indicator turns off during operation, readjust or fine-adjust the sensitivity.

Mutual interference

- For reflective type / retro-reflective type sensors, mutual interference protection can be set for up to 2 units. However, when the sensors are mounted facing each other, change the angle of the sensor head to prevent light being emitted into each unit. (The mark detection type does not include the mutual interference function.)
- Mutual interference prevention can be set when mounting a polarizing filter attachment (optional with thru-beam type sensors). (If operation is unstable even after mounting the polarizing filter, slightly lower the sensitivity.)
- For more detailed information about mutual interference or attachment, see the PZ-G Series catalog or contact your nearest KEYENCE office.

Specifications

Type			Thru-beam		Reflective				Retro-reflective		Mark detection		
Configuration	Cable shape	Output mode	Normal	High-power	Diffuse-reflective Long-detecting distance	Diffuse-reflective Short-detecting distance	Narrow-view reflective	Definite reflective	Long detecting distance (with P.R.O. function)	transparent target detection (without P.R.O. function)	Red	Green	Blue
Rectangular	Cable	NPN	PZ-G51N	PZ-G52N	PZ-G41N	PZ-G42N	PZ-G101N	PZ-G102N	PZ-G61N	PZ-G62N	-		
		PNP	PZ-G51P	PZ-G52P	PZ-G41P	PZ-G42P	PZ-G101P	PZ-G102P	PZ-G61P	PZ-G62P			
	M8 connector	NPN	PZ-G51CN	PZ-G52CN	PZ-G41CN	PZ-G42CN	PZ-G101CN	PZ-G102CN	PZ-G61CN	PZ-G62CN	PZ-G10RCN	PZ-G10GCN	PZ-G10BCN
		PNP	PZ-G51CP	PZ-G52CP	PZ-G41CP	PZ-G42CP	PZ-G101CP	PZ-G102CP	PZ-G61CP	PZ-G62CP	PZ-G10RCP	PZ-G10GCP	PZ-G10BCP
	M12 pigtail quick disconnect	NPN	PZ-G51EN	PZ-G52EN	PZ-G41EN	PZ-G42EN	PZ-G101EN	PZ-G102EN	PZ-G61EN	PZ-G62EN	-		
		PNP	PZ-G51EP	PZ-G52EP	PZ-G41EP	PZ-G42EP	PZ-G101EP	PZ-G102EP	PZ-G61EP	PZ-G62EP			
Nut	Cable	Bipolar	PZ-G51B	PZ-G52B	PZ-G41B	PZ-G42B	PZ-G101B	PZ-G102B	PZ-G61B	PZ-G62B	-		
M12 connector	(NPN+PNP)	PZ-G51CB	PZ-G52CB	PZ-G41CB	PZ-G42CB	PZ-G101CB	PZ-G102CB	PZ-G61CB	PZ-G62CB				
Detecting distance*1			20 m	40 m	1 m (30 x 30 cm white mat paper)	300 mm (10 x 10 cm white mat paper)	200 mm	5 to 45 mm	0.1 to 4.2 m (when R-2L reflector is used)	0.1 to 1 m (when R-2L reflector is used)	8 to 15 mm		
Spot diameter			-	-	-	-	Approx. φ 5 mm (when the detecting distance is 100 mm)	Approx. φ 2 mm (when the detecting distance is 40 mm)	-	-	Approx. 1.5 x 4 mm (when the detecting distance is 10 mm)		
Light source (LED)			Red LED	Infrared LED x 2	Red LED					Infrared LED	Red LED	Green LED	Blue LED
Sensitivity adjustment			1-turn trimmer (230 degrees)										
Response time			500 μs										
Operation mode			LIGHT-ON/DARK-ON, trimmer-selectable										
Indicator (LED)			Transmitter: power (orange) Receiver: output (orange), stable operation (green), light (red)		Output (orange), stable operation (green)								
Control output			Open-collector 100 mA max. (30 V max.), Residual voltage 1 V max.										
Protection circuit			Reverse-polarity protection, over-current protection, output surge absorber										
Ratings	Power voltage		10 to 30 VDC, Ripple (P-P): ±10% max, Class 2.										
	Current consumption		Transmitter: 20 mA max. Receiver: 28 mA max.	Transmitter: 25 mA max. Receiver: 28 mA max.	34 mA max.								
Environmental resistance	Enclosure rating		IEC, JEM: IP67 / NEMA: 4X, 6, 12 / DIN: IP69K										
	Ambient light		Incandescent lamp: 5,000 (lx) max, Sunlight: 20,000 (lx) max.										
	Ambient temperature		-20 °C to +55°C (No freezing)										
	Relative humidity		35 to 85 % RH (No condensation)										
	Vibration resistance		10 to 55 Hz, 1.5 mm double amplitude in X, Y, Z directions, 2 hours each										
	Shock resistance		1000 m/s ² in X, Y, Z directions, 6 times each										
Interference prevention			2 units (when polarizing filter attachment is used)		2 units (with the automatic different cycle function)							-	
Material			Case, M18 nut (nut type only): reinforced glass polybutylene terephthalate (PBT), Trimmer: reinforced glass polyamide (PA) Cable (Cable type / pigtail quick disconnect type only): Polyvinyl chloride (PVC), Screw (Case connection): Steel, zinc-nickel plated, Packing (Case connection): Nitrile-butadiene rubber (NBR) Connector (pigtail quick disconnect type only): Brass-nickel plated, Polybutyleneterephthalate (PBT), Polyvinyl chloride (PVC)										
	Lens cover		Polyarylate (PAR)						Acrylic plastic (PMMA)		Polyarylate (PAR)		
Tightening torque			Rectangular type (side screw part): 0.5 N·m max. Nut type (front M18 part): 1.0 N·m max., (side slot part): 0.5 N·m max.										
Accessory*2			Instruction manual, M18 nut x 2 (nut thru-beam type), M18 nut x 1 (other nut types)										
Weight			Rectangular cable type: Approx. 60 g (Approx. 50 g for thru-beam transmitter), Rectangular M8 connector type: Approx 10 g, rectangular M12 pigtail quick disconnect type: Approx. 30 g Nut type cable type: Approx. 65 g (Approx. 55 g for thru-beam transmitter), Nut type M12 connector type: Approx 15 g										

*1 The detection distance is measured with the maximum sensitivity.

*2 The cable for the connector type / pigtail quick disconnect type is sold separately. The reflector for the retro-reflective type is sold separately.

WARRANTY

KEYENCE products are strictly factory-inspected. However, in the event of a failure, contact your nearest KEYENCE office with details of the failure.

1. WARRANTY PERIOD

The warranty period shall be for one year from the date that the product has been delivered to the location specified by the purchaser.

2. WARRANTY SCOPE

- (1) If a failure attributable to KEYENCE occurs within the abovementioned warranty period, we will repair the product, free of charge. However, the following cases shall be excluded from the warranty scope.
- Any failure resulting from improper conditions, improper environments, improper handling, or improper usage other than described in the instruction manual, the user's manual, or the specifications specifically arranged between the purchaser and KEYENCE.
 - Any failure resulting from factors other than a defect of our product, such as the purchaser's equipment or the design of the purchaser's software.
 - Any failure resulting from modifications or repairs carried out by any person other than KEYENCE staff.
 - Any failure that can certainly be prevented when the expendable part(s) is maintained or replaced correctly as described in the instruction manual, the user's manual, etc.
 - Any failure caused by a factor that cannot be foreseen at a scientific/technical level at the time when the product has been shipped from KEYENCE.
 - Any disaster such as fire, earthquake, and flood, or any other external factor, such as abnormal voltage, for which we are not liable.
- (2) The warranty scope is limited to the extent set forth in item (1), and KEYENCE assumes no liability for any purchaser's secondary damage (damage of equipment, loss of opportunities, loss of profits, etc.) or any other damage resulting from a failure of our product.

3. PRODUCT APPLICABILITY

KEYENCE products are designed and manufactured as general-purpose products for general industries.

Therefore, our products are not intended for the applications below and are not applicable to them. If, however, the purchaser consults with us in advance regarding the employment of our product, understands the specifications, ratings, and performance of the product on their own responsibility, and takes necessary safety measures, the product may be applied. In this case, the warranty scope shall be the same as above.

- Facilities where the product may greatly affect human life or property, such as nuclear power plants, aviation, railroads, ships, motor vehicles, or medical equipment
- Public utilities such as electricity, gas, or water services
- Usage outdoors, under similar conditions or in similar environments

E 1040-1

KEYENCE CORPORATION

1-3-14, Higashi-Nakajima, Higashi-Yodogawa-ku,
Osaka, 533-8555, Japan

PHONE: +81-6-6379-2211 www.keyence.com

Specifications are subject to change without notice.

A7WW1-MAN-0069

Copyright (c) 2010 KEYENCE CORPORATION. All rights reserved.

11227E 1070-1 96M11227

Printed in Japan



system

ASSEMBLY TITLE: FRAME ASSEMBLY

GENERAL FUNCTION:

- Provides solid mounting for labeling head if not installed on a system that allows for vertical and horizontal adjustment.
- Allows for vertical and horizontal adjustment in the setup of the labeling head operation.


SET-UP AND ADJUSTMENTS:


- Rotate leveling pads to appropriate position. Secure locknut when proper height is achieved.
- Using ratchet handle, adjust labeling head vertical and horizontal position.





MAINTENANCE:

- Clean wipe down rails with clean cloth.

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	4	791449-000	CASTERS, SWIVEL 3-1/2"	84187F-000
2	4	793020-001	LEVELING MOUNT	84187F-000
3	4	B22787-84187	CONVEYOR RISER	84187F-000
4	1	D24424-84187	WELDED FRAME ASSEMBLY	84187F-000
5	2	D24425-84187	WIRE COVER	84187F-000




A		Jul-07-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION		BY
ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY				
QUADREL LABELING SYSTEMS			SCALE:	5/32
			DATE:	Jul-07-25
			DRW BY:	TAZ
			CHK BY:08/11/2025-SEM	
			APPR BY:	
CONVEYOR MTG FRAME				
MAT'L			84187F-000	






THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 5/32	
XX ± .1		DATE: Jul-07-25	
XXX ± .005		DRW BY: TAZ	
ANGLES ± .00°		CHK BY: 08/11/2025-SEM	
SURFACE FINISH: 125		APPR BY:	
BREAK ALL EDGES .005/0.15		CONVEYOR MTG FRAME	
CORNER RADIUS .010/.030		MAT'L	
ALL ANGLES ARE 90°		84187F-000	

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	791449-000	SWIVEL CASTER	22614-84187
2	2	793020-001	LEVELING MOUNT	22614-84187
3	2	B22787-84187	CONVEYOR RISER	22614-84187
4	1	D25009-84187	WELDED FRAME ASSEMBLY	22614-84187



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 5/16	
XXX ± .01		DATE: Jul-07-25	
XXX ± .005		DRW BY: TAZ	
ANGLES ± 90°		CHK BY:	
SURFACE FINISH 125		APPR BY:	
BREAK ALL EDGES .005/ .015			
CORNER RADIUS .010/ .030			
ALL ANGLES ARE 90°			
QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700		CONVEYOR SUPPORT	
MAT'L		22614-84187	22614-84187




THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE

X ± .1
XX ± .01
XXX ± .005
ANGLES ± .50°


SURFACE FINISH 125
BREAK ALL EDGES .005/ .015
CORNER RADIUS .010/ .030
ALL ANGLES ARE 90°




QUADREL LABELING SYSTEMS
7670 JENTER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

SCALE: 1/4
DATE: Jul-07-25
DRW BY: TAZ
CHK BY:
APPR BY:

A	Jul-07-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY
CONVEYOR SUPPORT			
MAT'L		22614-84187	22614-84187







ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	791449-000	SWIVEL CASTER	84187S-000
2	1	793020-000	LEVELING MOUNT	84187S-000
3	1	C21306-000	HEAD SUPPORT BACKING PLATE	84187S-000
4	1	D24513-84187	STAND WELDMNT	84187S-000
5	4	HCS173		84187S-000
6	4	HHN002		84187S-000




A	Jul-07-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30°		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		SCALE: 1/4 DATE: Jul-07-25 DRW BY: TAZ CHK BY: APPR BY:	
ELECTRICAL ENCLOSURE STAND		MATERIAL	
84187S-000		84187S-000	







THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 5/32	
X ± .1		DATE: Jul-07-25	
XX ± .01		DRW BY: TAZ	
XXX ± .005		CHK BY:	
ANGLES ± .00°		APPR BY:	
SURFACE FINISH: 125		ELECTRICAL ENCLOSURE STAND	
BREAK ALL EDGES .005/ .015		MAT'L 84187S-000	
CORNER RADIUS .010/ .030		84187S-000	
ALL ANGLES ARE 90°			

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	791449-000	SWIVEL CASTER	84187S-001
2	1	793020-000	LEVELING MOUNT	84187S-001
3	1	A26332-006		84187S-001
4	1	C21306-000	HEAD SUPPORT BACKING PLATE	84187S-001
5	1	D24513-753	STAND WELDMNT	84187S-001
6	4	HCS173		84187S-001
7	4	HHN002		84187S-001



A	Jul-07-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30°		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		SCALE: 7/32 DATE: Jul-07-25 DRW BY: TAZ CHK BY: APPR BY:	
ELECTRICAL ENCLOSURE STAND		MAT'L 84187S-001	
		84187S-001	



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 5/32	
XXX ± .01		DATE: Jul-07-25	
XXX ± .005		DRW BY: TAZ	
ANGLES ± .00°		CHK BY:	
SURFACE FINISH 125		APPR BY:	
BREAK ALL EDGES .005/ .015		ELECTRICAL ENCLOSURE STAND	
CORNER RADIUS .010/ .030		MAT'L 84187S-001	
ALL ANGLES ARE 90°		84187S-001	

ASSEMBLY TITLE: NON-INTEGRATED CONVEYOR

GENERAL FUNCTION:

- To transfer the product to the labeling heads at a predetermined speed.
- To provide retention for the head support and guide rails.

SET-UP AND ADJUSTMENTS:

- Adjust conveyor to proper working height by rotating leveling pads to appropriate position. Secure locknut when proper height is achieved.
- Using ratchet handles, adjust guide rails to the product.
- Adjust conveyor speed by means of conveyor speed potentiometer (if applicable) located in the remote electronics enclosure mounted to the conveyor, or through the operator's touchscreen if provided.

MAINTENANCE:

- The conveyor drive chain must be greased with white lithium grease.
- Do not allow chain and sprockets to run dry, lubricate periodically.
- The gear motor gearbox should be checked quarterly and filled with Synthetic based Tivela Oil SC320 or an ISO320 Gear Lube lubricant.
- Grease flange bearings often to prevent them from running dry.

TROUBLESHOOTING:

PROBLEM


- Excessive Noise
- Chain too loose
- Uneven wear on sprockets.
- Shaft not running concentric

WHAT TO DO


- Realign sprocket.
- Check if chain and sprockets are lubricated. If dry, lubricate as discussed above.
- Slide gear motor downward to create more tension on chain.
- Realign sprockets.
- Replace flange bearing.







ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	22613-049P	4' OUTFEED CONVEYOR	84187C-000
2	1	342018-000	IDLER WHEEL	84187C-000
3	95	361174-000	TABLE TOP CHAIN LINK	84187C-000
4	2	791884-000-851N	WEAR STRIP, FLAT BAR CLIP-ON (8ft)	84187C-000
5	1	A23098-000	IDLER SHAFT	84187C-000
6	2	A23099-000	CHAIN BELT GUIDE	84187C-000
7	2	B22558-004	SPLICE PLATE	84187C-000
8	1	D22445-612	SIDE WALL INFEED EXTENSION	84187C-000
9	1	D22445-613	SIDE WALL EXTENSION	84187C-000
10	1	D22776-002	MOTOR SPLASH GUARD	84187C-000



A	Jul-09-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .00		 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		CUSTOM CONVEYOR	
MAT'L	84187C-000	84187C-000	




156.1

22.1


9.0




THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
X ± .1 XX ± .01 XXX ± .005 ANGLES ± .00°		SCALE: 5/32 DATE: Jul-09-25 DRW BY: TAZ CHK BY: APPR BY:	
SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		CUSTOM CONVEYOR	
MAT'L		84187C-000	84187C-000



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	111064-000	BEARING, BANDED THRUST BALL	22613-049P
2	2	151038-000	BEARING, THRUST WASHER	22613-049P
3	1	322172-000	SPROCKET, 30 TEETH	22613-049P
4	1	322191-001	SPROCKET	22613-049P
5	1	342019-000	DRIVE SPROCKET, MODULINE	22613-049P
6	2	361170-000	COLLAR, 1 IN. ID ONE-PIECE CLAMP	22613-049P
7	1	412529-000	GEARBOX, 10:1 RH	22613-049P
8	1	413005-000	MOTOR, 1 HP, 3 PHASE WASHGUARD	22613-049P
9	15	791838-000	SPACER	22613-049P
10	2	A21846-000	INTERNAL CONVEYOR BEARING BLOCK	22613-049P
11	2	A25452-012	GUARD STAND OFF	22613-049P
12	1	B20883-003	CONVEYOR DRIVE SHAFT	22613-049P
13	1	B22283-002	GEAR BOX MOUNTING PLATE	22613-049P
14	1	C20448-015	OUTFEED CONVEYOR CAP	22613-049P
15	1	C20478-004	OUTFEED CONVEYOR CAP	22613-049P
16	1	C21126-101	DRIVE GUARD	22613-049P
17	1	D25008-080	OUT FEED CONVEYOR SIDE WALL	22613-049P
18	1	D25008-081	SIDEWALL EXTENTION OUTFEED	22613-049P
19	1	202832-000	ENCODER	22613-049P

A	Jul-09-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
		SCALE: 3/16 DATE: Jul-09-25 DRW BY: TAZ CHK BY: APPR BY:	
		4' OUTFEED CONVEYOR	
		MAT'L 22613-049P	22613-049P



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE

xxx ± .01

xxx ± .005

ANGLES ± 90°

SURFACE FINISH 125

BREAK ALL EDGES .005/ .015

CORNER RADIUS .010/ .030

ALL ANGLES ARE 90°

QUADREL LABELING SYSTEMS

7670 JENTHER DRIVE

MENTOR, OHIO 44060

(440) 602-4700

SCALE: 3/8

DATE: Jul-09-25

DRW BY: TAZ

CHK BY:

APPR BY:

REV

DATE

DESCRIPTION

BY

A

Jul-09-25

NEW DRAWING


TAZ

MAT'L

22613-049P





22613-049P

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	791732-000	CLAMP FOR CONICAL SIDE GUIDE	22435-030
2	1	792711-000	CAP, ORANGE	22435-030
3	2	801308-000	KNOB W/ 1/4-20 STUD	22435-030
4	1	A20653-000	CLAMPING ROD	22435-030
5	1	A20875-000	RETAINER BLOCK, CONV. RAIL	22435-030
6	1	A20876-000	RETAINER BLOCK	22435-030
7	1	A21198-000	ADJUSTMENT ROD	22435-030



A	01/29/24	NEW DRAWING	SEM
REV	DATE	DESCRIPTION	BYE


THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30°		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
SURFACE FINISH 125 BREAK ALL EDGES .005/0.15 CORNER RADIUS .010/0.50		SCALE: 3/2 DATE: 01/29/24 DRW BY: SEM CHK BY: 03/07/2024-SEM APPR BY:	
MAT'L		CONVEYOR RAIL KIT	
		22435-030	



UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE

$x \pm .1$
 $xx \pm .01$
 $xxx \pm .005$
ANGLES $\pm .50^\circ$

SURFACE FINISH 125
BREAK ALL EDGES .005/ .015
CORNER RADIUS .010/ .030
ALL ANGLES ARE 90°



QUADREL LABELING SYSTEMS
7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700


A	01/29/24	NEW DRAWING	SEM
REV	DATE	DESCRIPTION	BYE

SCALE: 1/1
DATE: 01/29/24
DRW BY: SEM
CHK BY: 03/07/2024-SEM
APPR BY:

CONVEYOR RAIL KIT

MAT'L 22435-030





THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	791724-002	ROTOCON	22647-000
2	1	791798-000	BASE CLAMP, 1" PIPE	22647-000
3	1	791981-200	HEAT GUN	22647-000
4	1	801805-000	CLAMPING LEVER	22647-000
5	1	A20688-000	LOCKING CLAMP	22647-000
6	1	A20689-000	LOCKING CLAMP	22647-000
7	1	A20844-000	GUIDE RAIL CLAMP BAR	22647-000
8	1	A20845-000	GUIDE RAIL CLAMP BAR	22647-000
9	1	A21691-000	MOUNTING BLOCK	22647-000
10	2	A23478-003	VERTICAL ADJUSTMENT ROD	22647-000
11	1	A23483-000	MOUNTING PLATE	22647-000
12	1	A96330-000	HEAT GUN MOUNTING PLATE	22647-000


NOT SHOWN:
791981-101 HEAT GUN, ANGLE NOZZLE

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		QUADREL LABELING SYSTEMS	
X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30°		7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
SURFACE FINISH 125 BREAK ALL EDGES .005/0.15 CORNER RADIUS .010/0.50		SCALE: 1/2 DATE: JAN-04-22 DRW BY: TAZ CHK BY: APPR BY:	
HEAT GUN MOUNT		MAT'L	
		22647-000	



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/2	
XX ± .01		DATE: JAN-04-22	
XXX ± .005		DRW BY: TAZ3	
ANGLES ± .00		CHK BY:	
SURFACE FINISH 125		APPR BY:	
BREAK ALL EDGES .005/ .015		HEAT GUN MOUNT	
CORNER RADIUS .010/ .030		MAT'L	
ALL ANGLES ARE 90°		22647-000	


ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	792190-000	TRANSFER ROLLERS	22831-000
2	1	B21924-003	TRANSFER ROLLER MOUNTING PLATE	22831-000
3	1	B21925-005	TRANSFER SUPPORT PLATE	22831-000
4	1	B21926-003	TRANSFER CONNECTING PLATE	22831-000



A	3-8-24	NEW DRAWING	ATT
REV	DATE	DESCRIPTION	BY





THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/1	
X ± .1		DATE: 3-8-24	
XX ± .01		DRW BY: ATT	
XXX ± .005		CHK BY:	
ANGLES ± .00°		APPR BY:	
SURFACE FINISH 125		ROLLER END TRANSFER, 4.50"	
BREAK ALL EDGES .005/ .015		MAT'L	
CORNER RADIUS .010/ .030		22831-000	
ALL ANGLES ARE 90°		22831-000	

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	221152-005	ENCLOSURE, E-STOP W/ BUTTON	20789-000
2	1	241780-000	STRAIN RELIEF, CABLE	20789-000
3	1	241780-001	STRAIN RELIEF, CABLE PANEL	20789-000
4	1	A25719-000	CYLINDER MOUNTING ANGLE	20789-000



A	8-29-16	NEW DRAWING	TJS
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30°		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		SCALE: 1/1 DATE: 8-29-16 DRW BY: TJS CHK BY: 03/08/2024-SEM APPR BY:	
MAT'L		EMERGENCY STOP ASSEMBLY	
		20789-000	



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/1	
XX ± .01		DATE: 8-29-16	
XXX ± .005		DRW BY: TJS	
ANGLES ± .00°		CHK BY: 03/08/2024-SEM	
SURFACE FINISH: 125		APPR BY:	
BREAK ALL EDGES .005/ .015		EMERGENCY STOP ASSEMBLY	
CORNER RADIUS .010/ .030		MAT'L	
ALL ANGLES ARE 90°		20789-000	

ASSEMBLY TITLE: HEAD SUPPORT ASSEMBLY

GENERAL FUNCTION:

The head support assembly keeps the labeling head in a “locked position” and prevents head vibration and wobbling as the label motor is engaged. The head support assembly is also used to set the camber or front/back tilt of the head.

SETUP AND ADJUSTMENTS:


HORIZONTAL ADJUSTMENT: To set the horizontal position of the labeling head, use the side mount wheel handle (some older systems may feature the ratcheted handle). Turn the handle clockwise to move the head towards the conveyor. Turn it counter clockwise to move the head away from the conveyor.

VERTICAL ADJUSTMENT: Using the lower wheel handle to set the vertical position of the labeling head. Turn the wheel clockwise to lower labeling head. Turn the wheel counter clockwise to raise the labeling head.

MAINTENANCE:

No scheduled maintenance is required for this assembly. Always keep the drive areas free of label flash and debris.





TROUBLESHOOTING: None this section.




ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	21790-005_8	PNEUMATIC LIFT KIT	84187HS-000
2	1	22173-600	VERTICAL IGUS SLIDE, 17.5"	84187HS-000
3	1	791449-000	CASTERS, SWIVEL 3-1/2"	84187HS-000
4	1	793020-000	LEVELING MOUNT	84187HS-000
5	1	801080-001	6" HANDWHEEL	84187HS-000
6	1	C21306-000	HEAD SUPPORT BACKING PLATE	84187HS-000
7	1	D23570-84187	HORIZONTAL MOUNTING FRAME	84187HS-000
8	1	D24433-84187	HEAD SUPPORT RISER	84187HS-000
9	4	HCS173		84187HS-000
10	4	HHN002		84187HS-000

A	Jul-07-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30°		SCALE: 7/32 DATE: Jul-07-25 DRW BY: TAZ CHK BY: APPR BY:	
SURFACE FINISH 125 BREAK ALL EDGES .005/0.15 CORNER RADIUS .010/0.50		CUSTOM HEAD SUPPORT W/PNEUMATIC LIFT	
MAT'L		84187HS-000	84187HS-000








THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 3/16	
X ± .1		DATE: Jul-07-25	
XX ± .01		DRW BY: TAZ	
XXX ± .005		CHK BY:	
ANGLES ± .00°		APPR BY:	
SURFACE FINISH 125		CUSTOM HEAD SUPPORT W/PNEUMATIC LIFT	
BREAK ALL EDGES .005/.015		MAT'L 84187HS-000	
CORNER RADIUS .010/.030		84187HS-000	
ALL ANGLES ARE 90°		84187HS-000	



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	4	111072-000	BEARING, BALL	21790-005_8
2	1	141172-000	SLEEVE BEARING, 1/2OD. x 3/8ID. x 3/4LNG	21790-005_8
3	1	141177-000	SLEEVE BEARING, 5/8OD. x 1/2ID. x 3/4LNG	21790-005_8
4	2	151018-000	BEARING, THRUST WASHER	21790-005_8
5	1	151021-000	BEARING, THRUST WASHER	21790-005_8
6	2	181079-000	BEARING, NEEDLE ROLLER	21790-005_8
7	4	181080-000	BEARING, THRUST WASHER	21790-005_8
8	1	181108-000	BEARING, NEEDLE ROLLER	21790-005_8
9	2	181111-000	THRUST WASHER	21790-005_8
10	1	191562-000	BELT, TIMING 1/5P	21790-005_8
11	5	361169-000	COLLAR, 1/2 IN. ID ONE-PIECE CLAMP	21790-005_8
12	2	392568-000_RET	AIR CYLINDER	21790-005_8
13	4	792248-001	PILLOW BLOCK	21790-005_8
14	1	792264-010	DRYLIN RAIL	21790-005_8
15	1	792354-000	DIGITAL POSITION INDICATOR	21790-005_8
16	1	801079-000	4" DIA HANDWHEEL 1/2" BORE	21790-005_8
17	1	801080-000	6" HANDWHEEL	21790-005_8
18	1	A24077-000	BRONZE NUT, RH	21790-005_8
19	1	A24734-002	COUPLING BASE BLOCK	21790-005_8
20	2	A24735-000	COUPLING JAW	21790-005_8
21	1	A24736-000	CYLINDER MOUNTING PLATE	21790-005_8
22	2	A25701-006	HANDLE SHAFT	21790-005_8
23	2	A25702-000	TIMING PULLEY	21790-005_8
24	2	A25881-000	TIMING PULLEY	21790-005_8
25	1	B21346-000	BOTTOM BEARING PLATE	21790-005_8
26	1	B22005-012	BEARING PLATE	21790-005_8
27	1	C20626-000	STAND SLED	21790-005_8
28	1	C20848-003	PNEUMATIC LIFT THREADED ROD	21790-005_8
29	1	HCS281		21790-005_8
30	1	SON022		21790-005_8


B	Sep-16-25	IGUS CHANGED TO COLLAR	TAZ
A	Aug-01-24	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .01 XX ± .01 XXX ± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		QUADREL LABELING SYSTEMS	
		7670 JENTHER DRIVE	
		MENTOR, OHIO 44060	
		(440) 602-4700	
		SCALE: 1/4 DATE: Aug-01-24 DRW BY: TAZ CHK BY: &CREO.CHK APPR BY:	
PNEUMATIC LIFT KIT			
MAT'L		21790-005	







THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
REV	A	Aug-01-24	NEW DRAWING
	DATE	DESCRIPTION	BY
UNLESS OTHERWISE SPECIFIED		SCALE: 9/32	
DIMENSIONAL TOLERANCE		DATE: Aug-01-24	
XX ± .01		DRW BY: TAZ	
XXX ± .005		CHK BY:	
ANGLES ± 90°		APPR BY:	
SURFACE FINISH 125		PNEUMATIC LIFT KIT	
BREAK ALL EDGES .005/ .015		MAT'L	
CORNER RADIUS .010/ .030		21790-005	
ALL ANGLES ARE 90°		21790-005	

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	141172-000	SLEEVE BEARING	22173-600
2	1	141177-000	SLEEVE BEARING	22173-600
3	2	181108-000	BEARING, NEEDLE ROLLER	22173-600
4	4	181111-000	THRUST WASHER	22173-600
5	1	362186-000	COLLAR, 3/8 IN. ID ONE-PIECE CLAMP	22173-600
6	1	791914-001_10	MYLAR SCALE, QUADREL LOGO	22173-600
7	4	792248-001	PILLOW BLOCK	22173-600
8	1	792354-000	DIGITAL POSITION INDICATOR	22173-600
9	1	792355-000	DRYLIN RAIL	22173-600
10	1	801080-000	HANDLE WHEEL, MODIFIED	22173-600
11	1	A24077-000	BRONZE NUT, RH	22173-600
12	1	B20045-111	THREADED ROD	22173-600
13	1	B21346-000	BOTTOM BEARING PLATE	22173-600
14	1	B22005-012	BEARING PLATE	22173-600
15	1	C20626-600	STAND SLED	22173-600




B	Sep-30-22	WAS C20977-113	TAZ
A	20-DEC-2016	NEW DRAWING	
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .01 XX ± .005 ANGLES ± .30°	QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700		SCALE 3/4
			DATE 20-DEC-2016
			DRAWN BY CRT
SURFACE FINISH .125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		VERTICAL IGUS SLIDE, 17.5"	
MAT'L		22173-600	22173-600



		A	20-DEC-2016	NEW DRAWING	
		REV	DATE	DESCRIPTION	BY
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± 30° SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADII .010/ .030	QUADREL LABELING SYSTEMS			SCALE	3/4
	7670 JENTHER DRIVE			DATE	20-DEC-2016
	MENTOR, OHIO 44060			DRAWN BY	CRT
	(440) 602-4700				
		VERTICAL IGUS SLIDE, 17.5"			
MAT'L		22173-600		22173-600	



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	141172-000	SLEEVE BEARING, 1/20D. x 3/8ID. x 3/4LNG	22914-000
2	4	792248-001	PILLOW BLOCK	22914-000
3	2	792276-000	DRYLIN RAIL	22914-000
4	2	A20904-000	RAIL SPACER, 1/2"	22914-000
5	1	B21529-000	OUTER BEARING PLATE	22914-000
6	1	B21530-002	INNER BEARING PLATE	22914-000
7	1	C20753-006	HORIZONTAL SLED, WIDE VERSION	22914-000
8	4	C21327-002		22914-000
9	1	C21530-000	SLED SUPPORT PLATE	22914-000

A	Sep-15-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE





$.XX \pm .01$
 $.XXX \pm .005$
ANGLES $\pm .50^\circ$

SURFACE FINISH 125
BREAK ALL EDGES .005/ .015
CORNER RADIUS .010/ .030
ALL ANGLES ARE 90°

QUADREL LABELING SYSTEMS
7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700


SCALE: 1/2
DATE: Sep-15-25
DRW BY: TAZ
CHK BY:
APPR BY:

SLED ADAPTER ASSEMBLY		
MAT'L	22914-000	22914-000



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 13/32	
X ± .1		DATE: Sep-15-25	
XX ± .01		DRW BY: TAZ	
XXX ± .005		CHK BY:	
ANGLES ± .00°		APPR BY:	
SURFACE FINISH 125		SLED ADAPTER ASSEMBLY	
BREAK ALL EDGES .005/ .015		MATERIAL	
CORNER RADIUS .010/ .030		22914-000	
ALL ANGLES ARE 90°		22914-000	

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	801850-000	CLAMPING LEVER	22816-012
2	2	B21190-200	YOKE SIDE PLATE	22816-012
3	1	B21555-121	MTG YOKE BACK PLATE	22816-012







A	Aug-06-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/2	
XX ± .01		DATE: Aug-06-25	
XXX ± .005		DRW BY: TAZ	
ANGLES ± 90°		CHK BY:	
SURFACE FINISH 125		APPR BY:	
BREAK ALL EDGES .005/ .015		Q125 YOKE	
CORNER RADIUS .010/ .030		MATERIAL	
ALL ANGLES ARE 90°		22816-012	
		22816-012	




7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700








THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/2	
X ± .1		DATE: Aug-06-25	
XX ± .01		DRW BY: TAZ	
XXX ± .005		CHK BY:	
ANGLES ± .00°		APPR BY:	
SURFACE FINISH 125		Q125 YOKE	
BREAK ALL EDGES .005/ .015		MATERIAL	
CORNER RADIUS .010/ .030		22816-012	
ALL ANGLES ARE 90°		22816-012	

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	793045-000	DIAMOND KNURL KNOB	22824-007
2	1	A26179-007	KNOB STUD	22824-007
3	1	C21348-400	ADJUSTMENT PLATE	22824-007




A	Sep-16-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30 SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADII .010/.030 ALL ANGLES ARE 90°		QUADREL LABELING SYSTEMS	
		7670 JENTHER DRIVE	
		MENTOR, OHIO 44060	
		(440) 602-4700	
			SCALE: 1/1
			DATE: Sep-16-25
			DRW BY: TAZ
		CHK BY:	
		APPR BY:	
ADJUSTMENT BLOCK ASSEMBLY			
MAT'L		22824-007	22824-007



A	Sep-16-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

<div>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE $\begin{matrix} X \pm .1 \\ XX \pm .01 \\ XXX \pm .005 \end{matrix}$ ANGLES $\pm 30^\circ$ SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030 ALL ANGLES ARE 90°</div>	<div><div>QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700</div></div>	SCALE: 1/1
		DATE: Sep-16-25
		DRW BY: TAZ
		CHK BY:
		APPR BY:
		ADJUSTMENT BLOCK ASSEMBLY
MAT'L	22824-007	22824-007

7.4 PACING WHEEL / BELT ASSEMBLY

7.4.1 GENERAL INFORMATION

The pacing wheel/belt are an optional module that is generally placed at the entrance of the conveyor to allow adequate spacing of products as they travel towards the labeling head. The speed of the wheel/belt will vary how much spacing is created between the products. It is controlled by a DC motor and DC drive located in the electrical enclosure.

7.4.2 ADJUSTMENTS

The adjustments for both assemblies are fairly straight forward. The pacing wheel assembly has a pivoting in and out adjustment and height adjustment. The pivot in and out adjustment is made by loosening the ratcheting handle on the mount and rotating the assembly as needed.





The vertical adjustment for the pacing wheel is achieved by loosening the collar on the shaft then loosening the ratchet handle and manually pull up or push down as needed. The height is locked in place with the lock collar. Tighten the ratchet handle when finished.



CAUTION

Do not make any adjustments when assembly or conveyor are running.

The pacing belt assembly has both vertical and horizontal adjustments. To adjust vertically loosen the 2 3/8-16 bolts and pull up on the assembly. To adjust horizontally (in and out) loosen the 2 ratchet handles under the assembly and slide in and out as needed.



ASSEMBLY TITLE: SERVO ORIENTING BELTS

GENERAL FUNCTION:

- The servo orienting belts are used to orient a product to the labeler so that the products are all facing the same way for label application. A photo eye is mounted at the hugger assemblies to detect the presence of a product.
-

SET UP AND ADJUSTMENTS:

- The hugger assembly is adjusted horizontally by rotating the handle clockwise or counter-clockwise to fit the product. Ensure there is a firm grip on the product but not so much as to distort the product surface.
- Product should enter and exit smoothly. Adjust guide rails and belt pressure accordingly.
- Belt tension should be set to remove belt backlash only. Do not over tighten belt or belt delamination will occur.

MAINTENANCE:


- Keep the hugger belts free of discarded labels and debris. This will allow for free product movement.
- When not using assembly for a period of time longer than a shift, more than 8 hours, rotate the belts so the belt seams are not on a pulley (Seam Bending open) This will dramatically improve the life of the belts.

TROUBLESHOOTING:

PROBLEM	WHAT TO DO
Belt delamination	Replace belt Always store system with belt seams not on a pulley. (See Maintenance)
Belt does not rotate	Check Servo drive for Fault Code and correct fault error.
Belts do not rotate	Check to see if function is enabled in Recipe. Check Servo drives for fault codes

CAUTION:





- **Before performing any maintenance or cleaning make sure the system is powered down.**
- **Pressing the E-Stop disables the servo drives.**



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	8	111073-000	BEARING, BALL	22643-84187
2	2	141177-000	SLEEVE BEARING, 5/8OD. x 1/2ID. x 3/4LNG	22643-84187
3	8	151003-000	BEARING, THRUST WASHER	22643-84187
4	4	181079-000	BEARING, NEEDLE ROLLER	22643-84187
5	8	181080-000	BEARING, THRUST WASHER	22643-84187
6	2	181108-000	BEARING, NEEDLE ROLLER	22643-84187
7	4	181111-000	THRUST WASHER	22643-84187
8	2	193397-007	TIMING BELT	22643-84187
9	2	361169-000	COLLAR, 1/2 IN. ID ONE-PIECE CLAMP	22643-84187
10	1	362164-000	COUPLING, ONE PIECE CLAMP-ON	22643-84187
11	2	412178-000	GEARMOTOR,AC,283 RPM,1/6 HP	22643-84187
12	8	792248-001	PILLOW BLOCK	22643-84187
13	1	792354-000	DIGITAL POSITION INDICATOR	22643-84187
14	2	793023-100	DRYLIN RAIL	22643-84187
15	1	801332-000	LOBE KNOB W/ ORANGE CENTER	22643-84187
16	4	A20904-200	RAIL SPACER, 5/8	22643-84187
17	1	A25120-000	BRONZE NUT, RH	22643-84187
18	1	A25121-000	BRONZE NUT, LH	22643-84187
19	4	A25350-000	IDLER SHAFT	22643-84187
20	4	A25351-000	IDLER PULLEY, 1/5P 20 GROOVE	22643-84187
21	2	A25351-007	IDLER PULLEY, 1/5P 20 GROOVE	22643-84187
22	4	A25353-005	DRIVE PULLEY FLANGE	22643-84187
23	2	A25354-007	BACK UP GUIDE PLATE	22643-84187
24	4	A25355-000	SPACER	22643-84187
25	2	A26238-001	MOTOR MOUNTING PLATE	22643-84187
26	1	B21346-005	BOTTOM BEARING PLATE	22643-84187
27	1	B22005-001	BEARING PLATE	22643-84187
28	2	B22104-030	MOUNTING ANGLE	22643-84187
29	1	C20910-152	THREADED ROD	22643-84187
30	1	C20910-153	THREADED ROD	22643-84187
31	2	C21059-200	HUGGER TOP PLATE	22643-84187
32	2	C21060-101	WRAP BOTTOM PLATE	22643-84187
33	2	C21293-111	HUGGER BELT MOUNTING PLATE	22643-84187
34	2	C21293-186	MOUNTING PLATE	22643-84187


A	Jul-14-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .01 XX ± .005 XXX ± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700 SCALE: 11/32 DATE: Jul-14-25 DRW BY: TAZ CHK BY: 09/19/2025-SEM APPR BY: DUAL AC MOTOR HUGGER BELT	
SHEET 1 OF 2		MAT'L 22643-84187	22643-84187



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/2	
XX ± .01	XX ± .005	DATE: Jul-14-25	
ANGLES ± 90°		DRW BY: TAZ	
SURFACE FINISH 125		CHK BY: 09/19/2025-SEM	
BREAK ALL EDGES .005/ .015		APPR BY:	
CORNER RADIUS .010/ .030			
ALL ANGLES ARE 90°			



QUADREL LABELING SYSTEMS
7670 JENTER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

DUAL AC MOTOR HUGGER BELT	
MAT'L	22643-84187
22643-84187	

7.7 TOP HOLD DOWN ASSEMBLY

7.7.1 GENERAL INFORMATION

The top hold down module is a motor driven spring loaded belt that applies overhead pressure to the containers and enables the product to remain stable as the label is applied. This assembly is powered by an AC motor or servo motor. Ideal for front / back or single side applications.

7.7.2 ADJUSTMENTS

Adjusting the height of the top hold down is achieved by turning the hand wheel on the top of the assembly counter clockwise or clockwise.



ASSEMBLY TITLE:

TOP TRAP ASSEMBLY

GENERAL FUNCTION:

- As a product enters the label application area near the labeling head, it needs additional support to prevent it from being upset as a label is applied. A product hold down conveyor or more commonly known as a "top trap" is used to provide product support.

The speed of the top trap is set to match the speed of the conveyor and is encoder matched to follow conveyor speed changes.

SETUP AND ADJUSTMENTS:

- Place the product to be labeled under the top trap. Loosen clamp lever and turn the **hand wheel** so that the rubber belt of the top trap compresses the product slightly.
- When the desired height is achieved, tighten the clamp lever.
- **The top trap is spring loaded to accommodate products that vary in height slightly.**
- Top trap belt tension can be adjusted by tightening or loosening the set screws at the infeed end of the top trap.

MAINTENANCE:

- No maintenance is required except for an occasional belt replacement.

TROUBLESHOOTING:


PROBLEM

- Top trap jumping teeth
- Too much pressure on product
- Top trap not moving
- Top trap swaying under load.

WHAT TO DO

- Tighten top trap belt
- Raise top trap
- Check drive belts and replace if broken.
- Tighten clamp lever. Tighten pulleys and shafts.





ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	4	111074-000	BEARING, BALL	84187TT-000
2	2	111075-000	BEARING, BALL	84187TT-000
3	2	151006-000	BEARING, THRUST WASHER	84187TT-000
4	2	151008-000	BEARING, THRUST WASHER	84187TT-000
5	1	412173-000	GEARMOTOR; 3/8 HP 170RPM 3PH AC	84187TT-000
6	1	791975-001	R-CLIP	84187TT-000
7	25	811256-000	COMPRESSION SPRING	84187TT-000
8	2	871025-000	EXTERNAL RETAINING RING	84187TT-000
9	1	A21578-120	TOP TRAP COVER PLATE	84187TT-000
10	1	A21578-121	TOP TRAP COVER PLATE	84187TT-000
11	1	A21823-000	IDLER SHAFT	84187TT-000
12	1	A21824-200	CROWNED IDLER PULLEY	84187TT-000
13	1	A21826-216	DRIVE PULLEY, 5/8" SHAFTS	84187TT-000
14	1	A21830-201	TOP TRAP BELT	84187TT-000
15	2	A23403-000	FLANGE	84187TT-000
16	1	A23731-005	MOTOR MTG. PLATE	84187TT-000
17	2	A26084-121	COVER	84187TT-000
18	2	A26203-000	ROLLER SHAFT	84187TT-000
19	2	A26204-000	ROLLER	84187TT-000
20	1	B21769-120	TOP TRAP SPACER	84187TT-000
21	25	B22784-000	SPRING BLOCK STEM	84187TT-000
22	25	B22785-000	SPRING BLOCK PLATE	84187TT-000
23	1	C21268-734	OUTSIDE TOP TRAP PLATE	84187TT-000
24	1	C21268-744	INSIDE TOP TRAP PLATE	84187TT-000
25	1	D24415-120	SPRING BLOCK MOUNTING CHANNEL	84187TT-000

NOT SHOWN:
A21830-201 TOP TRAP BELT

A	Nov-03-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE

X ± .01
XX ± .01
XXX ± .005
ANGLES ± .30°

SURFACE FINISH 125
BREAK ALL EDGES .005/.015
CORNER RADIUS .010/.030





QUADREL LABELING SYSTEMS

7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700


SCALE: 1/4
DATE: Nov-03-25
DRW BY: TAZ
CHK BY:
APPR BY:

PROLINE TOP TRAP

MAT'L 84187TT-000 84187TT-000



A	Nov-03-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
<div>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .00° SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°</div>		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
		SCALE: 5/16	
		DATE: Nov-03-25	
		DRW BY: TAZ	
		CHK BY:	
		APPR BY:	
		PROLINE TOP TRAP	
MAT'L		84187TT-000	84187TT-000







ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	141172-000	SLEEVE BEARING, 1/20D. x 3/8ID. x 3/4LNG	22867-00
2	1	141177-000	SLEEVE BEARING, 5/80D. x 1/2ID. x 3/4LNG	22867-00
3	2	181108-000	BEARING, NEEDLE ROLLER	22867-00
4	4	181111-000	THRUST WASHER	22867-00
5	1	362186-000	COLLAR, 3/8 IN. ID ONE-PIECE CLAMP	22867-00
6	2	729006-000	CAP INSERT FOR 2 X 4 TUBE	22867-00
7	4	792248-001	PILLOW BLOCK	22867-00
8	1	792354-002	DIGITAL POSITION INDICATOR	22867-00
9	1	793035-001	DRYLIN RAIL	22867-00
10	1	801080-000	6" HANDWHEEL	22867-00
11	1	A24077-000	BRONZE NUT, RH	22867-00
12	1	B20045-200	THREADED ROD	22867-00
13	1	B21346-000	BOTTOM BEARING PLATE	22867-00
14	1	B22005-012	BEARING PLATE	22867-00
15	1	B22790-002	TOP PACING CONNECTOR PLATE	22867-00
16	1	B22791-010	TOP TRAP SPACER	22867-00
17	1	B22791-011	TOP TRAP SPACER	22867-00
18	1	B22791-012	TOP TRAP SPACER	22867-00
19	1	C21292-001	TOP TRAP RISER	22867-00
20	1	C21293-001	TOP TRAP MOUNTING PLATE	22867-00
21	2	C21293-83516_	TOP TRAP MOUNTING PLATE	22867-00

A	22-AUG-2024	NEW DRAWING	CRT
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .01 XXX ± .005 ANGLES ± .30°		SCALE: 0.313 DATE: 22-AUG-2024 DRW BY: CRT CHK BY: 08/22/2024-SEM APPR BY:	
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		TOP PACING UPRIGHT ASSEMBLY, 2" W CONVEYORS	
MAT'L		22867-00	




QUADREL LABELING SYSTEMS
7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700




THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 0.250	
X ± .1		DATE: 08/27/24	
XX ± .01		DRW BY: CRT	
XXX ± .005		CHK BY: 08/22/2024-SEM	
ANGLES ± .30°		APPR BY:	
SURFACE FINISH 125		TOP PACING UPRIGHT ASSEMBLY, 2" W CONVEYORS	
BREAK ALL EDGES .005/.015		MAT'L	
CORNER RADIUS .010/.030		22867-00	

A	08/28/24	NEW DRAWING	CRT
REV	DATE	DESCRIPTION	BY






QUADREL LABELING SYSTEMS
7670 JENTER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	111072-000	BEARING, BALL	22667-000
2	1	322180-001	SPROCKET	22667-000
3	1	322193-001	SPROCKET	22667-000
4	1	361127-000_82719	ROLLER CHAIN, 1/2" PITCH 44 LINKS	22667-000
5	1	361127-001	MASTER LINK, 1/2" PITCH	22667-000
6	1	413006-000	GEARMOTOR, 3/8HP 85RPM 230VAC	22667-000
7	1	B22609-003	MOTOR MOUNTING PLATE	22667-000
8	1	B22610-003	GUARD	22667-000




A		Apr-11-25	NEW DRAWING	RDL
REV	DATE	DESCRIPTION	BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY				
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		QUADREL LABELING SYSTEMS 7670 JENTER DRIVE MENTOR, OHIO 44060 (440) 602-4700		SCALE: 1/2 DATE: Apr-11-25 DRW BY: RDL CHK BY: 04/16/2025-SEM APPR BY:
X ± .1 XX ± .01 XXX ± .005 ANGLES ± .00°		SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		
MOTORIZED LIFT			22667-000	
MAT'L				







THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY	
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE $\begin{matrix} X \pm .1 \\ Y \pm .01 \\ X \pm .005 \\ \text{ANGLES} \pm 30^\circ \end{matrix}$ SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030 ALL ANGLES ARE 90°	 7670 JENTER DRIVE MENTOR, OHIO 44060 (440) 602-4700
QUADREL LABELING SYSTEMS MOTORIZED LIFT	
MAT'L	SCALE: 5/8 DATE: Apr-11-25 DRW BY: RDL CHK BY: 04/16/2025-SEM APPR BY:
	22667-000

SHEET 2 OF 2

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	801308-000	KNOB W/ 1/4-20 STUD	84187FT-000
2	2	A20875-000	RETAINER BLOCK, CONV. RAIL	84187FT-000
3	2	A20876-000	RETAINER BLOCK	84187FT-000
4	1	A21198-000	ADJUSTMENT ROD	84187FT-000
5	1	A21198-120	ADJUSTMENT ROD	84187FT-000
6	1	A24968-002		84187FT-000




A	Aug-06-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/1	
XX ± .01		DATE: Aug-06-25	
XXX ± .005		DRW BY: TAZ	
ANGLES ± .00°		CHK BY:	
SURFACE FINISH 125		APPR BY:	
BREAK ALL EDGES .005/ .015		FOLD TOOLING LEFT HAND	
CORNER RADIUS .010/ .030		MAT'L	
ALL ANGLES ARE 90°		84187FT-000	
		84187FT-000	




THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/2	
xxx ± .01		DATE: Aug-06-25	
xxx ± .005		DRW BY: TAZ	
ANGLES ± 90°		CHK BY:	
SURFACE FINISH 125		APPR BY:	
BREAK ALL EDGES .005/ .015		FOLD TOOLING LEFT HAND	
CORNER RADIUS .010/ .030		MAT'L 84187FT-000	
ALL ANGLES ARE 90°		84187FT-000	





ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	801308-000	KNOB W/ 1/4-20 STUD	84187FT-001
2	2	A20875-000	RETAINER BLOCK, CONV. RAIL	84187FT-001
3	2	A20876-000	RETAINER BLOCK	84187FT-001
4	1	A21198-000	ADJUSTMENT ROD	84187FT-001
5	1	A21198-120	ADJUSTMENT ROD	84187FT-001
6	1	A24968-003		84187FT-001



A	Aug-06-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE XX ± .1 XXX ± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030 ALL ANGLES ARE 90°		QUADREL LABELING SYSTEMS		SCALE: 1/1
		7670 JENTHER DRIVE		DATE: Aug-06-25
		MENTOR, OHIO 44060		DRW BY: TAZ
		(440) 602-4700		CHK BY:
		FOLD TOOLING RIGHT HAND		APPR BY:
MAT'L		84187FT-001	84187FT-001	



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/2	
X ± .1		DATE: Aug-06-25	
XX ± .01		DRW BY: TAZ	
XXX ± .005		CHK BY:	
ANGLES ± .00°		APPR BY:	
SURFACE FINISH 125		FOLD TOOLING RIGHT HAND	
BREAK ALL EDGES .005/ .015		MAT'L	
CORNER RADIUS .010/ .030		84187FT-001	
ALL ANGLES ARE 90°		84187FT-001	

Items: 22442SN-000 Thru 22442SN-000 Location: 01 QUADREL WHSE

Activity Codes: Active Items Only

1 Levels With No Blow Through

No Selection On Basis Of Effectivity Date No Selection On Basis Of Obsolete Date

Level	Seq	Component-Item	Component-Description	Loc	Opr	UOM	Scrap	Act	Stk	B/I	Qty	On-Hand	Qty-Per-Parent
					LLC	Draw	REV	P/M	Ctl	B/F	Qty-Allocated		Qty-On-Order
=====													
Parent Item: 22442SN-000		SENSOR KIT, TOP TRAP LIFT			Loc: 01	LLC: 1							
		LASER, PROX, CABLES											
1	5	203376-002	SENSOR, LASER DISTANCE, 0-10V		0	EA	.0	A	Y	N			1.000000
		"BANNER" Q4XTULAF500-Q8		01	6				Y	N			
1	10	202161-001	CABLE, M12, 4P, FEM, 5m		0	EA	.0	A	Y	N			1.000000
		"LUMBERG" RKT4-633/5M ****		01	6				P	Y	N		
1	15	202206-002	PROX, INDUCTIVE, NC, M8, 45mm		0	EA	.0	A	Y	N			2.000000
		"CONTRINEX" DW-AS-614-M8-001 *		01	3				P	Y	N		
1	20	202089-001	PROX MTG BRKT 8mm CLAMP STYLE		0	EA	.0	A	Y	N			2.000000
		"BALLUFF" BAM00A2		01	5				P	Y	N		
1	25	202624-001	CABLE, M8, 3 PIN, 5m		0	EA	.0	A	Y	N			2.000000
		"TURCK" PKG3M-5/S760		01	6				P	Y	N		
1	30	252019-000	CONNECTOR, M12, 4P, MALE		0	EA	.0	A	Y	N			3.000000
		"LUMBERG" RSC4/7		01	10				P	Y	N		

A28456-001 MTG BLOCK FOR SENSOR

Q4X Stainless Steel Laser Sensor



Quick Start Guide

Class 1 laser CMOS sensor with a discrete (PNP or NPN) output. Patent pending.

This guide is designed to help you set up and install the Q4X Sensor. For complete information on programming, performance, troubleshooting, dimensions, and accessories, please refer to the Instruction Manual at www.bannerengineering.com. Search for p/n 181483 to view the Instruction Manual. Use of this document assumes familiarity with pertinent industry standards and practices.

For illustration purposes, the threaded barrel model Q4X images are used throughout this document.



WARNING: Not To Be Used for Personnel Protection

Never use this device as a sensing device for personnel protection. Doing so could lead to serious injury or death. This device does not include the self-checking redundant circuitry necessary to allow its use in personnel safety applications. A sensor failure or malfunction can cause either an energized or de-energized sensor output condition.

Features




Figure 1. Sensor Features—Threaded Barrel Models




Figure 2. Sensor Features—Flush Mount Models

Display and Indicators

The display is a 4-digit, 7-segment LED. The main screen is the Run mode screen.

For 2-pt, BGS, FGS, and DYN TEACH modes, the display shows the current distance to the target in millimeters. For dual TEACH mode, the display shows the percentage matched to the taught reference surface. A display value of **9999** indicates the sensor has not been taught.




Figure 3. Display in Run Mode

1. Stability Indicator (STB—Green)
2. Active TEACH Indicators
 - DYN—Dynamic (Amber)
 - FGS—Foreground Suppression (Amber)
 - BGS—Background Suppression (Amber)

Output Indicator

- On—Outputs conducting (closed)
- Off—Outputs not conducting (open)

Active TEACH Indicators (DYN, FGS, and BGS)

- DYN, FGS, and BGS all off—Two-point TEACH mode selected (default)
- DYN on—Dynamic TEACH mode selected
- FGS on—Foreground suppression TEACH mode selected
- BGS on—Background suppression TEACH mode selected
- DYN, FGS, and BGS all on—Dual TEACH mode selected


Stability Indicator (STB)

- On—Stable signal within the specified sensing range
- Flashing—Marginal signal, the target is outside the limits of the specified sensing range, or a multiple peak condition exists
- Off—No target detected within the specified sensing range



Buttons

Use the sensor buttons (SELECT)(TEACH), (+)(DISP), and (-)(MODE) to program the sensor.



(SELECT)(TEACH)

- Press to select menu items in Setup mode
- Press and hold for longer than 2 seconds to start the currently selected TEACH mode (the default is two-point TEACH)

(+)(DISP)

- Press to navigate the sensor menu in Setup mode
- Press to change setting values; press and hold to increase numeric values
- Press and hold for longer than 2 seconds to switch between light operate (LO) and dark operate (DO)

(-)(MODE)

- Press to navigate the sensor menu in Setup mode
- Press to change setting values; press and hold to decrease numeric values
- Press and hold for longer than 2 seconds to enter Setup mode

Note: When navigating the menu, the menu items loop.

Laser Description and Safety Information



CAUTION: Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure. Do not attempt to disassemble this sensor for repair. A defective unit must be returned to the manufacturer.

Class 1 Lasers

Class 1 lasers are lasers that are safe under reasonably foreseeable conditions of operation, including the use of optical instruments for intrabeam viewing.

COMPLIES WITH 21 CFR 1040.10 AND 1040.11
EXCEPT FOR DEVIATIONS PURSUANT TO
LASER NOTICE No. 50, DATED JUNE 24, 2007.
BANNER ENGINEERING CORP.
9714 10TH AVENUE NORTH
MINNEAPOLIS, MN 55441

CLASS 1
LASER PRODUCT

COMPLIES WITH IEC 60825-1:2007

Laser wavelength: 655 nm

Output: < 0.20 mW

Pulse Duration: 7 μ s to 2 ms

Installation

Install the Safety Label

The safety label must be installed on Q4X sensors that are used in the United States.



Note: Position the label on the cable in a location that has minimal chemical exposure.

1. Remove the protective cover from the adhesive on the label.
2. Wrap the label around the Q4X cable, as shown.
3. Press the two halves of the label together.




Figure 4. Safety Label Installation

Sensor Orientation

Optimize detection reliability and minimum object separation performance with correct sensor-to-target orientation. To ensure reliable detection, orient the sensor as shown in relation to the target to be detected.




Figure 5. Optimal Orientation of Target to Sensor

See the following figures for examples of correct and incorrect sensor-to-target orientation as certain placements may pose problems for sensing some targets. The Q4X can be used in the less preferred orientation and provide reliable detection performance; refer to the *Performance Curves* for the minimum object separation distance required for each case.




Figure 6. Orientation by a wall




Figure 7. Orientation for a turning object




Figure 8. Orientation for a height difference





Figure 9. Orientation for a color or luster difference


Mount the Sensor

1. If a bracket is needed, mount the sensor onto the bracket.
2. Mount the sensor (or the sensor and the bracket) to the machine or equipment at the desired location. Do not tighten the mounting screws at this time.
3. Check the sensor alignment.
4. Tighten the mounting screws to secure the sensor (or the sensor and the bracket) in the aligned position.

Wiring Diagram—Threaded Barrel Models



Note: Open lead wires must be connected to a terminal block.




Key

- 1 = Brown
- 2 = White
- 3 = Blue
- 4 = Black
- 5 = Gray



Note: The input wire function is user-selectable; see the Instruction Manual for details. The default for the input wire function is off (disabled).

Wiring Diagram—Flush Mount Models



Note: Open lead wires must be connected to a terminal block.



Note: The input wire function is user-selectable; see the Instruction Manual for details. The default for the input wire function is off (disabled).

Cleaning and Maintenance

Handle the sensor with care during installation and operation. Sensor windows soiled by fingerprints, dust, water, oil, etc. may create stray light that may degrade the peak performance of the sensor. Blow the window clear using filtered, compressed air, then clean as necessary using water and a lint-free cloth.

Sensor Programming

Program the sensor using the buttons on the sensor or the remote input (limited programming options).

In addition to programming the sensor, use the remote input to disable the buttons for security, preventing unauthorized or accidental programming changes. See the Instruction Manual, p/n 181483 for more information.

Setup Mode

Access Setup mode and the sensor menu from Run mode by pressing and holding **MODE** for longer than 2 seconds. Use \oplus and \ominus to navigate through the menu. Press **SELECT** to select a menu option and access the submenus. Use \oplus and \ominus to navigate through the submenus. Press **SELECT** to select a submenu option and return to the top menu, or press and hold **SELECT** for longer than 2 seconds to select a submenu option and return immediately to Run mode.

To exit Setup mode and return to Run mode, navigate to **End** and press **SELECT**.




Figure 10. Sensor Menu Map—Channel 1

Basic TEACH Instructions

Use the following instructions to teach the Q4X sensor. The instructions provided on the sensor display vary depending on the type of TEACH mode selected. Two-point TEACH is the default TEACH mode.

1. Press and hold **TEACH** for longer than 2 seconds to start the selected TEACH mode.
2. Present the target.
3. Press **TEACH** to teach the target. The target is taught and the sensor waits for the second target, if required by the selected TEACH mode, or returns to Run mode.

Complete steps 4 and 5 only if required for the selected TEACH mode:

4. Present the second target.
5. Press **TEACH** to teach the target. The target is taught and the sensor returns to Run mode.


See the Instruction Manual for detailed instructions and other available TEACH modes. The TEACH modes include:


- Two-point static background suppression $\overline{2-Pl}$ —Two-point TEACH sets a single switch point. The sensor sets the switch point between two taught target distances, relative to the shifted origin location.
- Dynamic background suppression \overline{dyn} —Dynamic TEACH sets a single switch point during machine run conditions. The sensor takes multiple samples and the switch point is set between the minimum and the maximum sampled distances.
- One-point window (foreground suppression) \overline{FGS} —One-point window sets a window (two switch points) centered around the taught target distance.
- One-point background suppression \overline{BGS} —One-point background suppression sets a single switch point in front of the taught target distance. Objects beyond the taught switch point are ignored.
- Dual intensity + distance \overline{dual} —Dual mode records the distance and amount of light received from the reference surface. See *Dual Mode Reference Surface Considerations* on page 10 for more information about selecting a reference surface. The output switches when an object passing between the sensor and the reference surface changes the perceived distance or amount of returned light.

Manual Adjustments

Manually adjust the sensor switch point using the \oplus and \ominus buttons.

1. From Run mode, press either \oplus or \ominus one time. The current switch point value flashes slowly.
2. Press \oplus to move the switch point up or \ominus to move the switch point down. After 1 second of inactivity, the new switch point value flashes rapidly, the new setting is accepted, and the sensor returns to Run mode.

 **Note:** When FGS mode is selected (FGS indicator is on), manual adjustment moves both sides of the symmetrical threshold window simultaneously, expanding and collapsing the window size. Manual adjustment does not move the center point of the window.


 **Note:** When dual mode is selected (DYN, FGS, and BGS indicators are on), after the TEACH process is completed, use the manual adjustment to adjust the sensitivity of the thresholds around the taught reference point. The taught reference point is a combination of the measured distance and returned signal intensity from the reference target.

Manual adjustment does not move the taught reference point, but pressing \oplus increases the sensitivity, and pressing \ominus decreases the sensitivity. When re-positioning the sensor or changing the reference target, re-teach the sensor.

Light Operate/Dark Operate

The default output configuration is light operate. To switch between light operate and dark operate, use the following instructions:

1. Press and hold **LO/DO** for longer than 2 seconds. The current selection displays.
2. Press **LO/DO** again. The new selection flashes slowly.
3. Press **SELECT** to change the output configuration and return to Run mode.

 **Note:** If neither **SELECT** nor **LO/DO** are pressed after step 2, the new selection flashes slowly for a few seconds, then flashes quickly and the sensor automatically changes the output configuration and returns to Run mode.

Locking and Unlocking the Sensor Buttons

Use the lock and unlock feature to prevent unauthorized or accidental programming changes. Three settings are available:

- \overline{ULOC} —The sensor is unlocked and all settings can be modified (default).
- \overline{LOC} — The sensor is locked and no changes can be made.

- **OLoc** —The switch point value can be changed by teaching or manual adjustment, but no sensor settings can be changed through the menu.

When in **Loc** mode, **Loc** displays when the **(SELECT)(TEACH)** button is pressed. The switch point displays when **(+)(DISP)** or **(-)(MODE)** are pressed, but **Loc** displays if the buttons are pressed and held.

When in **OLoc** mode, **Loc** displays when **(+)(DISP)** or **(-)(MODE)** are pressed and held. To access the manual adjust options, briefly press and release **(+)(DISP)** or **(-)(MODE)**. To enter TEACH mode, press the **(SELECT)(TEACH)** button and hold for longer than 2 seconds.

To enter **Loc** mode, hold \oplus and press \ominus four times. To enter **OLoc** mode, hold \oplus and press \ominus seven times. Holding \oplus and pressing \ominus four times unlocks the sensor from either lock mode and the sensor displays **OLoc**.

Specifications

Sensing Beam

Visible red Class 1 laser, 655 nm

Supply Voltage (Vcc)

10 to 30 V dc

Power and Current Consumption, exclusive of load
< 675 mW

Sensing Range—Threaded Barrel Models

500 mm models: 25 mm to 500 mm (0.98 in to 19.69 in)
300 mm models: 25 mm to 300 mm (0.98 in to 11.81 in)
100 mm models: 25 mm to 100 mm (0.98 in to 3.94 in)

Sensing Range—Flush Mount Models

310 mm models: 35 mm to 310 mm (1.38 in to 12.20 in)
110 mm models: 35 mm to 110 mm (1.38 in to 4.33 in)

Output Configuration

Threaded Barrel Models: Bipolar (1 PNP and 1 NPN) output
Flush Mount Models: PNP or NPN output, depending on model

Output Rating

100 mA total maximum (protected against continuous overload and short circuit)

Off-state leakage current: < 5 μ A at 30 V dc

PNP On-state saturation voltage: < 1.5 V dc at 100 mA load

NPN On-state saturation voltage: < 1.0 V dc at 100 mA load

Discrete Output Distance Repeatability

Table 1: Beam Spot Size—300/310 mm and 500 mm Models

Distance (mm)		Repeatability
Threaded Barrel Models	Flush Mount Models	
25 to 50 mm	35 to 60 mm	± 0.5 mm
50 to maximum range	60 to 310 mm	$\pm 1\%$ of range

Table 2: Beam Spot Size—100/110 mm Models

Distance (mm)		Repeatability
Threaded Barrel Models	Flush Mount Models	
25 to 100 mm	35 to 110 mm	± 0.2 mm

Remote Input

Allowable Input Voltage Range: 0 to Vcc

Active Low (Internal weak pullup—sinking current): Low State < 2.0 V at 1 mA max.

Supply Protection Circuitry

Protected against reverse polarity and transient overvoltages

Response Speed

User selectable:

- **15** —1.5 milliseconds
- **3** —3 milliseconds
- **10** —10 milliseconds
- **25** —25 milliseconds
- **50** —50 milliseconds

Excess Gain—Threaded Barrel Models

Table 3: HIGH Excess Gain (Std Excess Gain¹)

Response Speed (ms)	Excess Gain—90% White Card			
	at 25 mm	at 100 mm	at 300 mm	at 500 mm
1.5	200	100	20	7
3	200	100	20	7
10	1000 (500)	500 (250)	100 (50)	36 (18)
25	2500 (1000)	1250 (500)	250 (100)	90 (36)
50	5000 (2500)	2500 (1250)	500 (250)	180 (90)

Excess Gain—Flush Mount Models

Table 4: HIGH Excess Gain (Std Excess Gain²)

Response Speed (ms)	Excess Gain—90% White Card		
	at 35 mm	at 110 mm	at 310 mm
1.5	200	100	20
3	200	100	20
10	1000 (500)	500 (250)	100 (50)
25	2500 (1000)	1250 (500)	250 (100)
50	5000 (2500)	2500 (1250)	500 (250)

1. Std excess gain available in 10 ms, 25 ms, and 50 ms response speeds only
2. Std excess gain provides increased noise immunity

Beam Spot Size—300/310 mm and 500 mm Models

Table 5: Beam Spot Size—300/310 mm and 500 mm Models

Distance (mm)		Size (Horizontal x Vertical)
Threaded Barrel Models	Flush Mount Models	
25	35	2.6 mm x 1.0 mm
150	160	2.3 mm x 0.9 mm
300	310	2.0 mm x 0.8 mm
500	-	1.9 mm x 1.0 mm

Beam Spot Size—100/110 mm Models

Table 6: Beam Spot Size—100/110 mm Models

Distance (mm)		Size (Horizontal x Vertical)
Threaded Barrel Models	Flush Mount Models	
25	35	2.4 mm x 1.0 mm
50	60	2.2 mm x 0.9 mm
100	110	1.8 mm x 0.7 mm

Delay at Power Up

< 750 ms

Maximum Torque**Side mounting:** 1 N·m (9 in-lbs)**Nose mounting:** 20 N·m (177 in-lbs)**Ambient Light Immunity**

> 5,000 lux at 300 mm

> 2,000 lux at 500 mm

Connector**Threaded Barrel Models:** Integral 5-pin M12/Euro-style male quick disconnect (QD)**Flush Mount Models:** Integral 4-pin M12/Euro-style male quick disconnect (QD)**Construction****Housing:** 316 L stainless steel**Lens cover:** PMMA acrylic**Lightpipe and display window:** polysulfone**Temperature Effect**

0.05 mm/°C at <125 mm (threaded barrel models)/< 135 mm (flush mount models)

0.35 mm/°C at 300 mm (threaded barrel models)/< 310 mm (flush mount models)

1 mm/°C at 500 mm (threaded barrel models)

Chemical Compatibility

Compatible with commonly used acidic or caustic cleaning and disinfecting chemicals used in equipment cleaning and sanitation. ECOLAB® certified. Compatible with typical cutting fluids and lubricating fluids used in machining centers

Application Note

For optimum performance, allow 10 minutes for the sensor to warm up

Environmental Rating

IEC IP67 per IEC60529

IEC IP68 per IEC60529

IEC IP69K per DIN40050-9

Operating Conditions

-10 °C to +50 °C (+14 °F to +122 °F)

35% to 95% relative humidity

Storage Temperature

-25 °C to +75 °C (-13 °F to +167 °F)

Vibration

MIL-STD-202G, Method 201A (10 Hz to 60 Hz, 0.06 inch (1.52 mm) double amplitude, 2 hours each along X, Y and Z axes), with sensor operating

Shock

MIL-STD-202G, Method 213B, Condition I (100G 6x along X, Y and Z axes, 18 total shocks), with sensor operating

Required Overcurrent Protection**WARNING:** Electrical connections must be made by qualified personnel in accordance with local and national electrical codes and regulations.

Overcurrent protection is required to be provided by end product application per the supplied table.

Overcurrent protection may be provided with external fusing or via Current Limiting, Class 2 Power Supply.

Supply wiring leads < 24 AWG shall not be spliced.

For additional product support, go to www.bannerengineering.com.

Supply Wiring (AWG)	Required Overcurrent Protection (Amps)
20	5.0
22	3.0
24	2.0
26	1.0
28	0.8
30	0.5

Certifications

Class 2 power

UL Environmental Rating: Type 1



chemical compatibility certified

ECOLAB is a registered trademark of Ecolab USA Inc. All rights reserved.

Performance Curves—Threaded Barrel Models

Minimum Separation Distance Between Target and Background for: Uniform and Non-Uniform Targets







Figure 11. Minimum Object Separation Distance (90% to 6% reflectance)

Performance Curves—Flush Mount Models

Minimum Separation Distance Between Target and Background for: Uniform and Non-Uniform Targets




Figure 12. Minimum Object Separation Distance (90% to 6% reflectance)

Dual Mode Reference Surface Considerations

Optimize reliable detection by applying these principals when selecting your reference surface, positioning your sensor relative to the reference surface, and presenting your target. The robust detection capabilities of the Q4X allows successful detection even under non-ideal conditions in many cases. Typical reference surfaces are metal machine frames, conveyor side rails, or mounted plastic targets. Contact Banner Engineering if you require assistance setting up a stable reference surface in your application. For detailed instructions for detecting clear or transparent objects, refer to the Instruction Manual, p/n 181483.

1. Select a reference surface with these characteristics where possible:
 - Matte or diffuse surface finish
 - Fixed surface with no vibration
 - Dry surface with no build-up of oil, water, or dust
2. Position the reference surface between 50 mm and the maximum sensing range for threaded barrel models or between 60 mm and the maximum sensing range for flush mount models.
3. Position the target to be detected as close to the sensor as possible, and as far away from the reference surface as possible.
4. Angle the sensing beam relative to the target and relative to the reference surface 10 degrees or more.

Banner Engineering Corp. Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. **IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.**

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: www.bannerengineering.com.



ASSEMBLY TITLE:

PRODUCT DETECT ASSEMBLY

DRAWING NO.:

GENERAL FUNCTION:


- The product detect signal is used to trigger the labeling cycle. Optimum placement and setup of the product detect sensor is critical to accurate and repeatable label placement.

SETUP AND ADJUSTMENTS:





- Set the vertical position of the sensor at a point on the product that provides a stable and repeatable sense area. Loosen the bolts securing the sensor, and move as required, then retighten screws.
- The sensor is configured at the factory for optimum performance however if a new product is introduced adjustments may be required or a different sensor may if adjustments are required please refer to manufacturers data sheet for detailed setup and calibration if needed.

MAINTENANCE: None

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	203370-002	LASER SENSOR	10964-006
2	1	203370-101	SWIVWL BRACKET	10964-006
3	1	252019-000	4 PIN MALE CONNECTOR	10964-006
4	1	A20654-009	ADJ. ROD	10964-006



A	6-22-23	NEW DRAWING		ATT	
REV	DATE	DESCRIPTION		BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .01 XXX ± .005 ANGLES ± 30° SURFACE FINISH .125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		QUADREL LABELING SYSTEMS		SCALE	1/1
		7670 JENTHER DRIVE		DATE	6-22-23
		MENTOR, OHIO 44060		DRAWN BY	ATT
		(440) 602-4700			
		HUGGER/ROLLER PRODUCT DETECT			
MAT'L		10964-006		10964-006	



A	6-22-23	NEW DRAWING		ATT	
REV	DATE	DESCRIPTION		BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± 30°		QUADREL LABELING SYSTEMS		SCALE	1/1
		7670 JENTHER DRIVE		DATE	6-22-23
		MENTOR, OHIO 44060		DRAWN BY	ATT
		(440) 602-4700			
HUGGER/ROLLER PRODUCT DETECT					
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		MAT'L		10964-006	10964-006



Self-contained CMOS Laser Sensor LR-ZB□B Series



Instruction Manual

Read this manual before using the product in order to achieve maximum performance.
Keep this manual in a safe place after reading it so that it can be used at any time.

The following symbols alert you to important messages.
Be sure to read these messages carefully.

WARNING	It indicates a hazardous situation which, if not avoided, could result in death or serious injury.
NOTICE	It indicates a situation which, if not avoided, could result in product damage as well as property damage.

Safety Information for LR-ZB Series

WARNING	<ul style="list-style-type: none"> This product is only intended to detect object(s). Do not use this product for the purpose to protect a human body or part of a human body. This product is not intended for use as an explosion-proof product. Do not use this product in a hazardous location and/or potentially explosive atmosphere. This product uses DC power. The product may explode or burn if an AC voltage is applied.
NOTICE	<ul style="list-style-type: none"> Do not wire the cable along with power lines or high-tension lines, as the sensor may malfunction or be damaged due to noise. When using a commercially available switching regulator, ground the frame ground terminal and ground terminal. Do not disassemble this product. Laser emission from this product is not automatically stopped when it is disassembled. Use with an over current protection device which is rated 30 V or more and not more than 1 A.

Safety Precautions on Laser Product


WARNING	<ul style="list-style-type: none"> This product uses a semiconductor laser for the light source. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure. Follow the instructions mentioned in this manual. Otherwise, injury to the human body (eyes and skin) may result. Laser emission from this product is not automatically stopped when it is disassembled. Do not disassemble this product. Do not stare into the beam.
----------------	---

Wavelength/Output	660 nm/145 μW
FDA(CDRH) Part1040.10 *	Class 1 laser product
IEC 60825-1	Class 1 laser product

* The laser classification for FDA (CDRH) is implemented based on IEC60825-1 in accordance with the requirements of Laser Notice No.50.

Certification and Identification Label

When using this product in the U.S. affix the Certification and Identification Label included in the package of this product as shown on the right.
(Affix this label in a location that is not splashed with oils or chemicals.)



Consignes de sécurité relatives au Laser

WARNING	L'utilisation des commandes ou réglages ou l'exécution des procédures autres que celles spécifiées dans les présentes exigences peuvent être la cause d'une exposition à un rayonnement dangereux.
----------------	--

Precautions on Regulations and Standards

UL Certification

This product is an UL/C-UL Listed product.
• UL File No. E301717/Category NRKH, NRKH7/Enclosure Type 1 (UL50)

Be sure to consider the following specifications when using this product as a UL/CUL Listed Product.
• Use a power supply with Class 2 output defined in NFPA70 (NEC: National Electrical Code).
• Power supply/ Control input/ Control output shall be connected to a single Class 2 source only.

- Install the product at the ambient temperature 45°C or below when using with following optional cable, (OP-75721, OP-85502, OP-85505, OP-85506, OP-75722, OP-87274, OP-87276, OP-87278)

CE and UKCA Marking

Keyence Corporation has confirmed that this product complies with the essential requirements of the applicable EU Directive(s) and UK regulations, based on the following specifications. Be sure to consider the following specifications when using this product in the Member States of European Union and in the United Kingdom.

- EMC Directive (CE) and Electromagnetic Compatibility Regulations (UKCA)**
 - Applicable standard EMI: (BS)EN60947-5-2, Class A/EMS: (BS)EN60947-5-2

Remarks: These specifications do not give any guarantee that the end product with this product incorporated complies with the essential requirements of EMC Directive and Electromagnetic Compatibility Regulations. The manufacturer of the end-product is solely responsible for the compliance on the end-product itself according to EMC Directive and Electromagnetic Compatibility Regulations.

Specifications

Type	Distance setting	
Appearance	M18 Threaded Mount	
Model	LR-ZB90CB	LR-ZB240CB
Detectable distance	25 to 90 mm (650 to 0) ¹	25 to 240 mm (215 to 0) ¹
Standard detection deviation	25 to 40 mm : 1.5 mm 40 to 90 mm : 3 mm	25 to 170 mm : 9 mm 170 to 240 mm : 25 mm
Display resolution	2 (0.2 mm)	1 to 3 (1 to 3 mm)
Spot diameter	2 x 1 mm at 90 mm	2.4 X 1.2 mm at 240 mm
Response time	1.5 ms / 10 ms / 50 ms selectable	
Light source	Type	Red laser (660 nm)
	Laser class	Class 1 laser product (IEC60825-1, FDA (CDRH) Part1040.10 ²)
Function	Indicator	3-digit 7-segment display (red), output indicator (yellow), DATUM indicator (orange), 1 spot indicator (green)
	Timer	OFF/ON delay/OFF delay/One-shot
Specifications	Power voltage	10 to 30 VDC, including 10% ripple (P-P), Class 2 or LPS
	Power consumption	450 mW or less (18 mA or less at 24 V, 34 mA or less at 12 V)
	Control output	NPN + PNP Open collector Applied voltage 30 VDC or less, Control current 100 mA or less, Residual voltage 1.2 V or less at 10 mA or less, 2 V or less at 10 to 100 mA
	Protection circuit	Protection against reverse power connection, output overcurrent, output surge, reverse output connection
	Output operation	Light-ON/Dark-ON selectable
Environmental resistance	External input	None
	Enclosure rating	IP68 (IEC60529)/IP69K (DIN40050-9)/ 4X, 6P, 13 (NEMA250)
	Ambient light ³	Incandescent lamp: 4000 lx or less Sunlight: 8000 lx or less
	Ambient temperature	-10 to +50°C
	Storage temperature	-25 to +75°C
	Ambient humidity	35 to 85%RH
	Shock resistance	1000 m/s ² in X, Y, Z axis directions respectively 6 times
	Vibration resistance	10 to 55 Hz Double amplitude 1.5 mm in the X, Y, Z axis directions respectively, 2 hours
Material	Insulating resistance	20 MΩ or more (500 VDC)
	Withstand voltage	1000 VAC 50/60 Hz 1 min
Weight	Approx. 75 g	


*1 Display reading used as a guide for the detecting distance. When the setting value is tuned, the readout shifts. When the value exceeds "99", "-FF" is displayed.

*2 The laser classification for FDA (CDRH) is implemented based on IEC60825-1 in accordance with the requirements of Laser Notice No.50.

*3 When the response time is 10 ms

I/O Circuit Diagram

Bipolar type (LR-ZB*B)




M12 connector (4-pin) type




Basic Operation

Part names and functions



DTM: This lights up when datum calibration is performed.
1 spot: This turns off when no light enters or multiple reflections occur.


Package contents



• Instruction manual

A connector cap is supplied with a connector.


Wiring




M12 Connector tightening torque: 0.8 Nm

* Tighten the connector by a hand, and then retighten it by using tools and so on. Insufficient tightening will degrade water-resistant performance.

Installation




Output configuration (L.ON ↔ D.ON)




Sensitivity adjustment


Basic setting (high accuracy) (2-point calibration, background suppression - BGS)




When an object other than the background is to be detected (Datum calibration, foreground suppression - FGS)



When an object located nearer than the background is to be detected (Maximum sensitivity calibration, background suppression - BGS)




Moving target calibration (Full auto calibration, background suppression - BGS)





* This function cannot be used when the background is not within the detecting area.

Manual adjustment



Advanced Settings



Warranties and Disclaimers

- KEYENCE warrants the Products to be free of defects in materials and workmanship for a period of one (1) year from the date of shipment. If any models or samples were shown to Buyer, such models or samples were used merely to illustrate the general type and quality of the Products and not to represent that the Products would necessarily conform to said models or samples. Any Products found to be defective must be shipped to KEYENCE with all shipping costs paid by Buyer or offered to KEYENCE for inspection and examination. Upon examination by KEYENCE, KEYENCE, at its sole option, will refund the purchase price of, or repair or replace at no charge any Products found to be defective. This warranty does not apply to any defects resulting from any action of Buyer, including but not limited to improper installation, improper interfacing, improper repair, unauthorized modification, misapplication and mishandling, such as exposure to excessive current, heat, coldness, moisture, vibration or outdoors air. Components which wear are not warranted.
 - KEYENCE is pleased to offer suggestions on the use of its various Products. They are only suggestions, and it is Buyer's responsibility to ascertain the fitness of the Products for Buyer's intended use. KEYENCE will not be responsible for any damages that may result from the use of the Products.
 - The Products and any samples ("Products/Samples") supplied to Buyer are not to be used internally in humans, for human transportation, as safety devices or fail-safe systems, unless their written specifications state otherwise. Should any Products/Samples be used in such a manner or misused in any way, KEYENCE assumes no responsibility, and additionally Buyer will indemnify KEYENCE and hold KEYENCE harmless from any liability or damage whatsoever arising out of any misuse of the Products/Samples.
 - OTHER THAN AS STATED HEREIN, THE PRODUCTS/SAMPLES ARE PROVIDED WITH NO OTHER WARRANTIES WHATSOEVER, ALL EXPRESS, IMPLIED, AND STATUTORY WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF PROPRIETARY RIGHTS, ARE EXPRESSLY DISCLAIMED.**
- IN NO EVENT SHALL KEYENCE AND ITS AFFILIATED ENTITIES BE LIABLE TO ANY PERSON OR ENTITY FOR ANY DIRECT, INDIRECT, INCIDENTAL, PUNITIVE,**

SPECIAL OR CONSEQUENTIAL DAMAGES (INCLUDING, WITHOUT LIMITATION, ANY DAMAGES RESULTING FROM LOSS OF USE, BUSINESS INTERRUPTION, LOSS OF INFORMATION, LOSS OR INACCURACY OF DATA, LOSS OF PROFITS, LOSS OF SAVINGS, THE COST OF PROCUREMENT OF SUBSTITUTED GOODS, SERVICES OR TECHNOLOGIES, OR FOR ANY MATTER ARISING OUT OF OR IN CONNECTION WITH THE USE OR INABILITY TO USE THE PRODUCTS, EVEN IF KEYENCE OR ONE OF ITS AFFILIATED ENTITIES WAS ADVISED OF A POSSIBLE THIRD PARTY'S CLAIM FOR DAMAGES OR ANY OTHER CLAIM AGAINST BUYER. In some jurisdictions, some of the foregoing warranty disclaimers or damage limitations may not apply.

BUYER'S TRANSFER OBLIGATIONS:

If the Products/Samples purchased by Buyer are to be resold or delivered to a third party, Buyer must provide such third party with a copy of this document, all specifications, manuals, catalogs, leaflets and written information provided to Buyer pertaining to the Products/Samples.

E 1101-3

KEYENCE CORPORATION

1-3-14, Higashi-Nakajima, Higashi-Yodogawa-ku,
Osaka, 533-8555, Japan
PHONE: +81-6-6379-2211

www.keyence.com/glb

Specifications are subject to change without notice.

ASW-W1-MAN-2121

Copyright (c) 2011 KEYENCE CORPORATION. All rights reserved.
11813GB 2052-2b [96M11813] Printed in Japan



ASSEMBLY TITLE: HUGGER BELT

GENERAL FUNCTION:

- The hugger belt assembly provides positive drive through the labeling station. It is controlled by a variable speed AC motor.

SET-UP AND ADJUSTMENTS:

- To adjust in/out spacing, turn handle at either end of the horizontal screw.

MAINTENANCE:

- Ensure that the hugger belts are free of labels. Remove label material using an environmentally safe adhesive cleaner.
- Inspect the belt weekly for evidence of excessive wear or stretching. Ensure that belt tension is correct to prevent these conditions.

TROUBLESHOOTING:


PROBLEM

Will not hold product

WHAT TO DO


Adjust in/out spacing to apply more pressure to product. See SET UP AND ADJUSTMENTS.






ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	181079-000	BEARING, NEEDLE ROLLER	84187HB-000
2	4	181080-000	BEARING, THRUST WASHER	84187HB-000
3	1	362164-000	COUPLING, ONE PIECE CLAMP-ON	84187HB-000
4	16	792248-001	PILLOW BLOCK	84187HB-000
5	1	792354-000	DIGITAL POSITION INDICATOR	84187HB-000
6	4	793023-000	DRYLIN RAIL - OAL=11.75	84187HB-000
7	4	793045-000	DIAMOND KNURL KNOB	84187HB-000
8	2	801080-000	6" HANDWHEEL	84187HB-000
9	1	84187HBL-000	HUGGER BELT LEFT	84187HB-000
10	1	84187HBR-000	HUGGER BELT RIGHT	84187HB-000
11	1	A21559-119	THREADED ROD	84187HB-000
12	1	A21560-119	THREADED ROD	84187HB-000
13	1	A25507-000	ADJUSTMENT BLOCK	84187HB-000
14	1	A25507-001	ADJUSTMENT BLOCK, LH	84187HB-000
15	4	A26179-120	KNOB STUD	84187HB-000
16	1	B22005-015	BEARING PLATE	84187HB-000
17	4	B22104-031	IGUS MOUNTING PLATE	84187HB-000
18	4	B22104-033	GUSSET	84187HB-000
19	4	B22104-040	CONVEYOR MOUNTING PLATE	84187HB-000
20	4	B22106-000	PIVOT MOUNTING BLOCK	84187HB-000
21	2	B22245-005	PIVOT SHAFT	84187HB-000
22	2	B22248-613	PIVOT ARM	84187HB-000
23	2	B22248-614	PIVOT ARM	84187HB-000
24	1	B22874-352	MOUNTING PLATE	84187HB-000
25	1	B22874-353	MOUNTING PLATE	84187HB-000
26	2	D22325-153	HUGGER BELT MOUNTING PLATE	84187HB-000

		A	Aug-05-25	NEW DRAWING	TAZ
		REV	DATE	DESCRIPTION	BY
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
<div>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE $X \pm .01$ $XX \pm .005$ $ANGLES \pm .30^\circ$ SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADII .010/.030</div>		<div>QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700</div>		SCALE: 9/32	
				DATE: Aug-05-25	
				DRW BY: TAZ	
				CHK BY:	
				APPR BY:	
HUGGER BELT MOUNTING					
MAT'L		84187HB-000		84187HB-000	



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY		QUADREL LABELING SYSTEMS	
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE XX ± .1 XXX ± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
HUGGER BELT MOUNTING		84187HB-000	
MAT'L		84187HB-000	

A	Aug-05-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY
SCALE:	1/4	DATE:	Aug-05-25
DRW BY:	TAZ	CHK BY:	
APPR BY:			



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	111075-000	BEARING, BALL	84187HBL-000
2	2	151008-000	BEARING, THRUST WASHER	84187HBL-000
3	1	413006-000	GEARMOTOR, 3/8 HP, 85 RMP, AC MOTOR	84187HBL-000
4	1	A21830-608	TOP TRAP BELT, LINOTEX	84187HBL-000
5	1	A25122-048	DRIVE PULLEY	84187HBL-000
6	1	A25122-049	DRIVE PULLEY	84187HBL-000
7	1	A25210-000	ADJUSTMENT MOUNTING	84187HBL-000
8	1	A25211-001	PULLEY GUARD	84187HBL-000
9	1	A25212-010	IDLER SHAFT	84187HBL-000
10	4	A26197-000	PULLEY FLANGE	84187HBL-000
11	1	B22073-751	WEAR STRIP MOUNTING PLATE	84187HBL-000
12	1	B22073-753	WEAR STRIP MOUNTING PLATE	84187HBL-000
13	1	B22073-954	WEAR STRIP MOUNTING PLATE	84187HBL-000
14	1	B22073-955	WEAR STRIP MOUNTING PLATE	84187HBL-000
15	1	B22075-851	BELT WEAR STRIP	84187HBL-000
16	1	B22075-953	BELT WEAR STRIP	84187HBL-000
17	1	B22075-954	BELT WEAR STRIP	84187HBL-000
18	1	B22075-955	HUGGER BELT WEAR STRIP	84187HBL-000
19	1	B23044-000	SPACER	84187HBL-000
20	1	B23044-612	SPACER	84187HBL-000
21	1	C21005-000	HUGGER BELT TOP RE-ENFORCEMENT PLATE	84187HBL-000
22	1	C21006-001	MOTOR MOUNTING PLATE	84187HBL-000
23	1	C21362-006	HUGGER BELT GUARD	84187HBL-000
24	1	D22219-763	HUGGER BELT SIDE PLATE	84187HBL-000
25	1	D22219-764	HUGGER BELT SIDE PLATE	84187HBL-000

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE
X ± .1
XX ± .01
XXX ± .005
ANGLES ± .00°
SURFACE FINISH 125
BREAK ALL EDGES .005/ .015
CORNER RADIUS .010/ .030
ALL ANGLES ARE 90°

QUADREL LABELING SYSTEMS

7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

SCALE: 7/32
DATE: Aug-05-25
DRW BY: TAZ
CHK BY:
APPR BY:





HUGGER BELT LEFT

A	Aug-05-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

MAT'L

84187HBL-000

84187HBL-000



A	Aug-05-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY


UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE	SCALE: 7/32
xxx ± .01	DATE: Aug-05-25
xxx ± .005	DRW BY: TAZ
ANGLES ± .00	CHK BY:
SURFACE FINISH 125	APPR BY:
BREAK ALL EDGES .005/ .015	
CORNER RADIUS .010/ .030	
ALL ANGLES ARE 90°	



QUADREL LABELING SYSTEMS
7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

HUGGER BELT LEFT

MAT'L	84187HBL-000	84187HBL-000
-------	--------------	--------------



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	111075-000	BEARING, BALL	84187HBR-000
2	2	151008-000	BEARING, THRUST WASHER	84187HBR-000
3	1	A21830-608	TOP TRAP BELT, LINOTEX	84187HBR-000
4	1	A25122-048	DRIVE PULLEY	84187HBR-000
5	1	A25122-049	DRIVE PULLEY	84187HBR-000
6	1	A25210-000	ADJUSTMENT MOUNTING	84187HBR-000
7	1	A25211-001	PULLEY GUARD	84187HBR-000
8	1	A25212-010	IDLER SHAFT	84187HBR-000
9	4	A26197-000	PULLEY FLANGE	84187HBR-000
10	1	A413006-000	GEARMOTOR, 3/8HP 340RPM 230VAC ENCODER MOUNT	84187HBR-000
11	1	B22073-751	WEAR STRIP MOUNTING PLATE	84187HBR-000
12	1	B22073-753	WEAR STRIP MOUNTING PLATE	84187HBR-000
13	1	B22073-954	WEAR STRIP MOUNTING PLATE	84187HBR-000
14	1	B22073-955	WEAR STRIP MOUNTING PLATE	84187HBR-000
15	1	B22075-851	BELT WEAR STRIP	84187HBR-000
16	1	B22075-955	HUGGER BELT WEAR STRIP	84187HBR-000
17	1	B22075-956	BELT WEAR STRIP	84187HBR-000
18	1	B22075-957	BELT WEAR STRIP	84187HBR-000
19	1	B23044-000	SPACER	84187HBR-000
20	1	B23044-612	SPACER	84187HBR-000
21	1	C21005-000	HUGGER BELT TOP RE-ENFORCEMENT PLATE	84187HBR-000
22	1	C21006-000	MOTOR MOUNTING PLATE	84187HBR-000
23	1	C21362-007	HUGGER BELT GUARD	84187HBR-000
24	1	D22219-763	HUGGER BELT SIDE PLATE	84187HBR-000
25	1	D22219-764	HUGGER BELT SIDE PLATE	84187HBR-000

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE
X ± .1
XX ± .01
XXX ± .005
ANGLES ± .00°

SURFACE FINISH 125
BREAK ALL EDGES .005/ .015
CORNER RADIUS .010/ .030
ALL ANGLES ARE 90°

QUADREL LABELING SYSTEMS
7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

SCALE: 1/4
DATE: Aug-05-25
DRW BY: TAZ
CHK BY:
APPR BY:





84187HBR-000

84187HBR-000

A	Aug-05-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY


HUGGER BELT RIGHT


SHEET 1 OF 2







THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
x ± .1 xx ± .01 xxx ± .005 ANGLES ± .00°		SCALE: 3/16 DATE: Aug-05-25 DRW BY: TAZ CHK BY: APPR BY:	
SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		HUGGER BELT RIGHT	
MAT'L 84187HBR-000		84187HBR-000	


ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	202057-002	ENCODER, SHAFT MOUNT W/COUPL.	22287-004
2	1	A21681-001	RATCHET HANDLE MTG. PIN	22287-004
3	1	A25400-100	ENCODER MOUNTING PLATE	22287-004
4	2	A25400-102	ENCODER MOUNTING PLATE	22287-004
5	1	A25400-200	ENCODER MOUNTING PLATE	22287-004



A		Oct-25-21		NEW DRAWING	
REV		DATE		DESCRIPTION	
				BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± 30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		 QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700		SCALE: 2/1	
				DATE: Oct-25-21	
				DRW BY: TJS	
				CHK BY: 03/18/2024-SEM	
				APPR BY:	
ENCODER KIT					
MAT'L		80550PP-000		22287-004	



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 2/1	
X ± .1		DATE: Oct-25-21	
XX ± .01		DRW BY: TJS	
XXX ± .005		CHK BY: 03/18/2024-SEM	
ANGLES ± .00°		APPR BY:	
SURFACE FINISH 125		ENCODER KIT	
BREAK ALL EDGES .005/ .015		MATERIAL	
CORNER RADIUS .010/ .030		80550PP-000	
ALL ANGLES ARE 90°		22287-004	



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	4	792248-001	PILLOW BLOCK	84187HB-001
2	1	793023-000	DRYLIN RAIL - OAL=11.75	84187HB-001
3	1	793045-000	DIAMOND KNURL KNOB	84187HB-001
4	1	A26179-120	KNOB STUD	84187HB-001
5	1	B22104-031	IGUS MOUNTING PLATE	84187HB-001
6	1	B22104-033	GUSSET	84187HB-001
7	1	B22104-040	CONVEYOR MOUNTING PLATE	84187HB-001
8	1	B22106-000	PIVOT MOUNTING BLOCK	84187HB-001
9	1	B22245-006	PIVOT SHAFT	84187HB-001
10	1	B22248-613	PIVOT ARM	84187HB-001
11	1	B22874-007	MOUNTING PLATE	84187HB-001
12	1	B23044-612	SPACER	84187HB-001
13	1	D22325-152	HUGGER SUPPORT SLED	84187HB-001

A	Sep-15-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE

.XX ± .1
XXX ± .01
XXX ± .005
ANGLES ± .00°

SURFACE FINISH 125
BREAK ALL EDGES .005/ .015
CORNER RADIUS .010/ .030
ALL ANGLES ARE 90°

QUADREL LABELING SYSTEMS

7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

SCALE: 15/32

DATE: Sep-15-25

DRW BY: TAZ

CHK BY:





APPR BY:

MATERIAL

84187HB-001

HUGGER BELT SUPPORT

84187HB-001




THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 9/16	
X ± .1		DATE: Sep-15-25	
XX ± .01		DRW BY: TAZ	
XXX ± .005		CHK BY:	
ANGLES ± .00°		APPR BY:	
SURFACE FINISH 125		HUGGER BELT SUPPORT	
BREAK ALL EDGES .005/ .015		MAT'L 84187HB-001	
CORNER RADIUS .010/ .030		84187HB-001	
ALL ANGLES ARE 90°		9/16	

Electronics

--	222431-001	1	Enclosure, 42EL4812
--	222200-002	1	Panel, SCE-48P42
--	201139-005	2	Nema 4X Hood
--	201139-004	1	Exhaust Kit
--	201139-003	1	Fan Assembly, 24V
--	222456-000	1	Left Hand Interlock Kit
--	251801-000	4	2 Position Jumper, ST2.5
--	251797-000	8	Phoenix Contact 3031212 Terminal Block, ST2.5 (E60425)

--	241231-000	2	Fuse, 30A, CC
--	251855-000	12	2-Pole Jumper
--	251858-000	2	5-Pole Jumper
--	251859-000	4	10 Position Jumpers
--	251798-000	3	Partition Plate
--	251799-000	5	End Cover
--	251795-000	30	Phoenix Contact End Terminal
--	251854-000	25	Phoenix Contact Ground Terminal, ST1.5
--	251853-000	180	Phoenix Contact Terminal Block, ST1.5
--	262822-001	2	Ethernet Cable, 3 ft
--	262822-006	1	Ethernet Cable, 2 ft

27	221490-000	1	Analog Output Expansion Module
26	221486-000	2	Output Expansion Module
25	221617-002	1	Power Supply, CompactLogix 24V
24	221489-000	2	Input Expansion Module
23	221545-000	1	High Speed Counter Module
22	221616-001	1	PLC, AB CompactLogix L33ER
21	412410-002	2	DB44 Cable, Female, for IO Plus
20	411902-001	2	IO 24 Plus Module
19	411902-000	2	PTi Module
18	411901-000	2	Option Card Mounting Kit
17	411900-001	2	Servo Drive, Digitax HD M750 5.6A (E171230)
16	221650-005	1	Phoenix 1301402 Safety Relay
15	211532-002	1	Power Supply, 24V, 6.5A
14	411458-004	2	AC Drive Encoder Card
13	411458-001	6	AC Drive, Frenic ACE, 1 HP
12	221682-000	1	Ethernet Switch, 5 Port
11	202628-000	1	Relay, 24V, SPDT
10	241166-000	2	Circuit Breaker, 2 Pole, 3A
9	241137-000	2	Circuit Breaker, 2 Pole, 15A
8	241161-000	6	Circuit Breaker, 2 Pole, 6A
7	251841-000	1	End Cover, ST6
6	251840-000	1	Partition Plate, ST6
5	251852-000	2	10 Position Jumper, ST6
4	251842-000	20	Phoenix Contact Terminal Block, ST6 (E60425)
3	272117-004	1	Non-Fused Disconnect, 40A
2	241285-000	2	Fuse Holder, CC
1	251830-002	1	Ground Bar
NO.	PART NO.	QTY	DESCRIPTION



1.5" Wireway Unless Noted
Component Hardware: 8-32 SHCS
Wireway/Din Rail Hardware: 8-32 BHCS

UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .XXTOL XX ± .XXXTOL XX ± .XXXTOL ANGLES ± .XXXTOL SURFACE FINISH FINISH BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.020	QUADREL LABELING SYSTEMS 7670 Jenther Drive Mentor, Ohio 44060 (440) 892-4700	SCALE: 1:1 DATE: 09JUN2025 DRAWN BY: CAV REVISED:
Layout, Custom		
MATL 84187E-000		B84187-000P

TECHLINE TOP
240VAC, 30A
AB COMPACTLOGIX PLC
NIDEC DIGITAX SERVO DRIVES
FUJI ACE INVERTERS




Page Descriptions

- 1: Main AC Distribution
- 2: Safety Relay, Network
- 3: Hugger Belts
- 4: Conveyor, Top Trap
- 5: Pacing, Top Trap Lift
- 6: Labeler #1
- 7: Labeler #2
- 8: PLC Slots #1 - #3
- 9: PLC PS, Slot #4
- 10: PLC Slots #5 - #6
- 11: Operator Enclosure
- 12: Sensors

WIRE SIZE/COLOR TABLE (UNLESS OTHERWISE NOTED)


240VAC:14AWG BLACK
24VDC/SIGNAL: 18AWG BLUE
0VDC: 18AWG WHITE/BLUE

EARTH GROUND WIRES: 14 AWG GREEN/YELLOW
AC MOTOR WIRES: 4-16AWG

-  : Terminal Block
-  : 2 Jumpered Terminal Blocks
-  : 3 Jumpered Terminal Blocks, etc

<div>QUADREL</div> <div>LABELING SYSTEMS</div> <div>7670 JENTHER DR.</div> <div>MENTOR, OH</div> <div>44060</div>				
	-	Release	CAV	11JUL2025
Drawn By: CAV	REV	DESCRIPTION	BY	DATE
Title				
CUSTOM TECHLINE				
Schematic #				Rev
SB84187-000				-
Date: Friday, July 11, 2025			Sheet 00 of 12	




220V, 1PH, 30A



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use



QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
	-	Release	CAV	11JUL2025
	REV	DESCRIPTION	BY	DATE
Title				
MAIN AC				
Schematic #				Rev
SB84187-000				-
Date: Friday, July 11, 2025				
Sheet 01 of 12				



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use



QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
	-	Release	CAV	11JUL2025
	REV	DESCRIPTION	BY	DATE
Title				
SAFETY, NETWORK				
Schematic #				Rev
SB84187-000				-
Date: Wednesday, October 22, 2025				
Sheet 02 of 12				



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use

QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
	-	Release	CAV	11JUL2025
	REV	DESCRIPTION	BY	DATE
Title				
HUGGER DRIVES				
Schematic #				Rev
SB84187-000				-
Date: Friday, July 11, 2025				
Sheet 03 of 12				



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use

QUADREL
LABELING SYSTEMS
7670 JENTHER DR.
MENTOR, OH
44060

Drawn By: CAV

REV

Release

DESCRIPTION

CAV

BY

DATE

11JUL2025

DATE

CONVEYOR, TOP TRAP

Schematic #


5284187-000

Rev


-

Date: Tuesday, October 07, 2025

Sheet 04 of 12





Drives:
Lift,
Pacing
Page 5



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use



QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
		-	Release	CAV
Drawn By: CAV	REV	DESCRIPTION	BY	DATE
Title				
TT LIFT, PACING				
Schematic #				Rev
5284187-000				-
Date: Friday, July 11, 2025			Sheet	05 of 12



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use




QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
	-	Release	CAV	11JUL2025
	REV	DESCRIPTION	BY	DATE
Title				
LABELER #1 DRIVE				
Schematic #				Rev
S384187-000				-
Date: Wednesday, September 17, 2025 Sheet 06 of 12				



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use



QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
	-	Release	CAV	11JUL2025
	REV	DESCRIPTION	BY	DATE
Title				
LABELER #2 DRIVE				
Schematic #				Rev
S384187-000				-
Date: Wednesday, September 17, 2025				
Sheet 07 of 12				



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use




QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
	-	Release	CAV	11JUL2025
	REV	DESCRIPTION	BY	DATE
Title				
PLC SLOTS 1-3				
Schematic #				Rev
SB84187-000				-
Date: Wednesday, September 17, 2025				
Sheet 08 of 12				



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use




QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
	-	Release	CAV	11JUL2025
	REV	DESCRIPTION	BY	DATE
Drawn By: CAV		Title		
PLC SLOT4, POWER SUPPLY				
Schematic #			Rev	
SB84187-000			-	
Date: Friday, July 11, 2025				
Sheet 09 of 12				



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use


QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
	-	Release	CAV	11JUL2025
	Drawn By: CAV	REV	DESCRIPTION	BY DATE
Title				
PLC SLOTS 5-6				
Schematic #				Rev
SB84187-000				-
Date: Thursday, October 23, 2025 Sheet 10 of 12				



COLOR	TECHNICIAN	DATE




For Quadrel Assembly Use

QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
	-	Release	CAV	11JUL2025
Drawn By: CAV	REV	DESCRIPTION	BY	DATE
Title				
OPERATOR ENCLOSURE				
Schematic #				Rev
SB84187-000				-
Date: Friday, July 11, 2025				
Sheet 11 of 12				






Port #	System	Address	Labeler #1	Address	Labeler #2	Address
#1	Infeed Sensor	1-I:2/05	Label Detect	7102	Label Detect	8102
#2	Product Detect #1	1-I:2/00	Low Label	7209	Low Label	8209
#3	Product Detect #2	8101	End of Web	7210	End of Web	8210
#4	Top Trap Upper Limit	1-I:2/07	Broken Web	7211	Broken Web	8211
#5	Top Trap Lower Limit	1-I:2/08	Spare		Spare	
#6	Outfeed Sensor	1-I:2/06	Position	7224	Position	8224
#7	Spare		Up/Down Solenoid	7206	Up/Down Solenoid	8206
#8	Spare		Spare		Spare	

Typical Sensor Wiring Example



Labeler	Up/Down Switch	Indicator	Jog
#1	7213	1-O:5/00	7212
#2	8213	1-O:5/01	8212



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use

QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
	-	Release	CAV	11JUL2025
	REV	DESCRIPTION	BY	DATE
Title				
SENSORS				
Schematic #				Rev
5284187-000				-
Date: Tuesday, September 23, 2025				
Sheet 12 of 12				

9 MAINTENANCE

9.1 GENERAL INFORMATION

This labeler has been designed with the minimal maintenance requirement possible. There are however some things to take into consideration.

The system is built to perform in humid conditions, but must not be pressure washed. In case of wash down conditions, it is recommended to cover each labeling head with a plastic tarp.

For the overall cleaning, it is recommended to use compressed air and clean, damp wipes.

Always turn off the system before proceeding with cleaning and maintenance.

The following section explains the preventive maintenance for each section

After every 100 hours of operation, a visual inspection of the system should be done and where it is necessary, lubricate and cleaning should be performed.



CAUTION

WEAR PROTECTIVE EYEWEAR when performing any maintenance on this equipment.



CAUTION

To reduce risk of fire, electrocution or other personal Injury when operating or maintaining the labeling head, follow basic safety precaution, including the following:

DO NOT perform any servicing or maintenance with the power ON.

Always disconnect the electrical plug from the wall socket

Make sure that the power is OFF or that the available E-stop buttons have been activated.

Quadrel labeling heads are reliable, versatile and durable. They will operate for years with very light maintenance. Most of the maintenance takes only a few minutes and substantially increases the operational life of the machine and maintains label placement accuracy. Not all items listed below are applicable to every machine. See sections that apply to your equipment

Daily: D
Weekly: W
Monthly M
Semi-Annually S

ASSEMBLY TITLE: LABELING HEAD ASSEMBLY

- D- Remove glue residue and labels from all rollers and idler
- M- Check and tighten all fasteners.

ASSEMBLY TITLE: UNWIND ASSEMBLY

- W- Check and adjust dancer spring if final spring tension is too soft. Replace
- W- Check and inspect band brake. Replace if torn

ASSEMBLY TITLE: REWIND ASSEMBLY

- W- Check and inspect friction disc, Replace when worn out. (A-DRIVE only)
- W- Check kinetrol for leaks, Replace if necessary. (B-DRIVE only)

ASSEMBLY TITLE: BRAKE BRUSH ASSEMBLY

- W- Reverse brake brush direction.
- M- Inspect Brake brush when brush body contour no longer viable or bristles are worn down. Replace

ASSEMBLY TITLE: SLOT SENSOR ASSEMBLY

- D- Keep the sensor optical area clean from label and glue residue

ASSEMBLY TITLE: SIDE PLATE ASSEMBLY

- S- Check and inspect and grease all rollers and idler.

ASSEMBLY TITLE: PEEL PLATE ASSEMBLY

- D- Clean all the parts that may acquire labels or glue residue.
- W- Inspect Teflon tap on peel plate tip
- S- Check and inspect and grease all rollers and idler.

ASSEMBLY TITLE: DRIVE AND PINCH ROLL ASSEMBLY

- D- Remove glue residue and labels from drive roller.
- W- Clean with soft brass brush knurled roll.
- W- Check and inspect drive roll, No play when powered up
- S- Replace springs and slugs.

ASSEMBLY TITLE: ROLLER/BRUSH IMPRESSER

- D- Check the rollers/brushes free of label flash, glue and debris. This will prevent jamming and web tears.
- W- Check the foam rollers. If foam wear is noticeable, replace as necessary.

NOTE: Exercise caution when removing bad labels from foam. Careless removal can result in torn foam which may leave the labeler inoperable until the roller is replaced!

ASSEMBLY TITLE: OPERATOR PANEL

- No maintenance is required for the operator panel
- Occasionally, the keypad may be cleaned with any non-solvent based cleaning solution.

ASSEMBLY TITLE: ELECTRICAL

- W- Check the foam for fan clean or replace.

ASSEMBLY TITLE: ROLLER/BRUSH IMPRESSER

D- Check the rollers/brushes free of label flash, glue and debris. This will prevent jamming and web tears.

W- Check the foam rollers. If foam wear is noticeable, replace as necessary.

NOTE: Exercise caution when removing bad labels from foam. Careless removal can result in torn foam which may leave the labeler inoperable until the roller is replaced!

ASSEMBLY TITLE: TAMP PAD ASSEMBLY

D – Check the tamp pad for label flash, glue residue and debris on tamp pad. If found clean tamp pad with adhesive remover and/or cleaner

D – (**RFID REJECT PADDLE ONLY**) – Remove rejected labels from reject paddle at least 1 time per shift and/or as needed. **No more than 5-6 labels are to be on reject paddle at any time. Once 5-6 labels are on reject paddle they should be removed to ensure proper operation**

W – Lightly run scotch bright across pad to ensure it is lightly scuffed. A shiny pad could cause label to stick to the pad as it is dispensing

W – Check for air leaks around tamp pad block and pad. Reseal as necessary with RTV silicon sealant.

W – Inspect all pneumatic components for wear.

W – Lubricate Pneumatic cylinder slide rods

ASSEMBLY TITLE: OPERATOR PANEL

-No maintenance is required for the operator panel


-Occasionally, the keypad may be cleaned with any non-solvent based cleaning solution.

ASSEMBLY TITLE: ELECTRICAL

W- Check the foam for fan clean or replace.


NOTES:

Setup procedure for Powered rewind using MGC403-11-00MD drive




Upon receiving drive set the following **BEFORE** installing in the machine.

1. Dip switches - set all switches to the off position. This is the Light blue row of switches shown in the image below




- a.
2. Set Jumpers on drive based on electrical schematic for your machine
 - a. SIG1 – VDC
 - b. SIG2 – VDC
 - c. J504 – A90
 - d. AMP CURRENT – 1.7A – This located near the 10 pin green connector that



i.


3. Using a small flat blade / Slot screwdriver adjust the following pots as indicated in the image below:



- a.
- i. Top row **OFS1** – WILL BE ADJUSTED AT LATER STEP
 - ii. Top row – **FACC** - turn counter clockwise until it stops.
 - iii. Top row **FWCL** – set to half way point – midpoint
 - iv. Middle row - **OFS2** – turn counter clockwise until it stops. This turns the pot OFF
 - v. Middle row – **RACC** - turn counter clockwise until it stops
 - vi. Middle row – **RVCL** – set to half way point – midpoint
 - vii. Bottom row – **MAX** – Set to 3/4 point
 - viii. Bottom row – **Leave other 2 pots at factory setting – DO NOT ADJUST**



4. Install drive in machine then proceed to next steps

5. Set the Cam on the rewind dancer per image below when the dancer arm is at rest. Rest is when the arm is all the way back against the rubber bumper as shown






6. On the HMI go to into labeling head service menu. You will be looking at the REWIND PROX VOLTAGE (example below)



7. Adjust the sensor gap at the cam by loosening the bolt using an allen key so that the sensor can be moved forward or backward. The bolt does NOT touch the sensor. Loosening it opens the clamp so you can adjust.
8. Set the gap so the REWIND PROX VOLTAGE on the HMI reads **.90 it must be under 1 volt.**
 - a. **Retighten screw so the clamp sensor no longer moves**



b.

9. Test by moving the rewind dancer arm forward. When doing this you should see the rewind prox voltage on the HMI increase up to 9 volts

a. If you do not see the voltage increase steadily, recheck cam sensor gap in step 7

10. Turn on rewind switch on the back of the labeler. This will engage / turn on the motor.
11. Move the rewind dancer arm forward the rewind hub should start to turn clockwise. It will slow then stop as you move forward. Rewind hub should ALWAYS be turning clockwise. If it moves counter clockwise move to **step 11a**
 - a. While holding the arm in the position where it started to run counter clockwise, it MUST be running counter clockwise, you will adjust **OFS1** until the rewind hub stops moving.



i.


- b. This adjustment may need to be done multiple times until it no longer moves counter clockwise when rewind arm is all the forward and at rest.

9.2 BELTS


Monthly, a visual inspection of the rewind belt and timing belt, to do this depending on the labeling head you may need to remove the bottom cover on the head.

Refer to photos below.

Servo labeling head.



Stepping labeling head.





CAUTION

DO NOT ATTEMPT doing this with the equipment under tension (with power on).

The visual inspection should consist of looking for cracks or defects in the belts. If this is the case, change the belts that are defective. Refer to the parts listing in the labeling head section of this manual.

The brake band mechanism requires a monthly visual inspection as well. Also once every 12 months you should consider replacing the belt (it is possible that you may need to change it later or earlier than 12 months depending the usage of the labeling head).

The brake band belt assembly is located at the base of the unwind assembly. See images below for reference.





For replacement parts see the unwind assembly drawing for your labeling head in this manual.

9.3 ROLLERS

It is important that your labeler is as clean as possible in its environment in order for it to perform properly. Daily, it is suggested to clean all the rollers including the drive roller (the rubber roller), the pressure shoe and peel plate using a damp cloth with alcohol. Make sure those parts have no glue or labels on it.

Weekly, spray a silicone base lubricant on each end of the plastic bearing.



9.4 SENSORS



The sensors all have an electronic eye called a photocell; these must be free of lint or dirt. Since the photocells are generally made with glass or plastic lenses. They naturally attract substances which could easily trigger the sensor, use a cotton swap to gently clean the eye of the sensor as you would any lens, in a circular motion.

9.5 CONVEYOR

Always keep the belt or (chain) clean. To clean it simply use compressed air with an osha approved nozzle and/or damp wipes. If necessary, a soft cleaning agent can be used.

9.5.1 CLEANING

To clean the under carriage portion of the conveyor, simply remove the belt using an punch or similar tool and hammer to tap out the retaining belt link pin. (see images below, the chain has an orientation to the pins, you must tap it out from the narrow diameter) Clean the desired portion with a damp cloth and replace the pin to the belt. The pin will be tapped in the opposite side you tapped it out. *You can also lift the chain and wipe under it.



10 CLEARING A JAM

In the event a jam occurs on your Quadrel Labeler reference the following steps to clear.

1. Press the conveyor stop button or the emergency stop if you are unable to reach the stop button.
2. Clear the jam manually in the affected area of the equipment where jam is located
3. Once jam is cleared reenergize the estop, if pressed, and press the reset button (where applicable) to clear faults.
4. Put equipment back into "run" and press start to turn the system back online to continue labeling

11 WARRANTY

The standard warranty period for Quadrel equipment is 12 months following invoicing. The warranty covers all parts with consideration taken towards reasonable use and normal wear and tear. Not covered by warranty are parts that have a limited wear factor, any required labor by Quadrel. Prior to return to Quadrel, parts must be verified defective.

Return of defective parts

To return a defective part, you will need to get an RMA number from Quadrel. All RMA's are issued through our parts department. Please specify the serial number of the equipment, the client's name, address, phone number, contact name and the nature of the problem. To get a replacement part, a purchase order is required. You will be billed for the new part and credited for the defective part after return and evaluation. If the part is determined to be defective due to improper use, no credit will be issued.

Appropriate Use of Equipment

The equipment supplied to the end user by Quadrel are to be used for the sole purpose for which they were intended and must follow Quadrel's specifications on usage as well as appropriate functions. Quadrel will not assume any responsibility for any inappropriate use or modifications to the said equipment other than for the use it was initially built for.

The warranty will cease to apply forthwith, in Quadrel's opinion, the equipment has been used abnormally or in an abusive manner, if it has not been properly maintained, if it has not been carried on a truck equipped with an air-ride suspension when required by Quadrel or if it has been used, or maintained contrary to the owners manual provided by Quadrel.

Responsibility Limits

The solution put forth has been prepared with the information that has been provided to Quadrel by the end user. Subsequently, Quadrel cannot assume any responsibility for the exactitude, precision, and the validity of the information which was supplied. Moreover, Quadrel cannot be responsible for (a) any damages, direct or indirect, secondary, or

accessory, including without limitations, the loss of profit, workflow interruption, loss of production, loss of profits and other; (b) any and all damages claimed against the end user by a third party; (c) any or all damages caused to the property of end user or any other third party; (d) any or all resulting in an act from the end user or third party, major force, or act of god, unforeseen cause, or event.

With all reservation, in the eventuality where the responsibility is that of Quadrel relative to any defect of quality of said equipment or proposed solution Quadrel would be able to accept the responsibility, to its entire discretion, with the replacement of part of the said equipment or solution. By a compatible or identical equipment or solution or by a reimbursement of value agreed upon. In no case can Quadrel's responsibility exceed the total monetary sums received for the said defective equipment or solution.