

QUADREL

LABELING SYSTEMS

Operating & Maintenance
Manual
For

ENGINEERED PACKAGING SYSTEMS

TECHLINE

FRONT/BACK/WRAP

Automatic Labeling System

Labeler Model #: Q120 STEPPER
Serial #: 84224-100

QUADREL LABELING SYSTEMS
7670 Jenther Drive
Mentor, Ohio 44060
440.602.4700

customerservice@quadrel.com
parts@quadrel.com

TERMS AND CONDITIONS OF SALE
QUADREL, INC
D/B/A Quadrel Labeling Systems Hereinafter Referred to as Quadrel

PERFORMANCE GUARANTEE:

If the surface of the product to be labeled is free from contamination so as to ensure proper label adhesion, the labels are manufactured in accordance with label specifications provided and the equipment is operated and maintained in accordance with the instructions contained in the Quadrel manual (two copies of the manual will be supplied by Quadrel with the labeling system; one printed copy, and one electronic copy). Quadrel guarantees the EQUIPMENT to perform after installation as stated.

1. Provided a sufficient amount of products are presented to the labeling system.
2. Dimensional inconsistency from one like product to be labeled to the other may result in additional label placement inaccuracy in direct relationship to the product inconsistency.
3. Slitting inconsistency within a given roll of labels or from one like roll to another may result in additional label placement inaccuracy in direct relationship to the slitting inconsistency.
4. If the Quadrel labeling system proposed herein does not include physical control of the product during label application, additional placement inaccuracy can occur in direct relationship to the product control inconsistency.
5. Label Placement Accuracy: Within Sigma 2 (approximately 95.5%) to be normal.

In the event of the failure if the Quadrel system to meet customer's specifications, as quoted by Quadrel or subsequently agreed to by Quadrel. Quadrel upon written notice from buyer shall, at its option, repair the system, or refund the purchase price upon return of the system. The warranty provided in this article and the obligations and liabilities of Quadrel thereunder are exclusive and in lieu of, and buyer hereby waived, other remedies warranties, guarantees or liabilities, express or implied arising by law or otherwise (including without limitation, any obligations of Quadrel with respect to fitness for a particular purpose, merchantability, specific performance, incidental and consequential damages) whether or not occasioned by Quadrel's negligence. This warranty should not be extended altered or varied except by written instrument signed by Quadrel and buyer.

EXCLUSIVE TERMS OF SALE: The proposal attached hereto or to which these Terms and Conditions of Sale apply (the "Proposal"), together with these Terms and Conditions of sale (collectively, the "Sale Agreement"), constitutes the complete and exclusive statement of the agreement between Quadrel and the purchaser specified in the Proposal ("Purchaser") concerning the equipment and other goods specified in the Proposal (collectively, the "Equipment"), as well as any and all services specified in the Proposal (collectively, the "Services"), and supersedes all prior contemporaneous agreements, representations and/or communications, either oral or written, between Quadrel and Purchaser or any representative such as parties with the respect to the subject matter of the Sale Agreement. No change to the Sale Agreement or waiver of any provision thereof will be binding on Quadrel unless made in writing and signed off by and authorized officer of Quadrel. Acceptance of the Equipment, in whole or part, or other express or implied assent by Purchaser to the terms hereof shall constitute Purchaser's agreement to the terms of the Sale Agreement. Acceptance of any purchase order or other document of Purchaser by Quadrel is expressly made conditional on the Purchaser's assent to the Sale Agreement. ANY ATTEMPTED MEMORIALIZATION OF THIS SALE BY A PURCHASE ORDER OR OTHER DOCUMENT CONTAINING TERM AND CONDITIONS INCONSISTANT WITH OR IN ADDITION TO THE CONDITIONS CONTAINED IN THE SALE AGREEMENT SHALL NOT BE BINDING UPON QUADREL AND QUADREL HEREBY EXPRESSLY OBJECTS TO AND REJECTS THE SAME.

GENERAL WARRANTY (EXCLUDES TABLETOP LABELERS)

Time from date of shipment	Covered Expenses
Up to 90 Days	All Parts , service time, living and travel expenses
UP to 12 Months	All parts

THE WARRANTIES PROVIDED ABOVE ARE IN LIEU OF ANY AND ALL OTHER WARRANTIES AND LIABILITIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. NO OTHER WARRANTIES ARE OFFERED BY QUADREL WITH RESPECT TO THE EQUIPMENT OR SERVICES AND QUADREL HAS NOT AUTHORIZED ANY EMPLOYEE OR AGENT TO OFFER ANY WARRANTIES EXCEPT THOSE PROVIDED ABOVE. PURCHASER AND QUADREL EXPRESSLY AGREE THAT THE WARRANTIES PROVIDED ABOVE SHALL SERVE AS PURCHASER'S SOLE AND EXCLUSIVE REMEDY WITH RESPECT TO THE EQUIPMENT AND SERVICES.

PURCHASER REQUIREMENTS. Purchaser must provide Quadrel descriptions and specifications of all labels and items to be labeled, including, without limitation, label material, product and label dimensions, and any other items required by Quadrel. Further, purchaser shall furnish Quadrel one (1) production size roll of each label and 100 samples of each item to be labeled for testing purposes. **Quadrel shall have no liability (whether under its Limited One-Year Warranty or otherwise) for labeling performance on labels or items to be labeled:**

- (a) Which were not specified or sufficiently described in the Proposal: or**
- (b) With respect to which Purchaser fails to provide Quadrel the samples specified herein, even if such labels or items to be labeled were specified in the Proposal. Further, Quadrel shall have no liability for delays caused by Purchaser's failure to furnish samples as specified herein.**

LIMITATION OF WARRANTIES. Quadrel shall have no obligation to honor its warranties and shall have no liability with respect to defective Equipment if:

- (a) The Equipment has been modified, altered, damaged, abused or used for any other than those purposes intended by Quadrel.
- (b) The Equipment has been changed without prior written consent from Quadrel.
- (c) The equipment has not been operated and maintained in accordance with generally accepted commercial practices for similar equipment and Quadrel's specifications and instructions, as published in the Quadrel manual.
- (d) The surface if the product to be labeled is not clean and free of contamination, including, but not limited to, mold release agents, condensation, dirt and oil.
- (e) Labels are not manufactured in accordance with label specifications provided by Quadrel, or are not from defects such as cracked edges, deep die strikes, *etc.*
- (f) Labels and items to be labeled are not set forth in the Proposal.
- (g) Samples of all products and labels were not provided to Quadrel for testing prior to Equipment shipment as required under "Purchaser Requirements" outlined above.
- (h) There is dimensional inconsistency from one like roll of labels to another.
- (i) *The Equipment does NOT include physical control of the product.*

LIMITATION OF REMEDIES. All warranty claims shall be subject to review and approval by Quadrel. Quadrel's obligation to honor warranties is in all cases limited to, at Quadrel's sole option:

- (a) Repair of defective Equipment or components: or
- (b) Providing a cash refund or credit, after Purchaser has returned Equipment to Quadrel.

Where warranty service is to be provided at the Quadrel facility, Purchaser shall return Equipment claimed to be defective to Quadrel, freight prepaid, for review. No Equipment shall be returned to Quadrel, whether for inspection, repair, refund, or any other reason, without prior return authorization from Quadrel. Quadrel may charge Purchaser cost resulting from testing, handling and disposition of Equipment claimed to be defective by Purchaser which is found by Quadrel to conform to Quadrel's warranties.

LIMITATION OF LIABILITY. QUADREL SHALL HAVE NO LIABILITY FOR ANY CONSEQUENTIAL, INCIDENTAL, PUNITIVE OR SPECIAL DAMAGES BY REASON OF ANY ACT OR OMISSION OR ARISING OUT OF OR IN CONNECTION WITH THE (a) EQUIPMENT OR ITS SALE, DELIVERY, INSTALLATION, MAINTENANCE, OPERATION, OR PERFORMANCE, OR (b) SERVICES. IN NO EVENT SHALL QUADREL'S LIABILITY EXCEED THE PRICE OF THE EQUIPMENT (OR THE PRICE OF THE SERVICES IF A CLAIM IS MADE WITH RESPECT TO THE SERVICES) WITH RESPECT TO WHICH A CLAIM IS MADE REGARDLESS OF WHETHER SUCH CLAIM IS BROUGHT

AT LAS OR IN EQUITY AND REGARDLESS OF WHETHER SUCH CLAIM IS BROUGHT UNDER CONTRACT, BREACH OF WARRANTY, TORT OR ANY OTHER THEORY OF LAW OR EQUITY.

ORDERS:

Orders entered, verbal or written, cannot be cancelled except upon terms that will compensate Quadrel against any and all claims

START-UP SERVICE:

Quadrel will provide, at standard installation rates, the number of normal eight-hour working days for the Quadrel Field Service Technician to start the EQUIPMENT and to train PURCHASER'S operating and maintenance personnel. EQUIPMENT is not uncrated and emplaced in desired location by PURCHASER prior to arrival of Quadrel Field Service Technician, or if the EQUIPMENT cannot be made operational due to non-availability of products, labels, appropriate utilities and/or related production equipment, PURCHASER shall pay Quadrel for additional service time required including travel expenses, if applicable, in accordance with Quadrel's Field Service rates. It is PURCHASER's obligation to schedule the start-up service at a time when PURCHASER'S engineering, maintenance and selected production personnel are available.

SERVICE AFTER INSTALLATION:

Quadrel Field Service Technicians are available to customers who do not maintain their own service departments. This can be handles on a per visit basis. Field Service rates are available on request.

PAYMENT TERMS:

Payment terms are as follows: 50% of purchase with purchase order, 40% of purchase at the time of shipment, 10% of purchase (plus freight charges) due net 30 days. If shipment is delayed beyond 30 days after the EQUIPMENT has been made ready for shipment, and the delay is caused directly or indirectly by the PURCHASER, then the total of the unpaid balance, at option of Quadrel, may become immediately due and payable upon written notice. Payments not paid when due shall thereafter bear monthly service charges at the rate of 1.5% per month on the unpaid balance until paid. If, in Quadrel's opinion, PURCHASER'S financial condition does not justify continuance of production or shipment on the terms of payment specified above, Quadrel may require payments in advance.

FINANCIAL IMPAIRMENT. Quadrel may, at its option, suspend performance if in its opinion the credit of the Purchaser becomes impaired until such time as Quadrel has received full payment, including any general price increases or surcharges, is satisfactory security for deliveries made and is satisfied as to Purchasers credit for future deliveries. Quadrel reserves the right to cancel Purchaser's credit at any time for any reason. In addition, Quadrel reserves the right by written notice to cancel any order or require full or partial payment or adequate assurance of performance from Purchaser without Liability to Quadrel in the event of:

- (a) Purchaser's insolvency
- (b) Filing of a voluntary petition in bankruptcy by Purchaser
- (c) Filing of an involuntary petition in bankruptcy against Purchaser
- (d) Appointment of a receiver or trustee for Purchaser
- (e) Execution by Purchaser of an assignment for the benefit of creditors

TAXES:

The amount of any present or future federal, state, local or other taxes applicable to the sale of EQUIPMENT shall be added to the price and paid by PURCHASER unless PURCHASER provides a valid exemption certificate acceptable to Quadrel and the appropriate tax authority.

GOVERNING LAW AND JURISDICTION. The sale agreement shall be governed and construed in accordance with the domestic laws of the State of Ohio without giving effect to any choice or conflict of law provision or rule that would cause the application of the laws of any jurisdiction other than the State of Ohio. Any legal action, suit or proceeding relating to the Sale Agreement shall be heard and determined exclusively in the United States District Court for the Northern District of Ohio or the Court of Common Pleas of Lake County, Ohio, and each party irrevocably submits to the jurisdiction of either such courts and waives any objection which such party may have to the laying of venue of any such legal action, suit or proceeding in any such court.

The Sale Agreement shall not be governed by the United Nations Convention on the International Sales of Goods. No actions arising out of the sale of Equipment or Services may be brought by either party more than one (1) year after shipment.

RETURNS:

EQUIPMENT sold by Quadrel is returnable only in accordance with the provisions hereof. Before returning of any EQUIPMENT or items thereof, PURCHASER must obtain Quadrel's written return authorization and instructions.

FORCE MAJEURE:

Quadrel shall not be liable for any loss, damage, delay, changes in shipment schedules or failure to deliver due to act of God, accidents, fires, strikes, riots, civil commotion, insurrection, war, the elements, embargoes, failure of carriers, inability to obtain electricity or other type of energy, transportation facilities, raw material, equipment or any problem or any similar or different contingency beyond its reasonable control which would make performance commercially impractical whether or not the contingency is of the same class as those above. Quadrel shall in no event be liable for any consequential damages.

TITLE AND RISK OF LOSS:

Title and risk of loss to EQUIPMENT shall pass to PURCHASER upon delivery by Quadrel to a common carrier, regardless of the freight terms stated or method of payment for transportation charges. Quadrel reserves the right to specify routing of shipments.

ENTIRE AGREEMENT:

This agreement embodies the entire agreement and understanding between the parties, is intended as complete and exclusive statement of terms of the agreement between the parties and supersedes any prior agreements or understandings between the parties relating to the subject matter hereof. PURCHASER acknowledges that Quadrel has not made any representations to PURCHASER other than those which are contained herein. Except as provided in this agreement, no change in or addition to the terms contained herein shall be valid as between the parties unless set forth in writing which is signed by an authorized representative of both parties and which specifically states that it constitutes an amendment to this agreement.

The parties may use their normal commercial forms in connection herewith: however, any such forms shall be used for convenience only and any terms or provisions which may be contained therein inconsistent with or in addition to those contained herein shall have no force or effect whatsoever between parties hereto.

EFFECTIVE:

This proposal is based upon the current cost of labor and materials and shall remain in effect for a period of sixty (60) days from the date hereof unless revoked by Quadrel in writing prior to acceptance.

INDEMNIFICATION:

The purchaser of this product ("Customer") hereby agrees to release, indemnify and hold harmless Quadrel and its agents, assignees and representatives for any and all liabilities, losses, costs, damages and expenses (including attorneys' fees and expenses) arising, directly or indirectly, from any and all manner of claims, demands, actions and proceedings that may be instituted against Quadrel on any grounds.

The Customer agrees to, at the Customer's own expense, promptly defend and continue the defense of any such claim, demands, actions or proceeding that may be brought against Quadrel, provided that Quadrel shall, within thirty (30) days of Quadrel receiving notice thereof, notify the Customer of such claims, demand, action or proceeding.

Quadrel shall at all times retain the right to defend itself and/or to otherwise participate in the defense of any such claim or action, and no settlement or other resolution of any such claims or action shall be finalized without Quadrel's written approval. Any failure by Quadrel to give prompt notice or provide copies of documents or furnish relevant data shall not constitute a defense in whole or in part to any claim by Quadrel against the Customer except to extend that such failure by Quadrel shall result in a material prejudice to the Customer.

The forgoing notwithstanding, if suit shall have been against Quadrel and the Customer shall have failed, after the lapse of a reasonable time after written notice to it of such suit, to take action to defend the same. Quadrel shall have the sole right to

defend the claim and shall be entitled to charge the customer with the reasonable cost of any such defense, including reasonable attorney’s fees, and Quadrel shall have the right, after notifying but without consulting the Customer, to settle or compromise such claim on any terms reasonably provided by Quadrel.

This release and indemnification is and shall be binding upon the Customer, as well as the Customer’s respective heirs, subsidiaries, affiliates, successors, assigns, agents and employees. If any provision or provisions of this release and indemnification shall be held to be invalid, illegal or unenforceable for any reason whatsoever, the validity, legality and enforceability of the remaining provisions of this Agreement shall not in any way be affected or impaired thereby. No supplement, modification or amendment of this Agreement shall be binding unless executed in writing by all of the parties hereto.

Any order put on hold or left dormant for any reason for 90 days will be considered cancelled. See Cancellation Policy below.

CANCELLATION POLICY:

In the event of order cancellation, the 50% down payment is non-refundable. Customer may also be responsible for additional charges covering engineering resources expended and committed materials depending upon the custom nature of the project and the point in the order process in which the cancellation occurs.

NOTE. No salesman, representative or agent of Quadrel is authorized to give a guarantee, warranty or make any representation contrary to above.

Please sign and acknowledge acceptance to these terms and conditions _____ Date _____




TABLE OF CONTENTS

1	MANUAL PREFACE
2	GENERAL DISCRIPTION
3	WARNING/CAUTION SAFETY INSTRUCTION
	3.1.1 SAFETY INTEGRATION
	3.1.2 GENERAL SAFETY INFORMATION
4	INSTALLATION / REASSEMBLY INSTRUCTIONS
5	HMI GUIDE
6	SET UP SHEETS
7	LABELING HEAD
	7.1.1 LABELING HEAD INFORMATION
	7.1.1.1 LOADING AND UNLOADING STOCK ROLL
	7.1.1.2 THREADING DIAGRAMS
	7.1.1.3 LABELER ADJUSTMENTS
	7.1.1.4 FUNCTION, OPERATION, & TROUBLESHOOTING
	7.1.2 SIDE PLATE ASSEMBLY
	7.1.2.1 ASSEMBLY WRITE UP
	7.1.2.2 DRAWING
	7.1.3 UNWIND ASSEMBLY
	7.1.3.1 ASSEMBLY WRITE UP
	7.1.3.2 DRAWING
	7.1.4 IMPRINTER MOUNT – (OPTIONAL)
	7.1.4.1 ASSEMBLY WRITE UP
	7.1.4.2 DRAWING
	7.1.5 PEEL PLATE ASSEMBLY
	7.1.5.1 ASSEMBLY WRITE UP
	7.1.5.2 DRAWING
	7.1.6 BRUSH IMPRESSER ASSEMBLY – (OPTIONAL)
	7.1.6.1 ASSEMBLY WRITE UP
	7.1.6.2 DRAWING
	7.1.7 DRIVE AND PINCH ROLL ASSEMBLY
	7.1.7.1 ASSEMBLY WRITE UP
	7.1.7.2 DRAWING
	7.1.8 STEPPER/SERVO MOTOR DRIVER ASSEMBLY
	7.1.8.1 ASSEMBLY WRITE UP
	7.1.8.2 DRAWING
	7.1.9 REWIND ASSEMBLY
	7.1.9.1 ASSEMBLY WRITE UP

- 7.1.9.2 DRAWING
 - 7.1.10 SLOT SENSOR ASSEMBLY
 - 7.1.10.1 ASSEMBLY WRITE UP
 - 7.1.10.2 DRAWING
- 7.2 LABELING HEAD FAULTS – **(OPTIONAL)**
 - 7.2.1 ASSEMBLY WRITE UP
 - 7.2.2 DRAWING
 - 7.2.3 END OF WEB / BROKEN WEB / LOW LABEL
- 8 MECHANICAL COMPONENTS
 - 8.1.1 FRAME ASSEMBLY
 - 8.1.1.1 ASSEMBLY WRITE UP
 - 8.1.1.2 DRAWING
 - 8.1.2 CONVEYOR ASSEMBLY
 - 8.1.2.1 ASSEMBLY WRITE UP
 - 8.1.2.2 DRAWING
 - 8.1.3 HEAD SUPPORT ASSEMBLY
 - 8.1.3.1 ASSEMBLY WRITE UP
 - 8.1.3.2 DRAWING
 - 8.1.4 PACING WHEEL/BELT ASSEMBLY/FEEDSCRW
 - 8.1.4.1 GENERAL INFORMATION
 - 8.1.4.2 ADJUSTMENTS
 - 8.1.4.3 ASSEMBLY WRITE UP
 - 8.1.4.4 DRAWING
 - 8.1.5 WRAP STATION ASSEMBLY
 - 8.1.5.1 GENERAL INFORMATION
 - 8.1.5.2 ADJUSTMENTS
 - 8.1.5.3 ASSEMBLY WRITE UP
 - 8.1.5.4 DRAWING
 - 8.1.6 BACK UP PLATE ASSEMBLY
 - 8.1.6.1 GENERAL INFORMATION
 - 8.1.6.2 ADJUSTMENTS
 - 8.1.6.3 ASSEMBLY WRITE UP
 - 8.1.6.4 DRAWING
 - 8.1.7 TOP HOLD DOWN ASSEMBLY
 - 8.1.7.1 GENERAL INFORMATION
 - 8.1.7.2 ADJUSTMENTS
 - 8.1.7.3 ASSEMBLY WRITE UP
 - 8.1.7.4 DRAWING
 - 8.1.8 PRODUCT DETECT ASSEMBLY
 - 8.1.8.1 ASSEMBLY WRITE UP
 - 8.1.8.2 DRAWING
 - 8.1.9 CHAIN ALIGNER / HUGGER BELT ASSEMBLY – **(OPTIONAL)**
 - 8.1.9.1 GENERAL INFORMATION
 - 8.1.9.2 ADJUSTMENTS
 - 8.1.9.3 ASSEMBLY WRITE UP

8.1.9.4 DRAWING

8.1.10 ROTARY ACTUATOR SQUEEGEE ASSEMBLY – **(OPTIONAL)**

8.1.10.1 GENERAL INFORMATION

8.1.10.2 ADJUSTMENTS

8.1.10.3 ASSEMBLY WRITE UP

8.1.10.4 DRAWING

8.1.11 STOP GATE ASSEMBLY / BLADDER – **(OPTIONAL)**

8.1.11.1.1 GENERAL INFORMATION

8.1.11.1.2 ADJUSTMENTS

8.1.11.1.3 ASSEMBLY WRITE UP

8.1.11.1.4 DRAWING

8.1.12 INFEED / OUTFEED BANK SENSORS – **(OPTIONAL)**

8.1.12.1.1 GENERAL INFORMATION

8.1.12.1.2 ADJUSTMENTS

8.1.12.1.3 ASSEMBLY WRITE UP

8.1.12.1.4 DRAWING

8.1.13 EJECT STATION ASSEMBLY – **(OPTIONAL)**

8.1.13.1.1 GENERAL INFORMATION

8.1.13.1.2 ADJUSTMENTS

8.1.13.1.3 ASSEMBLY WRITE UP

8.1.13.1.4 DRAWING

9 ELECTRONICS / SCHEMATICS

10 MAINTENANCE

10.1.1 GENERAL INFORMATION

10.1.2 BELTS

10.1.3 ROLLERS

10.1.4 SENSORS

10.1.5 CONVEYOR

10.1.6 CLEANING

10.1.7 WARRANTY



Quadrel Labeling Systems Quality Manual

Quality Statment:

Quadrel Labeling Systems strives to provide our customers with the highest quality labeling/sleeving solutions available on the market. In order to achieve total customer satisfaction, we shall adhere to the following objectives:

100% on-time delivery

zero defects

Value added service and support

Engineered solutions

Employee development and diversity

We will commit to continuously improve each facet of our business operations through implementation of, and compliance of this manual.

Chuck Wepler
General Manager / President

Approved by: Jim Brazee
Issue Date: 1/1/2018

1 **MANUAL PREFACE**

Thank you for choosing Quadrel Labeling Systems. We have designed and manufactured this equipment with the upmost pride and care ensuring you the absolute best quality, maximum versatility and reliability.

This equipment is intended to be used only as described in this document. Quadrel Labeling Systems Inc. cannot be held responsible for the improper use or functioning of non-described functions of this machinery. Liability for any personal injury, loss of production or revenues, or property damage occasioned by the use of this manual in effect maintenance, operation, or repair of the equipment is in no way assumed by Quadrel Labeling Systems Inc. Anyone one using a procedure not recommended by the end user should first completely satisfy himself/herself that personal safety and equipment integrity will not be jeopardized in the method selected.

DO NOT attempt to install, operate, or adjust the labeling system without first reading and understanding the contents of this manual.

Only a trained person is to be permitted to operate this equipment. Training should include instruction in operation under normal conditions and emergency situations. Under no circumstances should an untrained person operate this machine.

This manual will provide operating instructions, parts listing and schematics. The information contained in this manual will help the user in his/her operations, troubleshooting, and maintaining the machine in good operating conditions. Information, illustrations and specifications contained in this manual are based on the latest product information available at the time of this manual release. Quadrel Labeling Systems Inc. reserves the right to alter and substitute information contained herein at any time.

Due to the customization it is also possible that you have received a different variation of this equipment, with several different options. Some pictures used in this manual may not totally reflect your configuration, although the labeling is completely the same.

All rights reserved while every precaution has been taken in the preparation of this manual, Quadrel Labeling Systems Inc. cannot be held responsible for errors, omissions, damages, loss of production, or revenues resulting from the use of the information contain herein.

2 GENERAL DISCRIPTION - TECHLINE

In-line labeling machines apply labels to a wide variety of container shapes. In addition to conventional cylindrical containers, the in-line labeler can be used with specially contoured, elliptical or flat-sided containers. In-line labelers are manufacturing in a variety of configuration. Diagrams illustrate standard in-line labeler arrangements for different container designs.

The Techline labeling system is a high performance, economically priced labeling system for front/ back, wrap or custom applications with production rates up to 275 ppm. Built with quality, versatility and durability from the bottom up. This system surpasses all equipment in its price range and is suitable for multi-shift operations where long-term reliability is important. All critical components are designed for 24/7 reliability. The versatility of Techline makes it ideal for contract packagers or companies requiring frequent changeovers on a wide variety of products. Features such as PLC control with color touchscreen and simple “no tool/ no change parts” operation provide maximum flexibility for today’s packagers. This system has a compact footprint, suitable for harsh/ multi-shift environments. Allen-Bradley PLC control with color touchscreen with 50 programmable product presets. Encoder-based speed compensation. AC inverter controlled product handling. Ideal for Pharmaceutical, Food, Personal Care, Automotive and other markets.

3 WARNING/CAUTION SAFETY INSTRUCTION

Where safety is dependent upon starting or stopping devices, or both, they are to be kept free of obstructions that could endanger personnel.

The areas around loading and unloading points are to be kept free of obstructions that could endanger personnel. Instruct personnel working on or near this equipment as to the location and operation of pertinent stopping devices.

This equipment is to be used only for the purpose for which it is constructed.

Under no circumstances are the safety characteristics of this equipment to be altered.

Conduct routine inspections and corrective / preventive maintenance measures to ensure that all guards are installed and function properly. Alert personnel to the potential hazards indicated by the safety labels on this equipment.

3.1 SAFETY INTEGRATION

The end user's safety risk assessment will be the guiding document for proper integration of the equipment provided. Consideration of the following guidelines is recommended in order to achieve a safe result:

- Open areas under the equipment are to be guarded by the end user to prevent entry.
- Where conveyor flight lugs or product enters or exits the equipment, proper guarding and interlock are put in place by the end user to ensure mitigation of shear/jam points.
- The end user is responsible for properly guarding drive components on equipment that requires mechanical drive integration.

3.2 GENERAL SAFETY INFORMATION

This Quadrel Labeling System is engineered to feed and apply labels on your products. In designing the device, Quadrel valued personal safety; however we would like to draw your attention to the following safety acknowledgments.



WARNING

Hazards or unsafe practices, which **COULD** result in severe personal injury or death.



CAUTION

Hazards or unsafe practices, which **COULD** result in minor injury



CAUTION

The presence of safety systems in these units does not exempt the operators to act cautiously, avoiding behaviors that could

endanger their health or the equipment. These models are engineered to feed and apply labels on your products. In designing this device, Quadrel valued personal safety; however we would like to draw your attention to the following safety acknowledgments.

- Operators should know the basic operations and setup procedures before operating this equipment.
- Safe operations should be maintained at all times.
- Know the location of E-stops and power switches prior to operating machinery such as this.

WARNING

To reduce risk of fire, electrocution, or other personal injury when operating. Follow basic safety precautions, including the following:

- This equipment must have an operator attending the machine at all times to monitor the operations. **DO NOT** leave this equipment unattended during maintenance or perform any maintenance unless the e-stop condition has been activated or power turned off.
- The electrical power to device is: ____220__ Volts, ____SINGLE (1)____Phase, ____60____Hz, ____15____Amps. While installing make sure it's properly configured and connected by a qualified electrical technician.
- **DO NOT** by pass any of the safety circuits or safety features designed into this equipment.



- ALWAYS turn off **power and pneumatics** before performing repairs.
- The doors on all electrical enclosures must be closed. All covers on labeling heads must be on labeling heads. (if applicable)
- This device is built to perform in humid conditions, but must not be pressure washed. Wiping down the device is the recommended cleaning method.



- Do not stand, sit, or allow any personnel to be within reach of the tamp cylinder/ swing arm activation (if so equip).
- Report any malfunctions, or problems with the equipment to qualified maintenance personnel for repair or adjustments that may be required.
- Keep hands clear of moving parts. Do not place hands near labeling head when in operation.

For systems containing conveyors, you must be vigilant with loose clothing or bodily parts as they can get caught in the conveyor's belt or chains as direct injury or death can incur. **DO NOT** use the conveyor as a working platform or walkway.

TUCK IN ANY LOOSE CLOTHING. DO NOT WEAR TIES. PENDANTS, JEWELRY OR ANY OTHER ARTICLE OF CLOTHING OR ACCESSORY THAT MAY GET CAUGHT ON ANY PORTION OF THE SYSTEM.

FOR PROLINE SYSTEMS ONLY

CASTERS WERE IMPLEMENTED FOR EASE OF SHIPPING PURPOSES ONLY. PLEASE USE CAUTION WHEN MOVING PROLINE THROUGH FACILITY. THE PROLINE RECOMMENDED USE: SET IN PLACE/POSITION WITH LEVELING PADS DOWN TO SECURE.

WARNING

1. READ AND UNDERSTAND THE OPERATION MANUAL AND ALL SAFETY LABELS BEFORE OPERATING THIS MACHINE.
2. ONLY A TRAINED PERSON IS TO BE PERMITTED TO OPERATE THIS MACHINE. TRAINING SHOULD INCLUDE INSTRUCTION IN OPERATION UNDER NORMAL CONDITIONS AND EMERGENCY SITUATIONS.
3. THIS MACHINE IS TO BE SERVICED ONLY BY TRAINED AND AUTHORIZED PERSONNEL. FOLLOW LOCK-OUT PROCEDURES BEFORE SERVICING.
4. NEVER REACH INTO THE MACHINE FOR ANY REASON UNLESS THE MACHINE IS AT A COMPLETE STOP.
5. NEVER LEAVE THE MACHINE STOPPED IN SUCH A MANNER THAT ANOTHER WORKER CAN START THE MACHINE WHILE YOU ARE WORKING ON OR WITHIN THE MACHINE.
6. NEVER CHANGE OR DEFEAT THE FUNCTION OF ELECTRICAL INTERLOCKS OR OTHER MACHINE "SHUTDOWN" SWITCHES.
7. BEFORE STARTING THIS MACHINE, CHECK THAT: ALL PERSONS ARE CLEAR OF THE MACHINE; NO MAINTENANCE WORK IS BEING PERFORMED ON THE MACHINE, ALL GUARDS ARE IN PLACE.
8. ROUTINE INSPECTIONS AND CORRECTIVE/PREVENTATIVE MAINTENANCE MEASURES ARE TO BE CONDUCTED TO ENSURE THAT ALL GUARDS AND SAFETY FEATURES ARE RETAINED AND FUNCTION PROPERLY.

Using VFDs On GFCI Devices

By Bill Szatkiewicz, Senior Software Engineer

KB Electronics

for more information, email: info@kbelectronics.net

or visit: www.kbelectronics.com

The National Electrical Code, or NEC, continues to expand protection requirements for safety reasons resulting in an increase in Ground-Fault Circuit-Interrupter (GFCI) outlets being used in more environments. As a result, the Variable Frequency Drives (VFDs) industry is finding more instances of VFDs being powered from GFCIs. VFDs introduce high frequency harmonic content which may cause nuisance tripping on some GFCI devices. This paper is intended to assist anyone that needs to use a VFD on a circuit with GFCI protection. KB Electronics has developed special VFDs suitable for use with most GFCIs*.

* Please contact KB Electronics with information regarding your specific GFCI.

What is a VFD?

A VFD (also termed adjustable frequency drive, variable speed drive, AC drive, adjustable speed drive, micro drive, motor control, or inverter drive) is a power conversion device that will accept normal fixed branch circuit voltage of (115V or 230V) and frequency (50 Hz or 60 Hz) and allow the operator to control the speed of an induction motor (AC Motor) by varying the output voltage and frequency. A simplistic version of a typical VFD system is shown in Figure-1.

In addition to operator controllability, the VFD with soft start/stop features offers extended equipment life, increased performance, reduced maintenance, protection from excessive currents and voltages, as well as energy savings.




Figure-1: Typical VFD System

What is a GFCI?

A GFCI (shown in Figure-2) is a circuit breaker device which is designed to protect people from hazardous shock or electrocution by shutting off an electric power circuit when it detects current flowing in a way that it is not meant to, such as through water or a person.



Figure-2: Typical GFCI Outlet

The GFCI is intended to protect people from electrical shock, therefore, it is completely different from a fuse in the sense that it needs to shut off the electric power circuit at a low current, typically no more than 5 mA, in a quick amount of time (less than 1/10 of a second).

The GFCI does this by measuring and comparing the amount of current flowing in the ungrounded (hot) and grounded (neutral) conductors of the circuit. If the GFCI detects an imbalance in the circuit, it immediately shuts off the circuit.

Why Nuisance Trips Occur with Standard VFDs

Standard VFDs, when powered from GFCI outlets, can cause the GFCI to trip due to the leakage currents generated from the high switching frequency of the VFD's power devices and the harmonics associated with them. These high frequency leakage currents are not at the base frequency of the drive output which is normally 50 Hz or 60 Hz. These high frequency leakage currents, typically greater than 4 kHz, may cause the GFCI to trip because the GFCI is designed to work with 50 Hz or 60 Hz frequency inputs, not this higher value.

The high switching frequency of the VFD's power devices induce more capacitive-coupled currents, since a capacitor approximates a short circuit at high frequencies. This creates common-mode noise, referred to as leakage current, which travels through ground and can cause the GFCI to trip. The path to ground is made through the motor bearings or auxiliary equipment bearings.

In addition to the high switching frequency of the drive, there can be many other contributing factors which cause the GFCI to trip. Some drives have built-in filters which couple additional leakage current to earth ground. Other drives use external filters and replacing them with a low leakage filter may help.

One way to help determine if the GFCI tripping is occurring from the input filter or the VFD output is to remove either the input filter or the motor and observe if the GFCI still trips. For example, if the input filter is easily removed and doing so

prevents the GFCI from tripping, the source of the leakage currents tripping the GFCI was largely from the input filter.

Another method is to disconnect the motor. If doing so prevents the GFCI from tripping the contributing source of leakage current is most likely from the output stage of the VFD. However, most often than not, the GFCI is tripping from a combination of the two and improvements on both the input and output will help.

Long motor power cables can also create noise spikes. These long leads add more capacitance which increases noise spikes from the fast switching power devices of the VFD. Use a VFD rated cable with the shortest leads possible when connecting the motor power cables. A choke on the VFD's motor outputs may help reduce noise spikes.

In addition, ensure that motor cables are properly shielded, sized, routed, terminated, and grounded at both the motor and drive.

KB's GFCI Solution

KB's engineering team has studied VFDs powered from a variety of GFCI devices. A solution has been created which considers all contributing factors to get a best-case scenario that successfully works with most GFCIs.

KB investigated switching frequencies and developed custom switching frequency algorithms to reduce audible noise and leakage currents. High frequency noise spikes and ringing were reduced by modifying our proprietary power circuits for optimal results. In addition, output chokes, low leakage filters, and shielded cable were introduced, if needed, to find a GFCI solution.

Conclusion

KB has had great success providing VFDs that work with GFCIs for numerous original equipment manufacturers (OEMs). KB offers a full range of motor controls (shown in Figure-3) which can be customized to work with GFCIs. Let KB Electronics provide a solution for you.



Figure-3: VFDs Available from KB Electronics

Unboxing & Installation of your Quadrel Labeling Systems Machine

This section of your manual is aimed towards making the transition from Shipping Crate to Assembly line less Dramatic. If you have scheduled an install with one of our Professional Technicians the set-up of your machine will be a breeze. If not your manual as all of the information needed to get you going. In this section there may be some equipment shown that does not apply to the machine you purchased.

NOTE This is general instruction for all equipment (your equipment may vary slightly).

Let's get started...

First things first, check your crate/box/machine for damage. If there is damage please note the exception and contact Quadrel immediately. Any extra boxes or pallets will be either in your crate or tethered to the crate or pallet. Once you have inspected your shipment you can open the crate. Check packing slip Bill of lading against boxes received. Notify Quadrel of any discrepancies.



Carefully remove all banding on the legs, misc. boxes and assemblies in the crate or on the pallet. If your machine is



wrapped in bubble wrap or plastic wrap go ahead and carefully cut and remove that as well. Ensure you are wearing the appropriate safety gear when removing your machine from the crate.



Ensure all plastic wrap is removed from the assembly you are removing the support from before removing the support.

Remove the supports under your labeling heads, wrap station, top trap, HMI, Pacing wheel or belt. See images for various supported assemblies.



Most assemblies supported have a tool-less vertical adjustment using a knob or hand wheel.

The hand wheel may be wrapped to the assembly to prevent damage.


Remove the hand wheel from the wrap, then fasten the hand wheel to the square end on the lead screw using a 3/32 "L" handle Allen wrench.

Turn the handle/knob to raise the assembly this will take the weight off the supports so you can remove them.

Top Trap Support (top) Labeler Head Support (bottom) Plastic wrapped hand wheel (right)




All top and bottom labeling heads will be supported




similar to the image shown on the left.

Wrap stations will have supports similar to the image to the right. These supports do not require moving the assembly.

Pacing belt
assembly
supports can
be removed
will be
without raising
the assembly.




Pacing wheels
supported as shown





Often the head support will be moved in shipping or moved to be supported. When you are setting up your machine refer to your set up sheet in this manual. There are scales on the side of the assembly to line the carriage up to (as shown in the Image to the left and below).



Peel plates with or without the rods may be removed from the labeling head to move the head all the way in during shipping.

All assemblies removed will be bubble wrapped then plastic wrapped to the machine (as shown in image on the right) or in box on the pallet the machine is on (as shown in image below).



Mount the peel plate assembly using a 5/16 L handle Allen wrench (as shown in image on the left). The bolts are located in the assembly. You simply put the wrench in the quick change access holes to loosen or tighten the assembly.

NOTE When you are setting up your machine make sure the peel plate assembly is perpendicular to the conveyor. When the peel plate assembly is on the rods there is a small amount of play allowing you to make small adjustments to the assembly.

If you have the peel plate rods removed with the peel plate assembly and the label detect assembly (as shown below).

All assemblies removed will be bubble wrapped then plastic wrapped to the machine or in box on the pallet the machine is on.




First back the head out all the way. Locate your peel plate assembly and slide it into the holes in the drive roll assembly (as shown on the left of the image above). Make sure you take the bolts out of the end of the rods before putting them into the drive roll assembly.



Fasten the assembly to the drive roll with the bolts supplied using a 5/16 L handle Allen wrench. Make sure you have the lock washers on the bolts.

NOTE When you are setting up your machine make sure the peel plate assembly is perpendicular to the conveyor. When the peel plate assembly is on the rods there is a small amount of play allowing you to make small adjustments to the assembly.



When the peel plate rods are removed the label detect sensor is removed with it (show in image to the left). The sensor is locked into place so it won't move or need adjusted. All that will need done is simply reconnect the sensor to the zip port. To re-connect the sensor first locate the zip port (as shown in image on the right). The zip port is located under the head on the chassis or mounting plate. Take the cable coming from the sensor, route it neatly under the head, and screw it into the zip port where it says "label detect".



Some machines may have the unwind flange (shown in image to the right) removed to protect the flange during shipping do to the width of the machine.

All assemblies removed will be bubble wrapped then plastic wrapped to the machine or in box on the pallet the machine is on.

First, slide the unwind flange (with the collar facing towards you as shown in image to the right) over the unwind shaft. Make sure the top of the flange is 1 ¼ inches off the side plate.

Then, lock into place by tightening the collar with a 5/32 L handle Allen wrench.

Slide the quick lock collar over the shaft by lining the set screw up with the flat. The collar locks into place by rotating the collar 90 degrees.



Some machines may have the rewind flange (shown in image to the right) removed to protect the flange during shipping do to the width of the machine.

All assemblies removed will be bubble wrapped then plastic wrapped to the machine or in box on the pallet the machine is on.

First, slide the rewind flange (with the collar facing away from you as shown in image to the right) over the rewind hub make sure the flange just above the rubber bumper roughly 1/2 inch off the side plate.

Then, lock into place by tightening the collar with a 5/32 L handle Allen wrench.



Rails and transfers on the infeed and outfeed may be removed for shipping purposes. They will be wrapped in bubble wrap and wrapped to the machine. Carefully remove wrap and place in position as shown lock into place by tightening the knobs or ratchet handles.

NOTE Your machine may have a different rail system either adjustment is tool-less and fastened by a knob of ratchet handle.



End transfers will be wrapped in bubble wrap and plastic wrap. They will be located in a box on the pallet with your machine or wrapped to the machine itself.

Fasten the end transfer plate to the machine using a 5/32 L handle Allen wrench and the supplied 10-32 socket head screws. Ensure the transfer plate is both level with the conveyor and DOES NOT hit the conveyor chain.

Stack lamps are usually placed at the highest point of the machine and for that reason they are either removed or rotated 180 degrees. The stack lamp will be wrapped in bubble wrap and wrapped to the machine.

If the stack lamp is rotated then all you need to do is remove one of the bolts, rotate the stack lamp and put the screw back in. We use various screws on stack lamps you will need one of the following tools for the job.

- 3/32 L handle Allen wrench
- 1/8 L handle Allen wrench
- 5/32 L handle Allen wrench
- 3/16 L handle Allen wrench
- 1/2 open end wrench



HMI over head touch screen displays may be laid flat across the top of the enclosure wrapped in bubble wrap and plastic wrap.

Carefully remove the plastic wrap and bubble wrap.

Rotate the HMI 90 degrees and slide into the mount on the enclosure.

Fasten the pole in place by tightening the 2 set screws on the mount with a 6MM L handle Allen wrench.



The HMI may be enclosed in a wooden support off the enclosure to hold it in place during shipping.

If HMI is located remotely off the enclosure it will still be supported during shipping.

If so, carefully remove the supports and you are done.


All printers, printer controllers and lasers are removed from the machine when shipping and placed in the manufacturer's box. The cabling will remain on the machine for ease of installation.

The printer is mounted to the printer mount with 1 ¼-20 ratchet handle. Make sure you line up the indents in the plates with the brass nut on the threaded rod. Then slide the ratchet handle through the center of all of the blocks and tighten. Plug in the cables and you are done.



Table top printers with printer tables will ship in separate boxes or pallets (as shown to the left) the printer will be disconnected and placed in the manufacturer's box. The table will either get banded to the pallet with the machine or a separate pallet tethered to the machine pallet. Printer tables may be connected to the machine via weldment or a remote from machine. If you have a weldment connected table, refer to the lay out drawing of your machine in this manual. Fasten the weldment to the frame of the conveyor using the supplied hardware and an open end wrench. If the table is remote then move into the desired position referring to your layout drawing. Remove the printer from the box set on the table and plug in the pre-wired connectors.





Print and apply printers will be removed from the labeling head as well and placed in the manufacturer's box. Your labeling head will likely ship in its own boxes with a few of the assemblies or flanges removed. Occasionally your head on a stand will ship on a framed pallet which will requires little work to get started.

The unwind flange is installed like the previous one discussed previously.

Remove the printer from the box and place it into the opening of the labeling head (as shown in image to the right). Fasten the printer to the side plate of the labeling head using the supplied (5) 10-32 socket head screws and a 5/32 L handle Allen wrench. Then, plug the printer in.




The corner wrap modules will be removed for shipping purposes. They will be wrapped in bubble wrap, plastic wrap, and placed into the box with the labeler.

Take out of the box, carefully remove the wrapping.

Then mount to the labeling head with (4) ¼-20 bolts using a 3/16 L handle Allen wrench.



To prevent kinking of the air lines during shipping on our q34 print and apply labeling heads. All lines are pulled and labeled to the corresponding color. The hoses are color coded and marked. Simply plug in hose into the matching color (as shown in image to the right).



Rotary accumulation tables are banded to a pallet and wrapped.

These tables usually operate independently to the machine.

Carefully un-band and unwrap the table.

Line it up to the transfer plate on the conveyor.

Level the table using the leveling pads.

Plus in and adjust speed through the control box.



Sleeving applicators are typically on a stand and will ship on a pallet. They will be banded have many supports and be wrapped to protect the machine during the shipping process.

Carefully remove the banding and wrapping.

Raise the head and remove the supports.


The pallet will contain boxes with. Misc assemblies and or parts (ie mandrels).



Below is an image of the mandrel. The mandrel is the most precise and important part of the sleeve system. Always handle the mandrel extremely carefully.



Your mandrel will be located on the machine pallet tethered to the machine. It will be wrapped and in a box or tube (as shown below).



Carefully remove the mandrel from the packaging.

Rotate the black handle to move the throw down rollers apart far enough to slide the mandrel in.

Ensure each roller is between 2 bearings, the fin on the top is between the sensor, and the cutter blades are in line with the cut in the mandrel.

Rotate the black handle to move the throw down rollers closer to the mandrel pinching it in the middle. DO NOT OVER TIGHTEN THE THROW

DOWN ROLLERS INTO THE MANDREL. They need to be just tight enough that the bearing spins and a label feeds through.

Proline machines with guarding will either be left on the machine and have wooden supports to protect during shipping or the guards are removed and placed on a pallet.

If the guarding has supports carefully remove the supports from the guarding.

If the guarding is removed from the machine each panel will be labeled and the machine will be labeled to make it easy to figure out which door goes where.



The doors are fastened to the frame of the machine with the supplied hardware.

Line the hinges up to the holes on the frame put the bolt through.

Tighten a nut on the opposite end with the supplied flat and lock washer.





During shipment if the conveyor gets skewed you may need to re-square it. First check the conveyor with a square to verify (as shown in images below). If the conveyor needs adjusted, adjust the conveyor by slightly loosening the 4 bolts connecting the 2 sections on conveyor you would like to adjust (as shown in image to left).

Make your adjustments and check the top and side with a square. Placing a square across the top will check the squareness vertically. Placing a square along the side will check squareness horizontally.



When the conveyor is square tighten the bolts and you are all set.

When shipping a proline with an extended boom the dual swiveling elbows in the center of the boom get flipped 180 degrees to allow the machine to have enough over head clearance to ship safely (shown in image below).



Below are the instructions to flip the elbows to the correct configuration (as shown in image below)



Ensure the overhead controls are safely supported by a tow motor or at least 2 people so it does not fall when disconnecting the elbows.

Locate the 2 screws on the top and 2 screw on the bottom holding the prospective covers on.



With a t25 torx bit screw driver, loosen the 2 bolts holding the cover on the top and bottom.

With the cover off you can now access the 4 bolts holding each of the tubes in place.

Ensure the overhead enclosure is supported enough to hold for a few minutes while you loosen the bolts and flip the elbow.

Using a 6MM L handle Allen wrench loosen the 4 bolts on the top and bottom tube.



Quickly pull the tubes out and rotate the elbow as shown below.



BEFORE



AFTER

Slide the tubes in. the overhead enclosures elevation is going to change when flipping the elbows if you have it supported via tow motor you will have to raise it.

Fasten the 8 bolts with a 6MM L handle Allen wrench.

Fasten the covers to the top and bottom elbow using a T25 torx bit screw driver.



To the left shows the correct orientation of the dual elbow boom for the overhead enclosure.

If you have any questions please give our professional technicians a call.

FAMILY GUIDE

QUADREL

LABELING SYSTEMS

Operator Interface Guide

Techline Labeling System

For Use with Files 84224_v000

Panel View Plus 7" Touch Screen with Allen Bradley CompactLogix L306 PLC

General Overview:

The Operator interface communicates to one PLC through an Ethernet connection. The application file is stored in the terminal's internal memory area and is executed on power-up. The actual data written to any parameter is stored in the PLC and is saved in its battery backed-up memory area.

Table of Contents

Opening Splash Screen.....	3
System Menus.....	4
Main Screen.....	5
Labeler Menu.....	7
Labeler Service Menu.....	9
Recipe Menu.....	11
Changeover Settings Menu.....	12
Product Flow Menu.....	13
Speed Calibration Menu.....	15
User Menu.....	16
Password Menu.....	17
Faults Menu.....	18
System Counters Menu.....	19
Fault History Menu.....	20
Warning Messages.....	21
Fatal Messages.....	22

Opening Splash Screen

Upon initial power up, the terminal will initialize and display a splash screen. Once this screen appears it sends a signal to the PLC to start executing logic.



Button / Indicator Reference:

Menu Navigation Buttons: Navigation buttons will be purple circles with white outlines and icons of the target screen. Some buttons will have text below them to identify the target screen.

Standard Buttons: Standard buttons are used to turn features on/off, reset faults, clear counters, or various other functions that require operator control. Toggle buttons will typically have icons to reflect the status of the function that is being toggled while momentary buttons like Resets are circular and do not change images/colors. Many buttons and toggles may be password protected, which will appear differently if the current user does not have proper access.

Indicators: Status Indicators will be circular and will change color based on states. Mode indicators will be oval in shape and will change colors and texts based on states.

Numeric and Text Displays: Numbers or Text displays will have a light orange background with black text, surrounded by a dark orange border. These are used to reflect numbers or recipe descriptions.


Numeric and Text Inputs: If a number or text can be entered, the button will have a dark green background with white text. The right side of the button will have a touch icon signify that it is an entry box.



System Menu:

Pressing the System Menu button in the top left corner of the screen will cause the menus to appear as pictured below.


Press any button to navigate to that menu, or the Close Menu button





Main Screen:

After touching the splash screen, the touch screen will display the Main screen. You can also get to the Main screen by pressing the Home icon (pictured left).



Menu/Setup Navigation Buttons:

These purple buttons across the top allow the operator to access the various screens that make up the entire touchscreen application. If you are currently on one of the screens, that screen's button will be green in color.

Fault/Message window:

Displays current alarms and status messages about the status of the labeling system.

The Faults Menu button can be used to display more messages or a history if needed. Pressing a reset button on the touch screen or physical button on the machine will clear these messages if the fault was remedied.

Labeler Run/Stop:

Each Labeler can be toggled between Run and Stop (pending fault conditions). The Run/Stop button will change colors and text based on the current status.



Green “Running” Button: This indicates the labeler is currently running and cannot be jogged. While running, the labeler will automatically apply labels to passing products. To **stop** the labeler, press this button.



Red “Stopped” Button: This indicates the labeler is currently stopped and may be jogged. While stopped, the labeler will ignore products passing by. To **run** the labeler, press this button.

Labeler Status Indicator:

The status indicator below the Run/Stop button will identify which fault state the labeler is in.

Ready/OK (green): The labeler has no fault conditions and may operate normally.

Warning (yellow): The labeler has a warning present (typically low on labels). The labeler may operate normally, but will require attention soon.

Faulted (red): The labeler has a fault on it that will prevent it from dispensing labels.

Disabled (grey): An emergency stop (both labelers) or Wrap Enable (Labeler #2) will disable the labeler. Faults and functions will be ignored.

Product Rate (Parts Per Minute):

This indicator will reflect how many parts per minute are being labeled by the system. This number will average out over a period of time and may need at least 10 products in order to start calculating a rate.

Product Count:

This counter reflects how many Products have passed the first product detect sensor while either labeler is Running. This count can be reset in either Labeler Menu.

Current Recipe Description:

This display reflects the description for the currently selected recipe. Recipes are explained in the Recipe / Labeler Menu.

Target Speed:

This entry box will change the speed of the system. It is entered as Inches per Minute.

Fault Reset:

Pressing this blue button with white "R" will clear and reset any active faults on the machine.

Product Flow Mode:

Green "Automatic" Button: Pressing this button will put the product flow into an automatic mode. The feedscrew/stop gate will stop/close and start/open based on the state of the system and any optional external sensors installed.




Red "Manually Stopped" Button: Pressing this button will stop the feedscrew/stop gate and keep them stopped/closed until placed into the Automatic mode.

1

Labeler Menu:

The Labeler Menu contains parameters related to dispensing labels on products.



Labeler Run/Stop:

Each Labeler can be toggled between Run and Stop (pending fault conditions). The Run/Stop button will change colors and text based on the current status.



Green “Running” Button: This indicates the labeler is currently running and cannot be jogged. While running, the labeler will automatically apply labels to passing products. To **stop** the labeler, press this button.



Red “Stopped” Button: This indicates the labeler is currently stopped and may be jogged. While stopped, the labeler will ignore products passing by. To **run** the labeler, press this button.

Labeler Status Indicator:

The status indicator below the Run/Stop button will identify which fault state the labeler is in.

Ready/OK (green): The labeler has no fault conditions and may operate normally.

Warning (yellow): The labeler has a warning present (typically low on labels). The labeler may operate normally, but will require attention soon.

Faulted (red): The labeler has a fault on it that will prevent it from dispensing labels.

Disabled (grey): An emergency stop (both labelers) or Wrap Enable (Labeler #2) will disable the labeler. Faults and functions will be ignored.

Product Count and Reset:

This counter reflects how many Products have passed the product detect sensor while any labeler is Running. The reset button below the counter will set this value to 0. The Product count and reset are global, so they will be identical on all labeler menus.

Labeler Jog:

When the Labeler is stopped, the Jog button becomes available. Pressing the Jog button will cause the labeler to dispense one label (pending proper threading and label gap detection). It is important to jog labels upon threading or changing over to verify the labeler is threaded and functioning properly.



Green “Jog” Button: This indicates the labeler can be jogged. Press this button to start a jog process. This button will be grey while the labeler is jogging.



Greyed out “Jog” Button: This indicates the labeler is currently running, and may not be manually jogged.

Label Count and Reset:

This counter reflects how many Labels have been dispensed when Jogging and Running. Pressing the reset button below the counter will set this value to 0.

Product Delay:

Product Delay (in inches) controls the point at which the labeler dispenses a label. A lower product delay value will cause the labeler to dispense “earlier” as the product passes by. A higher product delay value will cause the labeler to dispense “later” as the product passes.

Label Stop:

Label Stop (in inches) controls the label’s stop position. Typically, the label should stop with 1/8” to 1/4” sticking off of the peel plate. A higher Label Stop will result in more label off of the peel plate.

Note that a high label stop can result in more than one label being dispensed at once.

Max Feed Length:

The Max Feed Length (in inches) determines how much of the liner will advance when no label division is detected by the Label Sensor. If this value is lower than the physical length of the label, poor label stop will result. This value is typically set to a value at least 1/4” longer than the actual label length.


Speed Ratio:

Labeler Speed Ratio is the value that determines the speed of the labeler in relation to the conveyor belt.



Labeler Service Menu:

Each Labeler Service Menu contains parameters and toggles related to the Labeler that are not typically accessed on a regular basis. The Labeler Service Menu button is only visible when logged in.



Speed Calibration Toggle (Supervisor Level):

Calibration: Pressing this button will put the labeler into a Calibration Mode. While active, the labeler's drive system will continue to spin until Calibration Mode is turned off.

Use Caution and make sure the drive and rewind drum are clear before turning the Calibration on!

While the Calibration is active, the Speed Cal value can be changed so the labeler's drive roll speed is equal to that of the master encoder (conveyor). The Labeler should be Stopped to use the Calibration mode. Note that the speed ratio for the labeler will be forced to 1.0 while the Calibration is active.

Speed Calibration Value (Supervisor Level):

The Speed Calibration is the value that determines the actual dispensing speed in relation to the master encoder speed (typically the conveyor belt). Increasing the Speed Calibration value will decrease the labeler's speed in relation to the master encoder. A lower Speed Calibration value will increase the labeler's speed.

This value should not be changed while the labeler is running as it will affect accuracy and performance.

Labeler Run Hours and Reset (Supervisor Level):

This counter will count the hours that the Labeler has been in the run mode while the conveyor is running. The reset button is only visible when logged in at the Supervisor Level.

Line Compensation (Supervisor Level):

The Line Compensation value adds and subtracts product delay based on the master encoder frequency. This allows the labeler to be accurate across all speed ranges. The Line Compensation value is set at the factory by running products at a slow speed and max speed, and then altering the value until the labeler applies the labels in the same location. Note that the Line Compensation is based off of the Max Frequency value. Changing the Max Frequency will force the need to change the Compensation value.

Accel and Decel (Supervisor Level):

These are the ramp values used by the labeler drive when dispensing labels while running. A lower value results in a longer Acceleration or Deceleration rate.

Encoder Count:

This is the current encoder count as interpreted by the respective labeler drive.

Encoder Counts per Inch (Quadrel Level):

The Encoder Counts per Inch value tells the labeler how many encoder pulses are counted for every inch of conveyor travel. This value is set at the factory and typically does not need adjusted. Note that this value may not equal the PLC Encoder Counts per Inch value.

Drive Frequency:


This display will show the encoder frequency value in the labeler drive. Use this to determine the max frequency value.

Max Frequency (Supervisor Level):

The Max Frequency is calculated by running the system at max speed and adding 200 to 300 Hz to the displayed drive frequency. This is used for line speed compensation purposes.



Recipe Menu:



Current Recipe Description:

The description display at the top of the screen reflects the stored description for the recipe currently loaded.



Change Recipe Description (Supervisor Level): Pressing this button will allow the operator to change the current recipe description.

Note that the current recipe must be saved to retain the new description.

System Recipe (Load):

When the system is stopped, a new recipe number can be entered. When this number is changed, the newly entered recipe settings will automatically be loaded to the system.

Recipe to Save As (Supervisor Level):

Enter a target recipe to overwrite in this box. Note that the “Save As” button must be pressed in order to execute a save.



Save As Recipe Above (Supervisor Level): Pressing this button will save all current recipe values to the Recipe Number entered in the

“Recipe to Save As” box. Note that pressing this button will not change the system recipe, it only writes values to the target recipe.



Save Current System Recipe (Supervisor Level): Pressing this button will save all current recipe values to the currently loaded recipe.

Load Recipe by Description:

The center table shows the stored description for each recipe. The navigation buttons to the right of the table can be used to select descriptions. When

the desired recipe is highlighted, the “Load Selected” button must be pressed to load that recipe to the system.



Changeover Menu:

CHANGEOVER / DIAL SETTINGS

Current Recipe Description

Pacing Belt Up / Down: NNNNN

Labeler #1 Up / Down: NNNNN

Labeler #1 In / Out: NNNNN

Labeler #2 Up / Down: NNNNN

Labeler #2 In / Out: NNNNN

Wrap Belt Up / Down: NNNNN

Wrap Belt In / Out: NNNNN

Back Pad Up / Down: NNNNN


Back Pad In / Out: NNNNN

The Changeover / Dial settings menu contains indicators that make changing over from one product to another easier. These values can only be changed when logged in at the Supervisor level.



Product Flow Menu:

The Product Flow Menu controls timers and values associated with allowing products to enter the system.



Product Flow Control:

The pacing system can be stopped independently of the main system in order to prevent products from flowing into the system. This can be useful during setup or to purge the system. A pacing system can be a feedscrew, pacing wheel, pacing belt, stop gate, or combination of listed items.



Green “Automatic” Button: This indicates the pacing system will stop and start the pacing system based on external conditions.

The Pacing System will stop/close when:

- The system is stopped
- The infeed sensor is not blocked by products or “starved”.
- The outfeed sensor is blocked by products or “full”.
- The Product Flow button has been toggled to “Stopped”
- A Cycle Stop is active



Red “Stopped” Button: This indicates the pacing system is stopped and will not allow products into the system until toggled back to Automatic.

Product Flow Status Indicator:

The indicator below the Product Flow Control button identifies the actual status of the pacing system.

Green: Running. The pacing system is currently allowing products into the system.

Yellow: Waiting. The system is running but the pacing system is stopped because of a condition listed above.

Red: Stopped. The pacing system has been stopped manually and will not function until placed in the Automatic Mode.

Infeed Starved / Empty Delay (Maintenance Level):

This timer will start when the Infeed sensor does NOT see products, which results in an Empty/Starved condition. After this timer expires, the product flow will stop.

Infeed Primed/ Full Delay (Maintenance Level):

This timer will start when the Infeed sensor sees products, which results in an Primed/Full condition. After this timer expires, the product flow will start.

Outfeed Clear / Empty Delay (Maintenance Level):

This timer will start when the Outfeed sensor does NOT see products, which results in a Clear/Empty condition. After this timer expires, the product flow will start.


Outfeed Backup / Full Delay (Maintenance Level):

This timer will start when the Outfeed sensor sees products, which results in an Backed Up/Full condition. After this timer expires, the product flow will stop.



Speed Calibration Menu:

The System Speed Menu contains parameters and indicators related to the linear speed of the system.



Target Conveyor Speed:

This indicator reflects the current target linear speed of the conveyor in Inches per Minute.


Conveyor Calibration (Supervisor Level):

This value allows the conveyor to run at the Target Conveyor Speed. It is calibrated at the factory using a tachometer and should not be changed.



User Menu:

The User Menu enables alternate login levels to access protected screens and buttons. You can access this Menu by pressing the Lock icon (pictured left).



Log In: Press this button to enter a user password.



Log Out: Press this button to enter to log the current user out.



Password Menu: This will open up a security prompt before opening the password menu, where the passwords for the Maintenance and Supervisor levels are set.

Auto Log Out (Supervisor Level):

When Enabled (button will be Green), the logged in user will automatically be logged off at a set amount of time. Note that the system automatically enables the Auto Log Out feature upon startup.


Log Out Timer (Supervisor Level):

This timer (in minutes) determines the time it takes to log off a user if Auto Log Out is enabled.



Password Menu:

The Password Menu allows the creation and editing of the passwords for different security levels.



Maintenance:

There can be 3 user defined passwords for the Maintenance level. Note that there is one hard coded Maintenance Level password that cannot be viewed or changed.

Supervisor:

There can be 3 user defined passwords for the Supervisor level. Note that there is one hard coded Supervisor Level password that cannot be viewed or changed.

If a Maintenance and Supervisor password are the same, the system will log that user in at the Maintenance level.

The password(s) to open the Password Menu are stored in the HMI and cannot be modified. This will prevent any password loss in the event the PLC logic is altered.


Quadrel:

There is a hard coded Quadrel level password that cannot be viewed or changed. This is typically only used when a machine is first commissioned to set motor directions or global variables that do not change on a regular basis.



Fault Menu:

The Fault Menu displays all fault messages, shows system level counters, and gives access to a Fault History. You can access this Menu by pressing the Alert icon.



Fault Display:

The Fault dialog box will display all of the active faults on the machine.


Fault Reset:

Used to reset active faults displayed above.



Counters Menu:

The Counters Menu shows system level counters and status indicators. Counters may be reset when logged in at the Supervisor level.





Fault History:

The Fault History will store the last 128 fault message events.



Fault Messages and Indicators:

Green Lamp:

Steady: The Green lamp will be steady while the system is running.

Amber Lamp:

Flash: The Amber lamp will flash while a warning is active on the system.

Red Lamp:

Flash: The Red lamp will flash while a fatal fault is active.

Buzzer: The Audible Alarm will long pulse (1 second) when a fatal fault is present.

The buzzer will short pulse before the system starts.



Warning Messages: Warning messages identify a status or event that may need action soon. The machine will not stop from a warning message, but a warning may turn into a fatal fault that will stop the machine. Many warning messages will automatically clear once the problem is remedied.

Fatal Messages: Fatal messages will cause the system to stop immediately or initiate a cycle stop. Fatal faults are typically associated to events that prevent labels being applied properly, safety related faults, or other events that may prevent proper machine operation.

Messages	Cause/Solution
Warning Messages	
PLC Cycled without Screen. Restart System or Touch Screen	The PLC waits for a signal from the touch screen after power-up to verify communications before executing logic. If the PLC is cycled from power or downloading, the screen must be cycled as well.
Infeed Starved / Empty. Product Flow Stopped	The Product Flow has stopped because the infeed sensor is not satisfied.
Outfeed Full / Backed Up. Product Flow Stopped	The Product Flow has stopped because the Outfeed sensor is not satisfied.
Labeler #1 Drive (DR5) Faulted Warning	The drive that controls the Labeler #1 motor is faulted or turned off. If pressing the reset button does not clear this message, verify that the drive is powered up.
Labeler #1 Missing Label / Maximum Feed Length Reached	The listed labeler has reported it reached its maximum feed length. This can be an indicator of a missing label on the liner. If you feel you received this message in error, check the Maximum Feed Length value for the labeler.
Labeler #1 Drive (DR5) Program Stopped Warning	The internal program of the listed labeler drive is not executing logic. Pressing the Reset button or re-enabling the drive should remedy this problem.
Labeler #1 Communications Warning	The communications between the PLC and listed drive has timed out. Correct this issue before running or using that drive. Note that a communication failure with one drive may affect others.
Labeler #2 Drive (DR6) Faulted Warning	The drive that controls the Labeler #2 motor is faulted or turned off. If pressing the reset button does not clear this message, verify that the drive is powered up.
Labeler #2 Missing Label / Maximum Feed Length Reached	The listed labeler has reported it reached its maximum feed length. This can be an indicator of a missing label on the liner. If you feel you received this message in error, check the Maximum Feed Length value for the labeler.
Labeler #2 Drive (DR6) Program Stopped Warning	The internal program of the listed labeler drive is not executing logic. Pressing the Reset button or re-enabling the drive should remedy this problem.
Labeler #2 Communications Warning	The communications between the PLC and listed drive has timed out. Correct this issue before running or using that drive. Note that a communication failure with one drive may affect others.

Messages	Cause/Solution
Fatal Messages	
Safety Relay Active. Check E-Stops, Re-set	The Safety relay has been activated by an Emergency Stop. Unlatch all Emergency Stops and press the Reset button to reset the safety relay.
Conveyor Drive (DR1) Faulted / Turned Off	The drive that controls the conveyor motor is faulted or turned off. If pressing the reset button does not clear this message, verify that the drive is powered up.
Top Trap Drive (DR2) Faulted / Turned Off	The drive that controls the top trap motor is faulted or turned off. If pressing the reset button does not clear this message, verify that the drive is powered up.
Wrap Drive (DR3) Faulted / Turned Off	The drive that controls the wrap belt motor is faulted or turned off. If pressing the reset button does not clear this message, verify that the drive is powered up.
PLC Faulted	The PLC has become faulted. If resetting system power does not clear this fault, contact Quadrel support
Labeler #1 Drive (DR4) Faulted	The drive that controls the Labeler #1 motor is faulted or turned off while it was running or attempted to run. Reset the drive or re-enable the drive.
Labeler #1 Missing Label / Maximum Feed Length Reached	The listed labeler's drive has reported a maximum feed length movement while running. If there was no missing label on the web, ensure the "Max Feed Length" in the labeler menu is set to the proper value.
Labeler #1 Drive (DR4) Program Stopped Fault	The internal program of the listed labeler drive stopped executing logic while it was running or attempted to run. Reset the drive or re-enable the drive.
Labeler #1 Communications Fault	The communications between the PLC and listed drive has timed out while it was running or attempted to run.
Labeler #2 Drive (DR4) Faulted	The drive that controls the Labeler #2 motor is faulted or turned off while it was running or attempted to run. Reset the drive or re-enable the drive.
Labeler #2 Missing Label / Maximum Feed Length Reached	The listed labeler's drive has reported a maximum feed length movement while running. If there was no missing label on the web, ensure the "Max Feed Length" in the labeler menu is set to the proper value.
Labeler #2 Drive (DR4) Program Stopped Fault	The internal program of the listed labeler drive stopped executing logic while it was running or attempted to run. Reset the drive or re-enable the drive.
Labeler #2 Communications Fault	The communications between the PLC and listed drive has timed out while it was running or attempted to run.

To set user passwords during initial setup navigate to the passwords screen, then Log in using password "7670" Once logged in users can set passwords per HMI Guide.




USER MENU


Sunday

mm/dd/yy

HH:MM:SS




Passwords



Current User:

Default



Log Out

Disabled

Log Out
Timer:

12:34

Setup Sheets

QUADREL

LABELING SYSTEMS

Machine: 84224-100
Label Size/Product: 3.60" x 1.56" / Square 5.13" L x 2.25" H
Recipe: 1 Square

Labeler #1 Menu

	FACTORY	USER
Product Delay #1	7.450	
Label Stop #1	2.15	
Max Feed Length #1	6.00	
Speed Ratio #1	1.00	

Labeler #1 Service Menu

	FACTORY	USER
Speed Cal #1 Value	1240	
Line Compensation #1	50	
Labeler #1 Accel	4500	
Labeler #1 Decel	4500	
Maximum Frequency #1	15000	
Counts per Inch #1	515	

Labeler #2 Menu

	FACTORY	USER
Product Delay #2	7.100	
Label Stop #2	2.15	
Max Feed Length #2	6.00	
Speed Ratio #2	1.00	

Labeler #2 Service Menu

	FACTORY	USER
Speed Cal #2 Value	1238	
Line Compensation #2	50	
Labeler #2 Accel	4500	
Labeler #2 Decel	4500	
Maximum Frequency #2	15000	
Counts per Inch #2	515	

Speed Calibration Menu

	FACTORY	USER
Target Speed	600	
Conveyor Calibration	19.550	

QUADREL

LABELING SYSTEMS

Machine: 84224-100
Label Size/Product: 3.60" x 1.56" / Square 5.13" L x 2.25" H
Recipe: 1 Square

Product Flow Menu

	FACTORY	USER
Product Flow	Automatic	
Infeed Full/Primed Delay	1.00	
Infeed Starved/Empty Delay	1.00	
Outfeed Full/Backup Delay	1.00	
Outfeed Clear/Empty Delay	1.00	

Mechanical Settings (Changeover/Dial Settings)

	FACTORY	USER
Labeler #1 Up/Down	1938	
Labeler #1 In/Out	99623	
Labeler #2 Up/Down	1830	
Labeler #2 In/Out	99426	
Top Trap Up/Down	2132	
Pacing Belt Up/Down	99244	
Wrap Belt Up/Down	0	
Wrap Belt In/Out	0	
Back Pad Up/Down	0	
Back Pad In/Out	0	

QUADREL

LABELING SYSTEMS

Machine: 84224-100
Label Size/Product: 3.60" x 1.56" / Round 5.70" diameter x 2.25" H
Recipe: 2 Short Round

Labeler #1 Menu

	FACTORY	USER
Product Delay #1	7.050	
Label Stop #1	4.70	
Max Feed Length #1	9.00	
Speed Ratio #1	1.00	

Labeler #1 Service Menu

	FACTORY	USER
Speed Cal #1 Value	1240	
Line Compensation #1	50	
Labeler #1 Accel	4500	
Labeler #1 Decel	4500	
Maximum Frequency #1	15000	
Counts per Inch #1	515	

Labeler #2 Menu

	FACTORY	USER
Product Delay #2	7.100	
Label Stop #2	1.00	
Max Feed Length #2	9.00	
Speed Ratio #2	1.00	

Labeler #2 Service Menu

	FACTORY	USER
Speed Cal #2 Value	1238	
Line Compensation #2	50	
Labeler #2 Accel	4500	
Labeler #2 Decel	4500	
Maximum Frequency #2	15000	
Counts per Inch #2	515	

Speed Calibration Menu

	FACTORY	USER
Target Speed	600	
Conveyor Calibration	19.550	

QUADREL

LABELING SYSTEMS

Machine: 84224-100
Label Size/Product: 3.60" x 1.56" / Round 5.70" diameter x 2.25" H
Recipe: 2 Short Round

Product Flow Menu

	FACTORY	USER
Product Flow	Automatic	
Infeed Full/Primed Delay	1.00	
Infeed Starved/Empty Delay	1.00	
Outfeed Full/Backup Delay	1.00	
Outfeed Clear/Empty Delay	1.00	

Mechanical Settings (Changeover/Dial Settings)

	FACTORY	USER
Labeler #1 Up/Down	1838	
Labeler #1 In/Out	99317	
Labeler #2 Up/Down	1733	
Labeler #2 In/Out	99106	
Top Trap Up/Down	2135	
Pacing Belt Up/Down	99211	
Wrap Belt Up/Down	135	
Wrap Belt In/Out	49	
Back Pad Up/Down	69	
Back Pad In/Out	99792	

QUADREL

LABELING SYSTEMS

Machine: 84224-100
Label Size/Product: 3.60" x 1.56" / Round 5.70" diameter x 3.00" H
Recipe: 3 Tall Round

Labeler #1 Menu

	FACTORY	USER
Product Delay #1	7.050	
Label Stop #1	4.70	
Max Feed Length #1	9.00	
Speed Ratio #1	1.00	

Labeler #1 Service Menu

	FACTORY	USER
Speed Cal #1 Value	1240	
Line Compensation #1	50	
Labeler #1 Accel	4500	
Labeler #1 Decel	4500	
Maximum Frequency #1	15000	
Counts per Inch #1	515	

Labeler #2 Menu

	FACTORY	USER
Product Delay #2	7.100	
Label Stop #2	1.00	
Max Feed Length #2	9.00	
Speed Ratio #2	1.00	

Labeler #2 Service Menu

	FACTORY	USER
Speed Cal #2 Value	1238	
Line Compensation #2	50	
Labeler #2 Accel	4500	
Labeler #2 Decel	4500	
Maximum Frequency #2	15000	
Counts per Inch #2	515	

Speed Calibration Menu

	FACTORY	USER
Target Speed	600	
Conveyor Calibration	19.550	

QUADREL

LABELING SYSTEMS

Machine: 84224-100
Label Size/Product: 3.60" x 1.56" / Round 5.70" diameter x 3.00" H
Recipe: 3 Tall Round

Product Flow Menu

	FACTORY	USER
Product Flow	Automatic	
Infeed Full/Primed Delay	1.00	
Infeed Starved/Empty Delay	1.00	
Outfeed Full/Backup Delay	1.00	
Outfeed Clear/Empty Delay	1.00	

Mechanical Settings (Changeover/Dial Settings)

	FACTORY	USER
Labeler #1 Up/Down	1838	
Labeler #1 In/Out	99317	
Labeler #2 Up/Down	1733	
Labeler #2 In/Out	99106	
Top Trap Up/Down	1698	
Pacing Belt Up/Down	98801	
Wrap Belt Up/Down	135	
Wrap Belt In/Out	49	
Back Pad Up/Down	69	
Back Pad In/Out	99792	

Fuji Frenic Mini v.000 Rev A
For use with Techlines with Micrologix PLC

Job: 84224-100 Drive: DR1 Motor: Conveyor

SETUP AND ADJUSTMENTS: (Reference Fuji drive manual for detailed information)

Set Primary Parameters:

Parameter	Fuji Default	Quadrel Default Value	Quadrel Final Value	Description
F01	4	1 (10V)	1	Freq. Command
F02	2	1 (Terminals)	1	Operation
F03*	60.0	60.0	<u>90.0</u>	Max Frequency
F07	6.0	3.0	<u>3.00</u>	Accel Time
F08	6.0	3.0	<u>3.00</u>	Decel Time
F15	70.0	70.0	<u>90.00</u>	Frequency Limit
F26	2	6	<u>6</u>	Carrier Frequency
F42	0	2	2	Control Mode
P99	0	1 (HP)	1	Motor Type
P02	Varies	See Motor Nameplate	<u>0.38</u>	Rated Capacity (HP)

*: If F03 needs to be higher than 70.0, F15 must be changed first.

P02 Reference for frequently used motors:
3/8HP: 0.38, 1/6HP: 0.17

SINK/SOURCE Jumper: SOURCE

Initialize Parameters

- Navigate to Parameter H03
- Use the STOP and UP Arrow to change H03 to "2". Press the Func/Data button.
- "Save" will flash on the display. H03 will revert back to "0" once the parameters are automatically set.

Set the Motor Current based on the Motor Nameplate value. Entered as Amps.

Parameter	Fuji Default	Motor Nameplate	Quadrel Final value
P03	Varies	<u>1.9</u>	<u>1.90</u>

P03 Reference for frequently used motors:
3/8HP: 1.9, 1/6HP: 0.73

When Chain Aligners Installed, F30 (Analog Out Adjustment) on DR2 will change the Chain Aligner Speed

Parameter	Fuji Default	Quadrel Default	Quadrel Final value
F30	100	200	<u>100</u>

Fuji Frenic Mini v.000 Rev A
For use with Techlines with Micrologix PLC

Job: 84224-100 Drive: DR2 Motor: Top Trap

SETUP AND ADJUSTMENTS: (Reference Fuji drive manual for detailed information)

Set Primary Parameters:

Parameter	Fuji Default	Quadrel Default Value	Quadrel Final Value	Description
F01	4	1 (10V)	1	Freq. Command
F02	2	1 (Terminals)	1	Operation
F03*	60.0	60.0	<u>93.0</u>	Max Frequency
F07	6.0	3.0	<u>3.00</u>	Accel Time
F08	6.0	3.0	<u>3.00</u>	Decel Time
F15	70.0	70.0	<u>90.00</u>	Frequency Limit
F26	2	6	<u>6</u>	Carrier Frequency
F42	0	2	2	Control Mode
P99	0	1 (HP)	1	Motor Type
P02	Varies	See Motor Nameplate	<u>0.38</u>	Rated Capacity (HP)

*: If F03 needs to be higher than 70.0, F15 must be changed first.

P02 Reference for frequently used motors:
3/8HP: 0.38, 1/6HP: 0.17

SINK/SOURCE Jumper: SOURCE

Initialize Parameters

- Navigate to Parameter H03
- Use the STOP and UP Arrow to change H03 to "2". Press the Func/Data button.
- "Save" will flash on the display. H03 will revert back to "0" once the parameters are automatically set.

Set the Motor Current based on the Motor Nameplate value. Entered as Amps.

Parameter	Fuji Default	Motor Nameplate	Quadrel Final value
P03	Varies	<u>1.9</u>	<u>1.90</u>

P03 Reference for frequently used motors:
3/8HP: 1.9, 1/6HP: 0.73

When Chain Aligners Installed, F30 (Analog Out Adjustment) on DR2 will change the Chain Aligner Speed

Parameter	Fuji Default	Quadrel Default	Quadrel Final value
F30	100	200	<u>100</u>

Fuji Frenic Mini v.000 Rev A
For use with Techlines with Micrologix PLC

Job: 84224-100 Drive: DR3 Motor: Wrap

SETUP AND ADJUSTMENTS: (Reference Fuji drive manual for detailed information)

Set Primary Parameters:

Parameter	Fuji Default	Quadrel Default Value	Quadrel Final Value	Description
F01	4	1 (10V)	1	Freq. Command
F02	2	1 (Terminals)	1	Operation
F03*	60.0	60.0	<u>89.0</u>	Max Frequency
F07	6.0	3.0	<u>3.00</u>	Accel Time
F08	6.0	3.0	<u>3.00</u>	Decel Time
F15	70.0	70.0	<u>90.0</u>	Frequency Limit
F26	2	6	<u>6</u>	Carrier Frequency
F42	0	2	<u>2</u>	Control Mode
P99	0	1 (HP)	1	Motor Type
P02	Varies	See Motor Nameplate	<u>0.38</u>	Rated Capacity (HP)

*: If F03 needs to be higher than 70.0, F15 must be changed first.

P02 Reference for frequently used motors:
3/8HP: 0.38, 1/6HP: 0.17

SINK/SOURCE Jumper: SOURCE

Initialize Parameters

- Navigate to Parameter H03
- Use the STOP and UP Arrow to change H03 to "2". Press the Func/Data button.
- "Save" will flash on the display. H03 will revert back to "0" once the parameters are automatically set.

Set the Motor Current based on the Motor Nameplate value. Entered as Amps.

Parameter	Fuji Default	Motor Nameplate	Quadrel Final value
P03	Varies	<u>1.9</u>	<u>1.90</u>

P03 Reference for frequently used motors:
3/8HP: 1.9, 1/6HP: 0.73

When Chain Aligners Installed, F30 (Analog Out Adjustment) on DR2 will change the Chain Aligner Speed

Parameter	Fuji Default	Quadrel Default	Quadrel Final value
F30	100	200	<u>100</u>

WARNING



- KEEP HAND CLEAR OF MOVING PARTS. DO NOT PLACE HANDS NEAR LABELING HEAD WHEN IN OPERATION



- DO NOT OPERATE EQUIPMENT WITHOUT GUARDS OR COVERS INSTALLED



6.1 LABELING HEAD INFORMATION

6.1.1 LOADING AND UNLOADING STOCK ROLL



CAUTION

To avoid injuries, you must keep the labeler stopped/paused. You can manually jog labels with the JOG button.

Look carefully at the diagram and follow the threading procedures indicated below.

You will also find the threading diagram directly on the labeling head.

- 1) Place the label stock roll on the unwind shaft. Press the roll firmly against the flange. Then slide the locking collar over the unwind shaft aligning the set screw with the shaft. Press into the roll and twist to lock the collar in place.



- 2) Pull Approximately 36-40" of stock from label stock roll.





- 3) Follow the threading diagram on the labeling head for routing the web.
- 4) Thread through the dancer to the peel plate.









- 5) Feed the label around the peel plate and under the pressure shoe if (if there is one). Feed the label up the head to the pull roll. Pull all the slack out.




- 6) Wrap labels around the rubber roller as shown, then around the knurled roller. Make sure the knurled roller is not locked in by turning the red knob to the left or right of the red dot on the drive roll. When you have the labels completely threaded you can turn the knob to the red dot.



- 7) Thread the labels through the rewind dancers to the rewind shaft. Place the end of the label through the clip and rotate the rewind hub to take up the slack.



- 8) The finished product should look similar to the pictures below. Some heads are threaded differently depending on the style head you have. See threading diagrams on the head itself or the manual.



- 9) To unload the rewind loosen (counter clockwise) the “clevis” bolt on the top of the rewind hub. this will collapse the rewind and you can pull the liner off the hub.




CAUTION


There are many pinch points on a labeler. to avoid injury read and understand the owner’s manual before operating.

6.1.2 THREADING DIAGRAMS


Here are the following threading diagrams for our standard labeling heads.




Q120/Q125/Q115/Q110



Q60/Q65



Q34



E100

6.1.3 LABELER ADJUSTMENTS

The vertical adjustment is to position the label on the container at different heights. It's practical if you have different size labels and/or containers. To adjust the height you simply rotate the handwheel at the top of the labeler counter clockwise to go down and clockwise to go up.



Horizontal adjustments are made the same way except you rotate the hand wheel under the labeler. Rotating the hand wheel counter clockwise will move the labeler in and rotating clockwise will move the labeler out.



To adjust the angle of the labeling head you first need to loosen the large $\frac{3}{4}$ -10 nut with a $1\frac{1}{4}$ " wrench and the $\frac{5}{16}$ -18 hex head bolt. The angular adjustment is very important to increase the repeatability of the process. A good adjustment is when the exit of the label is tangent with the surface of the application.



CAUTION

DO NOT remove the nut & bolt.



Now to adjust the tilt of the labeling head by tightening and loosening the jack screws.



Rotate adjustment is achieved by loosening the 2 ratchet handles under the labeling head. There is a jack screw holding the labeling head in place, but still use caution when loosening the ratchet handles the labeling head can rotate

freely when loose. This is a fine adjustment that increases the parallelism of the label to the shape of the container.



CAUTION

When loosening the labeling head, the head may rotate freely. Keep positive pressure against the head to prevent the head from rotating on its own.





QUADREL LABELING SYSTEMS

Q120 7" LABELING HEAD

GENERAL DESCRIPTION

- The Q120 has been developed as a heavy duty automatic labeling head system for integration into high speed, high rate production environments. The labeling head can be configured for either wrap or wipe on applications. The Q120 labeler features a PLC based control, insuring accurate and drift free label application. The Q120 uses a high-torque stepping motor for web drive. The step motor drive system is indexed directly from the PLC controller. This allows for precise adjustment and calibration for any number of applications. In addition, a built in system of fault logic can easily interface with a host of optional sensors.

PRINCIPLE OF FUNCTION

- The Q120 labeling head applies pressure sensitive labels onto moving products. Various principles are involved to achieve accurate label application. In general, a labeling system integrates three (3) basic functions:

- Product Handling: The most common product handling component is the conveyor. Conveyors allow the product to transport smoothly through the labeling station. The Q120 labeler can be supplied either as a stand alone head (head on a stand) or integrated into a complete conveying/product handling system.

- Label Application: Usually the label is "tacked" directly to the product during the label dispensing cycle. Secondary label applicators such as brushes, roller or wrap belts are used to finish the label application and to ensure good adhesion.

- Label Dispensing: The labeling head uses a DC step motor to dispense the label. The label dispensing cycle begins when a product is sensed by the product sensor. This signal engages the drive motor which advances the unwind, and dispenses a label. As the label is dispensed, a slot sensor detects the division between the labels and disengages the motor. The DC step motor uses an internal braking action which holds the motor in a locked position preventing web movement between application cycles. All delays, sequencing and indexing are controlled by the PLC.

SEQUENCE OF OPERATION:

- The electrical and mechanical operating sequence described below is intended only to acquaint the operator with the operation of the label dispensing head and its related control circuitry.
- The "Jog Key" is provided for manual set-up of label dispensing. When it is depressed a single label dispense cycle is initiated.
- The label dispensing cycle is described in the following manner:
 1. The labeling cycle is initiated by the detection of a product by the product detect sensor. This triggers the start of the PRODUCT DELAY cycle which is indicated by the PRODUCT DETECT control panel LED.
 2. Label position time is initiated. The duration of the delay is set by the PRODUCT DELAY preset.
 3. At the end of this preset delay period, the label dispensing motor is energized. Label dispensing "starts."
 4. The label division (space between labels) passes through the label sensor gap and initiates the LABEL DELAY time-out. (Also considered label FLAG) As the label division is sensed by the label sensor, the red front panel LABEL DETECT LED will indicate the LABEL DELAY time-out.
 5. Label stop (flag) time is initiated.
 6. At the end of a preset time period, the label dispensing motor is de-energized and the label feed stops.
 7. If the optional imprinter is installed, the imprint cycle commences. At the completion of this cycle, the system is reset.

ASSEMBLY TITLE: Q120 LABELING HEAD ASSEMBLY

DRAWING NO.: NONE

GENERAL FUNCTION:

- Applies labels to the front and/or back, top/bottom of the products
- Wraps labels around cylindrical products

SET-UP AND ADJUSTMENTS:

- Tighten all loose connections and screws
- As noted in each sub-assembly

MAINTENANCE:

- Remove glue residue and labels from all rollers and idlers
- As noted in each sub-assembly

TROUBLESHOOTING:

- As noted in each sub-assembly

ASSEMBLY TITLE: Q120 LABELING HEAD - DANCER ARM ASSEMBLY

DRAWING NO.: None Applicable

GENERAL FUNCTION:

- The dancer arm and braking mechanism are used to control the unwind unit which will only advance a few inches of web at any time
- The position of the dancer arm affects the advancement of the web off the label roll.

SET UP AND ADJUSTMENTS:

- The dancer normal position of the dancer arm is reached when the dancer arm locks the supply reel.
- The spring tension can be adjusted to correctly locate the dance arm
- The spring may be adjusted by turning the threaded tensioner located near the unwind unit.
- The spring should be tight enough to bring the dancer arm back to its normal position and hold it with some force, but not tight enough to tear the web during label feed.
- Spring adjustment is also possible by rotating the spring mounting pin on the spring take up pulley around the mounting shaft.
- While in its normal position, the dancer arm roller should not interfere with the supply reel flange.

MAINTENANCE:

- Replace dancer spring if final spring tension is too soft.

TROUBLESHOOTING:

PROBLEM

- Web break
- Too much web slack
- Dancer arm hits supply flange position by loosening the brake cam.

WHAT TO DO

- Lower spring tension on dancer arm
- Increase spring tension
- Correct dancer arm final

ASSEMBLY TITLE:**Q120 LABELING HEAD - BRAKE BRUSH
ASSEMBLY****GENERAL FUNCTION:**

- The brake brush establishes web tension and controls backlash

SET UP AND ADJUSTMENTS:

- For accurate label feeds, the web must establish proper tension.
- Loosen the holding set screw in the brake brush body. The brake brush assembly can now be rotated on axis.
- Turn brush body into the web and tighten. To check for proper web tension, jog a label and check for web slack. If the web is tight and the label feeds correctly, the brush tension is set correctly.
- If backlash persists, continue to increase brake brush tension.

MAINTENANCE:

- Replace brake brush when brush body contour no longer viable or bristles are worn down.

TROUBLESHOOTING:PROBLEM

- Web break
- Motor stall
- Too much web slack

WHAT TO DO

- Too much brake tension. Decrease until no slack in web.
- Debris or brake flaw causing web tear
- Decrease brake tension
- Increase brake tension

ASSEMBLY TITLE:**Q120 LABELING HEAD - THREADING****GENERAL FUNCTION:**

- This section is used to guide the user through loading and feeding the label through the web path.

SET UP AND ADJUSTMENTS:

- Load label spool onto unwind hub. Secure unwind retainer onto hub and lock. Pull 3-4 feet of web from unwind and strip labels free of web.
- Unlock the drive roller locking handle.
- Using the threading diagram located on the labeling head, feed the web through the labeling head. Start at the unwind dancer assembly and work forward.
- Feed the web through the drive roller assembly.
- Feed the web around the rewind dancer assembly and onto the rewind hub. Wrap the web around the hub once. Lock the web in place with the rewind retaining bracket.
- Once the web has been threaded, lock down the drive roll assembly by rotating the drive roll locking arm into the locked position. (Towards the drive roller assembly)

MAINTENANCE:


- None this section.

TROUBLESHOOTING:PROBLEM

- Web break
- No Web Tension

WHAT TO DO

- Check web path and insure web routed correctly.
- Debris causing web tear and break. Clear as needed.
- Check web path through unwind and dancer assembly.
- Check drive roller lock position.



NOTES:

1) LABEL MATERIAL IS .003"
ALUMINUM FOIL W/PERMANENT
PRESSURE SENSITIVE ADHESIVE.

2) ALL LETTERING IS .125"
HIGH EUROSTYLE 2, BOLD
EXTENDED 2.

3) USE QUADREL STANDARD LOGO.


4) ALL LINES AND LETTERS ARE
BLACK ON A SILVER BACKGROUND
QUADREL AND (WEB PATH) ARE RED #(199c)
LINES ARE DASHED LINES.

5) LABEL SIZE 3.0" X 3.0".

A	5-8-19	NEW DRAWING
REV	DATE	DESCRIPTION

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

<p>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE</p> <p>X± .1 .XX± .01 .XXX± .005 ANGLES ± 30'</p> <p>SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030</p>	<p>QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700</p> <p>Q110/120/125 R.H. THREADING DIAGRAM</p>	SCALE: DRAWING SCALE
		DATE: 5-8-19
<p>MAT'L</p> <p>SEE NOTES</p>		DRW BY: TJS
		CHK BY:
		APPR BY:
		A26222-110RH



NOTES:

1) LABEL MATERIAL IS .003" ALUMINUM FOIL W/PERMANENT PRESSURE SENSITIVE ADHESIVE.

2) ALL LETTERING IS .125" HIGH EUROSTYLE 2, BOLD EXTENDED 2.


3) USE QUADREL STANDARD LOGO.

4) ALL LINES AND LETTERS ARE BLACK ON A SILVER BACKGROUND QUADREL AND (WEB PATH) ARE RED #(199c) LINES ARE DASHED LINES.

5) LABEL SIZE 3.0" X 3.0".

A	5-8-19	NEW DRAWING
REV	DATE	DESCRIPTION

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

<p>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE</p> <p>.X± .1 .XX± .01 .XXX± .005 ANGLES ± 30'</p> <p>SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030</p>		QUADREL LABELING SYSTEMS	SCALE: DRAWING SCALE
		7670 JENTHER DRIVE	DATE: 5-8-19
	MENTOR, OHIO 44060	DRW BY: TJS	
	(440) 602-4700	CHK BY:	
		APPR BY:	
Q110/120/125 L.H. THREADING DIAGRAM			
MAT'L	SEE NOTES		A26222-110LH

ASSEMBLY TITLE: Q120 SIDE PLATE ASSEMBLY

GENERAL FUNCTION:

- To provide a rigid mounting surface for outboard labeling components, electronic components, and system components.
- The side plate also supports the system mount

SET UP AND ADJUSTMENTS:

- None


MAINTENANCE:

- None

TROUBLESHOOTING:





- None






ITEM	QTY	PART NO.	DESCRIPTION
1	1	00669-01	BRAKE BRUSH
2	2	181062-000	BEARING, ROLL END
3	6	181063-000	BEARING, ROLL END
4	2	361198-000	COLLAR, GUIDE, 1 IN. ID
5	1	791459-000	RUBBER BUMPER
6	1	A20654-003	ADJ. ROD
7	3	A20928-001	ROLLER SHAFT
8	1	A21618-001	IDLER SHAFT
9	1	A22291-006	ROLLER
10	1	A24905-006	PIVOT PIN MOUNTING PLATE
11	1	A25912-000	MOUNTING PIN SPACER
12	3	B20071-002	IDLER ROLLER (DANCER)
13	1	D22800-121	TL HEAD SIDE PLATE REWORK

		A	19-AUG-16	NEW DRAWING	CRT
		REV	DATE	DESCRIPTION	BY
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X±.1 XX±.01 XXX±.005 ANGLES ± 30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030	QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700			SCALE	3/4
				DATE	11-26-13
				DRAWN BY	CRT
Q120 STEPPER SIDE PLATE ASSEMBLY					
MAT'L		22625SP-LHH		22625SP-LHH	







A	19-AUG-16	NEW DRAWING	CRT		
REV	DATE	DESCRIPTION	BY		
		SCALE	1/2		
		DATE	19-AUG-16		
		DRAWN BY	CRT		
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700					
Q120 STEPPER SIDE PLATE ASSEMBLY					
SURFACE FINISH 125 BREAK ALL EDGES .005/015 CORNER RADIUS .010/030					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE					
X± .1 XX± .01 XXX± .005 ANGLES ± .30°					
MAT'L		22625SP-LHH	22625SP-LHH		



ITEM	QTY	PART NO.	DESCRIPTION
1	1	00669-01	BRAKE BRUSH
2	2	181062-000	BEARING, ROLL END
3	6	181063-000	BEARING, ROLL END
4	2	361198-000	COLLAR, GUIDE, 1 IN. ID
5	1	791459-000	RUBBER BUMPER
6	1	A20654-003	ADJ. ROD
7	3	A20928-001	ROLLER SHAFT
8	1	A21618-001	IDLER SHAFT
9	1	A22291-006	ROLLER
10	1	A24905-006	PIVOT PIN MOUNTING PLATE
11	1	A25912-000	MOUNTING PIN SPACER
12	3	B20071-002	IDLER ROLLER (DANCER)
13	1	D22800-121	TL HEAD SIDE PLATE REWORK

A		06-JUN-16		NEW DRAWING	
REV		DATE		DESCRIPTION	
				BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X±.1 XX±.01 XXX±.005 ANGLES ± .30°		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700		SCALE	
				DATE	
				DRAWN BY	
				1/2 06-JUN-16 CRT	
SURFACE FINISH .125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		MAT'L			
		22625SP-RHH		22625SP-RHH	



A	06-JUN-16	NEW DRAWING		CRT	
REV	DATE	DESCRIPTION		BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X± .1 XX± .01 XXX± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		QUADREL LABELING SYSTEMS		SCALE 1/2	
		7670 JENTHER DRIVE		DATE 06-JUN-16	
		MENTOR, OHIO 44060		DRAWN BY CRT	
		(440) 602-4700			
MAT'L		22625SP-RHH		22625SP-RHH	

ASSEMBLY TITLE:**Q120 UNWIND ASSEMBLY****GENERAL FUNCTION:**

- Unwind flange provides support for label rolls (side application)
- Dual flanges prevent roll and label movement (top application)
- Dancer arm prevents roll run-away.
- Idler roller with guide collars guides web through slot sensor.
- Brake brush prevents web buckling through slot sensor.

SET UP AND ADJUSTMENTS:

- Move flange to required height and tighten set screw in flange hub.
- For top labeling, add second flange and tighten ratchet knob.
- Adjust dancer tension by turning check nut so that dancer roll snaps back to braking position when labeling head is threaded.
- Slide brake brush so that center of brush lines up with center of web. Rotate brush to provide web tension, then lock into place using the locking knob.
- Position guide collars on idler roll, one slightly above, the other slightly below the web.

DANCER TENSION ADJUSTMENT LOCATION:

- The unwind tension adjustment is located on the middle underside of the Q120 head. Use the knurled ring to adjust the dancer tension.

MAINTENANCE:

- Clean all the parts that may acquire glue residue


TROUBLESHOOTING:**PROBLEM**

- Unwind roll run-away
- Unwind roll not stopping
- Drive roll stalling
- Brush taking fixed shape

WHAT TO DO

- Tighten dancer spring, check nut or replace dancer spring, if necessary.
- Replace brake ring-belt if broken, or unevenly worn.
- Release web tension produced by brake brush.
- Turn brush around









ITEM	QTY	PART NO.	DESCRIPTION
1	1	111044-000	BEARING, 3/4 ID CLAMP TYPE
2	3	111074-000	BEARING, BALL
3	1	151001-000	BEARING, THRUST WASHER
4	1	151006-000	BEARING, THRUST WASHER
5	4	181063-000	BEARING, ROLL END
6	1	361165-000	COLLAR, SETSCREW, 5/16" BORE
7	1	801601-000	CHECK NUT
8	1	811216-000	EXTENSION SPRING, STAINLESS
9	1	871025-000	EXTERNAL SNAP RING
10	1	A20583-000	QUICK LOCK COLLAR REWORK
11	2	A20585-000	SUPPORT SPACER
12	1	A20590-000	BEARING PLATE
13	1	A20591-000	UNWIND BRAKE DRUM
14	1	A20592-000	UNWIND DANCER SHAFT
15	1	A20593-001	UNWIND SHAFT
16	1	A20595-000	DANCER COLLAR
17	2	A20596-000	DANCER BOLT
18	2	A20928-002	ROLLER SHAFT
19	1	A23131-000	STUD
20	1	A23298-000	BLOCK, SPRING TENSION
21	1	A23406-000	SUPPLY REEL CENTER HUB
22	1	A25825-000_22620	BRAKE BAND
23	2	B20071-003	IDLER ROLLER (DANCER)
24	1	B20980-001	UNWIND FLANGE
25	1	B21113-000	DANCER ARM, 16" UNWIND
26	1	B21931-001	CORE HUB
27	1	C21236-120	UNWIND SUPPORT PLATE

NOT SHOWN:

B21931-006 CORE HUB 6"

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
<small>UNLESS OTHERWISE SPECIFIED: DIMENSIONAL TOLERANCE FRACTIONS 1/32 DECIMALS .005 ANGLES .5° SURFACE FINISH 125 BREAK ALL EDGES .005 DIA CORNER RADIUS .010/.030</small>	REV	DATE	DESCRIPTION
	A	05-OCT-15	NEW DRAWING
	BY		CRT
	DRAWN BY	DATE	DATE
QUADREL LABELING SYSTEMS 7670 JENTNER DRIVE MENTOR, OHIO 44060 (440) 602-4700 Q120 7" UNWIND ASSEMBLY, RHH			
MAT'L	22620U-RHH		22620U-RHH



SHEET 2 OF 2

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED			
DIMENSIONAL TOLERANCE			
X.XX ± .01			
X.XX ± .05			
ANGLES ± .30°			
SURFACE FINISH 125			
BREAK ALL EDGES AND ROUNDS			
CORNER RADIUS .010/.030			
Q120 7" UNWIND ASSEMBLY, RHH			
MAT'L			
22620U-RHH		22620U-RHH	

ASSEMBLY TITLE: Q120 PEEL PLATE ASSEMBLY

GENERAL FUNCTION:

- The peel plate separates the label from the liner and puts the label in a "Flag" position.
- The mounting rods support the slot sensor assembly.
- The guide collars and the idler roller guide the web position over the peel plate
- The pivot pin provides for yoke mounting of the labeling head.

SET UP AND ADJUSTMENTS:

- On machines so equipped, the peel plate may be pivoted at various angles relating to the product by loosening the peel plate mounting bar. (The peel plate of all other models is mounted at a fixed angle and cannot be adjusted)
- To advance label flag on peel plate, move the slot sensor towards the peel plate. To decrease label flag, move slot sensor away from the peel plate.
- Position guide collars on idler roll, one slightly above and the other slightly below the web.

MAINTENANCE:

- Clean all the parts that may acquire labels or glue residue.

TROUBLESHOOTING:


PROBLEM

- Too much label flag at peel plate
- Too little label flag at peel-
- Web moving up and down peel plate


WHAT TO DO

- Move slot sensor away from peel edge
- Move slot sensor towards peel plate edge
- Make sure guide collars are properly positioned on idler roll.







SHEET 1 OF 2




ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	4	181063-000	BEARING, ROLL END	21343PP-00R
2	4	361198-000	COLLAR, GUIDE, 1" ID	21343PP-00R
3	1	801857-000	ADJUSTABLE HANDLE	21343PP-00R
4	1	871369-000	DOWEL PIN, 1/4 DIA X 1/2 LONG	21343PP-00R
5	1	A21758-000	SIDE PLATE	21343PP-00R
6	1	A21758-001	SIDE PLATE	21343PP-00R
7	1	A22245-000	PRESSURE SHOE MOUNTING BAR - 7"	21343PP-00R
8	2	A23791-003	SHAFT, IDLER ROLLER	21343PP-00R
9	2	B21198-003	IDLER ROLLER-(PEEL PLATE)	21343PP-00R
10	1	B7639-000		21343PP-00R




A	05-FEB-2024	NEW DRAWING
REV	DATE	DESCRIPTION

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY


UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030	 QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	SCALE: 1.000
		DATE: 05-FEB-2024
		DRW BY: CRT
		CHK BY: 03/07/2024-SEM
		APPR BY:

7" PEEL PLATE ASSEMBLY	
MAT'L	21343PP-00R




ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	4	181063-000	BEARING, ROLL END	21343PP-00L
2	1	22811-000	HANDLE ASSEMBLY, LEFT HANDED	21343PP-00L
3	4	361198-000	COLLAR, GUIDE, 1" ID	21343PP-00L
4	1	871369-000	DOWEL PIN, 1/4 DIA X 1/2 LONG	21343PP-00L
5	1	A21758-000	SIDE PLATE	21343PP-00L
6	1	A21758-001	SIDE PLATE	21343PP-00L
7	1	A22245-002	PRESSURE SHOE MOUNTING BAR - 7"	21343PP-00L
8	2	A23791-003	SHAFT, IDLER ROLLER	21343PP-00L
9	2	B21198-003	IDLER ROLLER-(PEEL PLATE)	21343PP-00L
10	1	B7639-000		21343PP-00L

NOT SHOWN:
A21230-021 CUT DOWN PRESSURE SHOE, 3.25"
B20529-064L CUT DOWN PEEL PLATE, 3.25" LH
791852-000 PEEL PLATE TAPE





THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE			A	05-FEB-2024	NEW DRAWING
			REV	DATE	DESCRIPTION
			SCALE: 0.875		
			DATE: 05-FEB-2024		
			DRW BY: CRT		
			CHK BY: 03/07/2024-SEM		
			APPR BY:		
SURFACE FINISH 125 BREAK ALL EDGES 0.005/0.015 CORNER RADIUS 0.018/0.030			7" PEEL PLATE ASSEMBLY		
		MAT'L	21343PP-00L		

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE
X ± .1
XX ± .01
XXX ± .005
ANGLES ± .30°
SURFACE FINISH 125
BREAK ALL EDGES .005/.015
CORNER RADIUS .010/.030



QUADREL LABELING SYSTEMS
7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

SCALE: 0.875
DATE: 05-FEB-2024
DRW BY: CRT
CHK BY: 03/07/2024-SEM
APPR BY:







A	2-5-24	NEW DRAWING	CRT
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE	SCALE: 1.000 DATE: 05-FEB-2024 DRW BY: CRT CHK BY: &CREO.CHK APPR BY:
XXX ± .01 XXX ± .005 ANGLES ± .00°	QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700

SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°	7" PEEL PLATE ASSEMBLY	MAT'L	21343PP-00L
--	------------------------	-------	-------------

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	801899-000	HANDLE	22811-000
2	1	841812-000	STUD	22811-000



A	Feb-05-24	NEW DRAWING	CRT
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		QUADREL LABELING SYSTEMS	
		7670 JENTHER DRIVE	
		MENTOR, OHIO 44060	
		(440) 602-4700	
		SCALE:	2/1
		DATE:	Feb-05-24
		DRW BY:	CRT
		CHK BY:	
		APPR BY:	
HANDLE ASSEMBLY, LEFT HANDED THREAD			
MAT'L			22811-000

ASSEMBLY TITLE: FIXED BRUSH IMPRESSER

DRAWING NO.: D21651-000

GENERAL FUNCTION:

- The fixed roller impresser is an option used in applications where a secondary wipe down or label wipe is necessary.

SET UP AND ADJUSTMENTS:

- When installed, the brush assembly will be mounted by an adjustable clamp. The mounting assembly is fastener to the option rail located on the peel plate side wall.
- Four axis of adjustment is available by loosening the set screw locking the roller arm in place.
- Locate the brush as necessary and re-tighten the clamping screws.
- Run a product through the brush area and insure the brush layed on the product but do not impede product travel. The brush can be adjusted too close to the product which will prevent the product from smoothly traversing through the brush area.

MAINTENANCE:

- Keep the brush free of label flash, glue and debris. This will prevent jamming and web tears.

NOTE: Exercise caution when removing bad labels from brush. Careless removal can result in brisals being pull out which may leave the labeler inoperable until the brush is replaced!

TROUBLESHOOTING:

PROBLEM

- Product jams at brush area
- Bubbles in label
- Label edge curling
- Wipedown inadequate

WHAT TO DO

- Increase brush spacing.
- Decrease labeling speed
- Decrease product delay
- Decrease brush spacing.




ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	A21264-018	CROSS ARM	10228-005
2	1	A21693-300		10228-005
3	1	A21758-300		10228-005
4	1	A23463-100	BRUSH HOLDER	10228-005

NOT SHOWN:

A28416-033 SQUEEGEE, 3.25"



A	Mar-02-20	NEW DRAWING		TJS	
REV	DATE	DESCRIPTION		BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .01 XXX ± .005 ANGLES ± 30° SURFACE FINISH .125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700		SCALE	1/1
				DATE	Mar-02-20
				DRAWN BY	TJS
HEAVY DUTY IMPRESSOR					
MAT'L		10228-005		10228-005	



A	Mar-02-20	NEW DRAWING		TJS	
REV	DATE	DESCRIPTION		BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 .XX ± .01 XXX ± .005 ANGLES ± .50°		SCALE		3/4	
		DATE		Mar-02-20	
		DRAWN BY		TJS	
SURFACE FINISH: 125 BREAK ALL EDGES: .005/.015 CORNER RADII: .010/.030		QUADREL LABELING SYSTEMS			
		7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700			
MAT'L		HEAVY DUTY IMPRESSOR			
		10228-005		10228-005	

ASSEMBLY TITLE:**Q120 DRIVE AND PINCH ROLL ASSEMBLY****GENERAL FUNCTION:**

- The drive roll pulls the liner through the entire labeling head. As the liner is pulled over the peel edge, the label dispenses.
- The spring-loaded pinch roll squeezes the liner against the drive roll to provide positive drive.
- The primary roll is the pull or drive roll as shown. The knurl roll provides a constant pressure against the pull roll.

SET UP AND ADJUSTMENTS:

- When threading the labeling head, use the pinch roll lever to release the pinch roll from the drive roll.
- Use the spring plunger adjustment screws to adjust the contact pressure between the knurl and pull rollers.
- The pressure should be adjusted as tight as necessary to prevent a loose liner, while still allowing full rotation of the pressure release arm.

MAINTENANCE:

- Clean all parts that may have acquired label or glue residue


TROUBLESHOOTING:**PROBLEM**

- Meter pulley rubbing against side plate
- Web slips
- Drive roll not rotating when stepping motor rotates
- Pinch roll not providing enough pressure against drive roll
- Drive roll unevenly worn causing tracking problem

WHAT TO DO





- Center pulley on motor shaft and tighten two (2) set screws in pulley.
- Drive roller not closed. Turn drive roll arm to closed position.
- Replace timing belt from motor to drive roll
- Replace pinch roll spring
- Increase tension on drive roll by adjusting spring loaded locking pins.
- Replace drive roll






ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	00301-17	SPRING, .275 x .052 x .94	22625DS-RHH
2	2	111072-000	BEARING, BALL	22625DS-RHH
3	2	151004-000	BEARING, THRUST WASHER	22625DS-RHH
4	1	191592-000	BELT, TIMING, 3/8P	22625DS-RHH
5	1	362161-000	COLLAR, SETSCREW, 1/2 IN. ID	22625DS-RHH
6	1	363157-002	SERVO COUPLING	22625DS-RHH
7	1	413041-000		22625DS-RHH
8	1	21700DY-001		22625DS-RHH
9	2	A20567-000	WHITE NYLON SLUG	22625DS-RHH
10	4	A20568-125	DRIVE MOTOR RISER	22625DS-RHH
11	1	A21421-000	DRIVE PULLEY (MODIFIED)	22625DS-RHH
12	1	A21750-000	PINCH POINT GUARD ROD	22625DS-RHH
13	1	A23125-000	SPACER	22625DS-RHH
14	1	A23751-000	SPACER	22625DS-RHH
15	1	A23752-000	SPACER	22625DS-RHH
16	1	A25249-000	INDEX DOT	22625DS-RHH
17	1	A25250-000	IND KNOB	22625DS-RHH
18	1	B20125-001	KNURLED ROLL SHAFT,	22625DS-RHH
19	1	B20126-001	KNURLED ROLL	22625DS-RHH
20	1	B20137-002	PULL ROLL, 7"	22625DS-RHH
21	1	C20097-611	PULL ROLL DRIVE SHAFT	22625DS-RHH

A	Nov-08-21	NEW DRAWING		TAZ	
REV	DATE	DESCRIPTION		BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .01 XX ± .01 XXX ± .005 ANGLES ± 30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		QUADREL LABELING SYSTEMS		SCALE	9/16
		7670 JENTHER DRIVE		DATE	Nov-08-21
		MENTOR, OHIO 44060		DRAWN BY	TJS
		(440) 602-4700			
		DRIVE ROLL ASSEMBLY, 7"			
MAT'L		22625DS-RHH		22625DS-RHH	







A		Nov-08-21		NEW DRAWING	
REV		DATE		DESCRIPTION	
				BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE				SCALE 5/8	
7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700				DATE Nov-08-21	
				DRAWN BY TAZ	
X ± .1 XX ± .01 XXX ± .005 ANGLES ± 30°					
DRIVE ROLL ASSEMBLY, 7"					
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030				MAT'L	
22625DS-RHH				22625DS-RHH	

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	111052-000	BEARING	21700DY-000
2	1	B21614-000	YOKE OUTSIDE PLATE	21700DY-000
3	1	B21615-000	YOKE INSIDE PLATE	21700DY-000
4	1	B21616-001	YOKE FILLER BAR	21700DY-000




A	3-18-08	NEW DRAWING
REV	DATE	DESCRIPTION

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY		
<div>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE</div> <div><div>X ± .1</div><div>XX ± .01</div><div>XXX ± .005</div><div>ANGLES ± 30°</div></div> <div><div>SURFACE FINISH 125</div><div>BREAK ALL EDGES .005/.015</div><div>CORNER RADIUS .010/.030</div></div>	<div></div> <div><div>QUADREL LABELING SYSTEMS</div><div>7670 JENTHER DRIVE</div><div>MENTOR, OHIO 44060</div><div>(440) 602-4700</div></div>	SCALE: 1/1
		DATE: 3-18-08
		DRW BY: ATT
		CHK BY:
		APPR BY:
3 PIECE ROLL ASSEMBLY		
MAT'L	21700DY-000	C20800-001



A	3-18-08	NEW DRAWING
REV	DATE	DESCRIPTION

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY		
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± 30' SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030	 QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	SCALE: 3/4
		DATE: 3-18-08
		DRW BY: ATT
		CHK BY:
		APPR BY:
3 PIECE ROLL ASSEMBLY		
MAT'L	21700DY-000	C20800-001

ASSEMBLY TITLE:**Q120 REWIND ASSEMBLY****GENERAL FUNCTION:**

- The rewind drum rolls up the liner
- The rewind pin, when pulled out, allows the liner to be released from the rewind drum.
- The rewind flange supports and guides the liner.
- The friction clutch allows for slippage to accommodate for varying speeds between the drive roll and rewind drum.
- The adjusting knob controls the torque adjustment of the drum.

SET UP AND ADJUSTMENTS:

- Position the rewind flange slightly below the web path and lock with the set screw in the hub.
- When threading liner to the rewind, place the liner between the drum and pin.
- Tighten adjusting knob just enough to allow the rewind drum to keep up with the drive roll.

NOTE: Excessive tightening will cause the web to be wound very tight, causing difficulty in removal and possible step motor stall.

MAINTENANCE:

- Clean all parts that have acquired label or glue residue
- Replace friction disc when worn out.


TROUBLESHOOTING:**PROBLEM**

- Rewind drum not rotating when stepping motor rotates
- Rewind drum not keeping up with drive roll
- Web winding too tight on hub
- Grinding in rewind hub

WHAT TO DO

- Replace timing belt from motor to rewind
- Tighten adjusting knob
- Loosen adjusting knob
- Replace friction disc by removing knob and sliding off rewind drum









ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	3	111075-000	BEARING, BALL	22625RS-RHH
2	1	121067-000	BEARING, NEEDLE	22625RS-RHH
3	2	151008-000	BEARING, THRUST WASHER	22625RS-RHH
4	4	181063-000	BEARING, ROLL END	22625RS-RHH
5	1	181081-000	BEARING, NEEDLE ROLLER	22625RS-RHH
6	2	181082-000	BEARING, THRUST WASHER	22625RS-RHH
7	1	361302-000	DASHPOT	22625RS-RHH
8	2	A20928-002	ROLLER SHAFT	22625RS-RHH
9	1	A22120-000	REWIND PULLEY ASSEMBLY	22625RS-RHH
10	1	B20004-120	REWIND BEARING PLATE	22625RS-RHH
11	1	B20005-125	GUARD	22625RS-RHH
12	2	B20071-003	IDLER ROLLER (DANCER)	22625RS-RHH
13	1	B20747-000	DASHPOT REWIND SHAFT	22625RS-RHH
14	1	C20894-004	REWIND DANCER ARM	22625RS-RHH
15	1	C20896-126	MOTOR COVER SIDE PLATE	22625RS-RHH
16	1	C20897-126	Q120 STEPPING MOTOR COVER	22625RS-RHH

A	Nov-08-21	NEW DRAWING	TJS
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE $.XX \pm .01$ $.XXX \pm .005$ ANGLES $\pm 30^\circ$	QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700		SCALE 5/8
			DATE Nov-08-21
			DRAWN BY TJS
Q120 RH REWIND			
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030	MAT'L	22625RS-RHH	22625RS-RHH



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE
X ± .1
XX ± .01
XXX ± .005
ANGLES ± 30°
SURFACE FINISH 125
BREAK ALL EDGES .005/.015
CORNER RADIUS .010/.030

QUADREL LABELING SYSTEMS
7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

Q120 RH REWIND

MAT'L22625RS-RHH

REVDATEDESCRIPTIONBY


A Nov-08-21NEW DRAWINGTJS

SCALE3/4

DATE Nov-08-21

DRAWN BYTJS





22625RS-RHH



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	22597-000	COLLAPSIBLE REWIND LOCKING HANDLE	22188-000
2	1	841145-000	1/4 X 1/2 LG. SHOULDER BOLT	22188-000
3	1	A22090-001	COLLABSIBLE REWIND REEL HUB	22188-000
4	1	A23112-001	COLLAPSIBLE REWIND FLANGE	22188-000
5	1	B22103-003	REWIND HUB	22188-000
6	1	B22141-001	SHAFT ASSEMBLY	22188-000
7	2	CSEE253	10-32 X 3/8 LG. FLAT HEAD	22188-000
8	1	SYE103	1/4-20 X 5/8 LG. SET SCREW	22188-000


A	Mar-30-21	NEW DRAWING	TJS
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
XX ± .01 XXX ± .005 ANGLES ± 30°		SCALE	1/1
SURFACE FINISH .125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		DATE	Mar-30-21
		DRAWN BY	TJS
		7" COLLAPSIBLE REWIND ASSEMBLY	
MAT'L		22188-000	22188-000



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
X ± .1 XX ± .01 XXX ± .005 ANGLES ± 30°		SCALE 3/4 DATE Mar-30-21 DRAWN BY TJS	
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		7" COLLAPSIBLE REWIND ASSEMBLY	
MAT'L		22188-000	22188-000

ITEM	QTY	PART NO.	DESCRIPTION
1	1	871352-000	DOWELL,PIN 1/8" x 1/2" SS.
2	1	871352-000	DOWELL,PIN 3/32" x 1/2" SS.
3	1	A22081-000	COLLAPSIBLE REWIND CAM
4	1	A25272-001	COLLAPSIBLE REWIND SHAFT
5	2	#4-40X0-500	SHCS #4-40 UNC 1/2" LG.




A	06/09/2008	NEW DRAWING
REV	DATE	DESCRIPTION





THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± 30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030	 QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (216) 975-0006	SCALE: 1/1
		DATE: 06/09/2008
		DRW BY: SEM
		CHK BY:
		APPR BY:
SHAFT ASSEMBLY 7.0"		
MATERIAL		B22141-001

ITEM	QTY	PART NO.	DESCRIPTION
1	1	871352-000	DOWELL,PIN 1/8" x 1/2" SS.
2	1	A26128-000	CLEVIS
3	1	A26129-000	HANDLE
4	1	SYE601	1/4-20 X 1-1/4 LG. SET SCREW



A		12-11-14		NEW DRAWING	
REV	DATE	DESCRIPTION		BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X± .1 XX± .01 XXX± .005 ANGLES ± .30°	QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700			SCALE	4/1
				DATE	12-11-14
				DRAWN BY	ATT
COLLAPSIBLE REWIND LOCKING HANDLE					
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		MAT'L		22597-000	22597-000



A	12-11-14	NEW DRAWING		
REV	DATE	DESCRIPTION		BY
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY				
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X± .1 XX± .01 XXX± .005 ANGLES ± .30°	QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700		SCALE	4/1
			DATE	12-11-14
			DRAWN BY	ATT
COLLAPSIBLE REWIND LOCKING HANDLE				
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		MAT'L	22597-000	22597-000

ASSEMBLY TITLE: Q60 KINETROL REWIND

GENERAL FUNCTION:

- The rewind drum rolls up the liner
- The collapsible rewind shaft when closed allows the liner to be removed easily. The normal running position for the shaft is in the open position
- The rewind flange supports and guides the liner
- The Kinetrol clutch allows for slippage to accommodate for varying speeds between the drive roll and rewind drum
- The adjusting knob controls the torque adjustment of the drum and is set at the factory.

SET UP AND ADJUSTMENTS:

- Position the rewind flange slightly below the web path and lock with the set screw in the hub
- When threading liner to the rewind, place the liner between the drum and pin
- Tighten adjusting knob just enough to allow the rewind drum to keep up with the drive roll.
- Loosen set screw before adjustment and re-tighten after adjustment

NOTE: Excessive tightening will cause the web to be wound very tight, causing difficulty in removal and possible step motor stall.

MAINTENANCE:

- Clean all parts that have acquired label or glue residue

TROUBLESHOOTING:

PROBLEM

- Rewind drum not rotating when stepping motor rotates
- Rewind drum not keeping up with drive roll
- Web winding too tight on hub
- Grinding in rewind hub

WHAT TO DO

- Replace timing belt from motor to rewind
- Adjust clutch dial (1 being loosest & 10 being tightest)
- Loosen adjusting knob
- Replace Kinetrol

Set screw location



ASSEMBLY TITLE: SLOT SENSOR ASSEMBLY

GENERAL FUNCTION:

- The slot sensor detects the separation between labels. This signals the electronics to stop the drive motor.
- The two (2) liner support rods prevent the liner from wearing out the slot sensor.
- The knob and thumbscrew lock the sensor firmly on the mounting rods.
- The male connector provides quick connection to the labeling head.

SET UP AND ADJUSTMENTS:

- See attached cut sheet


MAINTENANCE:

- Keep the sensor optical area clean from label and glue residue

TROUBLESHOOTING:





<u>PROBLEM</u>	<u>WHAT TO DO</u>
- No power to the sensor	- Check male connector and tightly secure connection to the head.
- Liner dragging over the slot	- Loosen knob and rotate slot sensor slot sensor surface liner rests on both support rods
- Too much slack through slot sensor	- Adjust brake brush tension
- Slot sensor moving with web	- Tighten all three (3) adjusting knobs

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	201444-301	SENSOR	20033-301
2	2	801297-000	THUMB SCREW PLSTC HEAD 8-32x1	20033-301
3	2	801299-000	KNOB WITH STUD	20033-301
4	1	A21391-300	SLOT SENSOR ADAPTER	20033-301
5	4	A21749-300	SLOT SENSOR SUPPORT ROD MTG BLOCK	20033-301
6	2	A21770-300	SUPPORT ROD WITH FLAT	20033-301
7	1	B20852-300	7 IN. WEB SLOT SENSOR MTG. BAR	20033-301
8	1	203035-000	CABLE, M8, 4COND	NOT SHOWN



A	JAN-05-21	NEW DRAWING	TJS
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30°		SCALE: 1/1 DATE: JAN-05-21 DRW BY: TJS CHK BY: 03/19/2024-SEM APPR BY:	
SURFACE FINISH 125 BREAK ALL EDGES .005/0.15 CORNER RADIUS .010/0.50		LABEL DETECT ASSEMBLY	
MAT'L		20033-301	




THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY		QUADREL LABELING SYSTEMS	
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
X ± .1 XX ± .01 XXX ± .005 ANGLES ± .50°		SCALE: 1/1 DATE: JAN-05-21 DRW BY: TJS CHK BY: 03/19/2024-SEM APPR BY:	
SURFACE FINISH: 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		LABEL DETECT ASSEMBLY	
MAT'L		20033-301	

Installation Manual



CLSC-1M8LEX185

1. Position Label



Align Label to Arrow (above)


Place the label web so that it is centered on the arrow. The arrow is where the transducers are aligned.

Align Gap to Line (right top)

Place label gap in center of the sensor using the alignment line as shown on right. When viewing from the top of the sensor, use the output LED to center label gap.

Gentle Tension (right bottom)

Place label webbing so that it slides along the bottom of the sensor gap plate. This will ensure a more consistent setup and performance.



2. Setup Instructions

Once the Gap is in view, press and hold the AUTOSET/GAP button for two seconds. This will result in a stable setup most every time. If you have any false triggers, put the Label in view, push and hold the AUTOSET/LABEL button for two seconds. This two-point setup will create a new threshold setting resulting in a more consistent signal span between web and label.

Note: Manual adjust by tapping arrows.

MULTI-FUNCTION OUTPUT INDICATOR

1. Illuminates when outputs are ON.
Note: Flashes when short circuit is detected.
2. Rapid flash indicates AUTOSET start (wait two seconds to complete).
3. Single flash during manual adjust.

AUTOSET/GAP Δ BUTTON

1. Push and Hold with gap in view for two seconds for AUTOSET.
2. Tap for UP to lower threshold.

AUTOSET/LABEL ∇ BUTTON

1. Push and Hold with label in view after GAP AUTOSET on rare occasions when labels have multiple layers.
2. Tap DOWN to increase threshold.

LT/DK Toggle

Light / Dark output toggle (inverts output).



Specifications

SUPPLY VOLTAGE

- 12 to 30 VDC
 - Polarity Protected
- Note: For use in Class 2 Circuits*

CURRENT REQUIREMENTS

- 95mA @ 12 VDC, 45mA @ 30 VDC

DIGITAL OUTPUTS

- (1) NPN and (1) PNP open collector output 150mA Max; <2V Residual Voltage
- All outputs are continuously short circuit protected

DIAGNOSTIC INDICATOR

- Illuminates when outputs are ON.
- Note: Flashes when short circuit is detected.*
- Rapid flash indicates AUTOSET start (wait two seconds to complete).
 - Single flash during manual adjust.

PUSHBUTTON CONTROL

- Three (3) push button controls
- Gap (for Gap AUTOSET)
- Label (for multi-layered labels)
- LT/DK= Light / Dark toggle

HYSTERESIS

- Dynamic – adjusted by AUTOSET

RESPONSE TIME

- 200µs

REPEATABILITY

- 125µs


AMBIENT TEMPERATURE

- 4°C to 50°C (39°F to 122°F)

RUGGED CONSTRUCTION

- Chemical resistant, high impact Aluminum housing
- Waterproof ratings: IP65
- Conforms to heavy industry grade CE requirements

ULTRASONIC
CLEAR
LABEL SENSOR



THRESHOLD SET

- 1-Point, 2-Point.

THRESHOLD ADJUST

- Manual Adjust


CONNECTOR

- M8 4-Pin

RoHS Compliant
Product subject to change without notice

Connections and Dimensions

Ultrasonic Clear Label Sensor X185



system

ASSEMBLY TITLE: FRAME ASSEMBLY

GENERAL FUNCTION:

- Provides solid mounting for labeling head if not installed on a system that allows for vertical and horizontal adjustment.
- Allows for vertical and horizontal adjustment in the setup of the labeling head operation.


SET-UP AND ADJUSTMENTS:

- Rotate leveling pads to appropriate position. Secure locknut when proper height is achieved.
- Using ratchet handle, adjust labeling head vertical and horizontal position.

MAINTENANCE:





- Clean wipe down rails with clean cloth.

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	4	729006-000	CAP INSERT FOR 2 X 4 TUBE	84224F-000
2	4	791449-000	SWIVEL CASTER	84224F-000
3	4	793020-000	LEVELING MOUNT	84224F-000
4	4	B22787-000	CONVEYOR RISER	84224F-000
5	1	D24424-84224	WELDED FRAME ASSEMBLY	84224F-000
6	2	D24425-84224	WIRE COVER	84224F-000



A	Oct-20-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30°		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
		SCALE: 3/16 DATE: Oct-20-25 DRW BY: TAZ CHK BY: APPR BY:	
		CONVEYOR MTG FRAME	
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030	MAT'L	84224F-000	84224F-000




THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE

X ± .1
XX ± .01
XXX ± .005
ANGLES ± .50°


SURFACE FINISH 125
BREAK ALL EDGES .005/ .015
CORNER RADIUS .010/ .030
ALL ANGLES ARE 90°

QUADREL LABELING SYSTEMS
7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700



SCALE: 3/16
DATE: Oct-20-25
DRW BY: TAZ
CHK BY:
APPR BY:

A	Oct-20-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY
CONVEYOR MTG FRAME			
MAT'L		84224F-000	84224F-000



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	141172-000	SLEEVE BEARING, 1/20D. x 3/8ID. x 3/4LNG	22867-11
2	1	141177-000	SLEEVE BEARING, 5/8OD. x 1/2ID. x 3/4LNG	22867-11
3	2	181108-000	BEARING, NEEDLE ROLLER	22867-11
4	4	181111-000	THRUST WASHER	22867-11
5	1	362186-000	COLLAR, 3/8 IN. ID ONE-PIECE CLAMP	22867-11
6	2	729006-000	CAP INSERT FOR 2 X 4 TUBE	22867-11
7	4	792248-001	PILLOW BLOCK	22867-11
8	1	792354-002	DIGITAL POSITION INDICATOR	22867-11
9	1	793035-001	DRYLIN RAIL	22867-11
10	1	801080-000	6" HANDWHEEL	22867-11
11	1	A24077-000	BRONZE NUT, RH	22867-11
12	1	B20045-200	THREADED ROD	22867-11
13	1	B21346-000	BOTTOM BEARING PLATE	22867-11
14	1	B22005-012	BEARING PLATE	22867-11
15	1	B22790-002	TOP PACING CONNECTOR PLATE	22867-11
16	1	B22791-010	TOP TRAP SPACER	22867-11
17	1	B22791-011	TOP TRAP SPACER	22867-11
18	1	B22791_750	TOP TRAP SPACER	22867-11
19	1	C21292-001	TOP TRAP RISER	22867-11
20	1	C21293-001	TOP TRAP MOUNTING PLATE	22867-11
21	2	C21293-023	TOP TRAP MOUNTING PLATE	22867-11

A		Oct-20-25	NEW DRAWING		TAZ
REV	DATE	DESCRIPTION	BY		

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE

.XX ± .1
XXX ± .005
ANGLES ± .90°

SURFACE FINISH 125
BREAK ALL EDGES .005/ .015
CORNER RADII .010/ .030
ALL ANGLES ARE 90°

QUADREL LABELING SYSTEMS

7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

SCALE: 3/8

DATE: Oct-20-25





DRW BY: TAZ

CHK BY:

APPR BY:


TOP PACING UPRIGHT ASSEMBLY 7.5"W CONVEYORS

MAT'L	22867-11	22867-11
-------	----------	----------







THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/4	
X ± .1		DATE: Oct-20-25	
XX ± .01		DRW BY: TAZ	
XXX ± .005		CHK BY:	
ANGLES ± .00°		APPR BY:	
SURFACE FINISH 125		TOP PACING UPRIGHT ASSEMBLY 7.5"W CONVEYORS	
BREAK ALL EDGES .005/.015		MAT'L	
CORNER RADIUS .010/.030		22867-11	
ALL ANGLES ARE 90°		22867-11	

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	729006-000	CAP INSERT FOR 2 X 4 TUBE	22615-027
2	1	791449-000	SWIVEL CASTER	22615-027
3	1	A24366-000	MODIFIED LEVELING MOUNT	22615-027
4	1	D25140-027	SUPPORT LEG	22615-027



A	Aug-19-22	NEW DRAWING	TJS	
REV	DATE	DESCRIPTION	BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY				
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE XX ± .01 XXX ± .005 ANGLES ± .30° SURFACE FINISH .125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700		
		SCALE	7/8	
		DATE	Aug-19-22	
		DRAWN BY	TJS	
ELECTRICAL BOX SUPPORT LEG				
MAT'L		22615-027	22615-027	



A	Aug-19-22	NEW DRAWING		TJS	
REV	DATE	DESCRIPTION		BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± 30°		SCALE		5/8	
		DATE		Aug-19-22	
		DRAWN BY		TJS	
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADII .010/.030		QUADREL LABELING SYSTEMS			
		7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700			
MAT'L		ELECTRICAL BOX SUPPORT LEG			
		22615-027		22615-027	

ASSEMBLY TITLE: NON-INTEGRATED CONVEYOR

GENERAL FUNCTION:

- To transfer the product to the labeling heads at a predetermined speed.
- To provide retention for the head support and guide rails.

SET-UP AND ADJUSTMENTS:

- Adjust conveyor to proper working height by rotating leveling pads to appropriate position. Secure locknut when proper height is achieved.
- Using ratchet handles, adjust guide rails to the product.
- Adjust conveyor speed by means of conveyor speed potentiometer (if applicable) located in the remote electronics enclosure mounted to the conveyor, or through the operator's touchscreen if provided.

MAINTENANCE:

- The conveyor drive chain must be greased with white lithium grease.
- Do not allow chain and sprockets to run dry, lubricate periodically.
- The gear motor gearbox should be checked quarterly and filled with Synthetic based Tivela Oil SC320 or an ISO320 Gear Lube lubricant.
- Grease flange bearings often to prevent them from running dry.

TROUBLESHOOTING:


PROBLEM

- Excessive Noise
- Chain too loose
- Uneven wear on sprockets.
- Shaft not running concentric

WHAT TO DO

- Realign sprocket.
- Check if chain and sprockets are lubricated. If dry, lubricate as discussed above.
- Slide gear motor downward to create more tension on chain.
- Realign sprockets.
- Replace flange bearing.





ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	22612-002	CONVEYOR INFEED 1'	22575-84224
2	1	171033-001	BEARING	22575-84224
3	1	192571-000	TIMING BELT 150XL037	22575-84224
4	1	342019-002	DRIVE SPROCKET, MODULINE	22575-84224
5	1	351166-000	TIMING PULLEY	22575-84224
6	1	361088-002-20	TABLE TOP CHAIN	22575-84224
7	1	413016-000	GEARMOTOR-3/8HP-57 RPM 3PHASE	22575-84224
8	34	791873-000	SPACER	22575-84224
9	2	792322-000_108	WEAR STRIP, FLAT BAR CLIP-ON	22575-84224
10	1	792361-000L-93	WEAR STRIP, FLAT BAR CLIP-ON (6ft)	22575-84224
11	1	792361-000R-93	WEAR STRIP, FLAT BAR CLIP-ON (6ft)	22575-84224
12	1	A25119-500	DRIVE SHAFT PULLEY	22575-84224
13	1	A25127-000	ENCODER COVER PLATE	22575-84224
14	1	B20237-507	CONVEYOR DRIVE SHAFT	22575-84224
15	2	B22558-004	SPLICE PLATE	22575-84224
16	1	D24421-84224L	CONVEYOR SIDE WALL	22575-84224
17	1	D24421-84224R	CONVEYOR SIDE WALL	22575-84224
18	1	202123-003	CUBE ENCODER	22575-84224

A	Oct-20-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE

X ± .1
XX ± .01
XXX ± .005
ANGLES ± .30°

SURFACE FINISH 125
BREAK ALL EDGES .005/.015
CORNER RADIUS .010/.030

QUADREL LABELING SYSTEMS

7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

7.5" WIDE CONVEYOR ASSEMBLY

MAT'L 22575-84224

SCALE: 3/16





DATE: Oct-20-25

DRW BY: TAZ

CHK BY:

APPR BY:

22575-84224




REV	DATE	DESCRIPTION	BY
A	Oct-20-25	NEW DRAWING	TAZ

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY


UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE	SCALE: 3/16
XX ± .01	DATE: Oct-20-25
XXX ± .005	DRW BY: TAZ
ANGLES ± .00°	CHK BY:
	APPR BY:





7.5" WIDE CONVEYOR ASSEMBLY	
MAT'L	22575-84224
	22575-84224

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	342018-000	IDLER WHEEL	22612-002
2	2	791873-000	SPACER	22612-002
3	1	A23098-107	CONVEYOR IDLER SHAFT	22612-002
4	2	A23099-002	CHAIN BELT GUIDE	22612-002
5	1	D25007-004	SIDE WALL EXTENTION INFEED	22612-002
6	1	D25007-005	SIDE WALL EXTENSION INFEED	22612-002



A	Oct-20-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE $X \pm .1$ $XX \pm .01$ $XXX \pm .005$ ANGLES $\pm .30^\circ$		QUADREL LABELING SYSTEMS	
		7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030	CONVEYOR INFEED 1'		SCALE: 1/2 DATE: Oct-20-25 DRW BY: TAZ CHK BY: APPR BY:
	MAT'L	22612-002	22612-002




A	Oct-20-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 3/4	
X ± .1		DATE: Oct-20-25	
XX ± .01		DRW BY: TAZ	
XXX ± .005		CHK BY:	
ANGLES ± .50°		APPR BY:	
SURFACE FINISH 125		CONVEYOR INFEEED 1'	
BREAK ALL EDGES .005/ .015		MAT'L	
CORNER RADIUS .010/ .030		22612-002	
ALL ANGLES ARE 90°		22612-002	



QUADREL LABELING SYSTEMS
7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700





ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	791732-000	CLAMP FOR CONICAL SIDE GUIDE	22435-034
2	1	791914-002_06	MYLAR SCALE, QUADREL LOGO	22435-034
3	1	791914-003_06	MYLAR SCALE, QUADREL LOGO, 6" LG.	22435-034
4	1	792711-000	CAP, ORANGE	22435-034
5	2	801308-000	KNOB W/ 1/4-20 STUD	22435-034
6	1	A20875-000	RETAINER BLOCK, CONV. RAIL	22435-034
7	1	A20876-000	RETAINER BLOCK	22435-034
8	1	A21198-199	ADJUSTMENT ROD	22435-034
9	1	A28000-000	CLAMPING ROD ASSEMBLY 6"	22435-034




A	Aug-07-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY


THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE XX ± .01 XXX ± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADII .010/.030 ALL ANGLES ARE 90°		QUADREL LABELING SYSTEMS		SCALE: 1/1
		7670 JENTHER DRIVE		DATE: Aug-07-25
		MENTOR, OHIO 44060		DRW BY: TAZ
		(440) 602-4700		CHK BY:08/28/2025-SEM
				APPR BY:
				RAIL KIT WITH SCALES
MAT'L		22435-034		




THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE			
X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30°		7670 JENTER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030 ALL ANGLES ARE 90°		RAIL KIT WITH SCALES	
MAT'L		22435-034	





ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	B21924-101	TRANSFER PLATE	21180-101
2	1	B21925-007	TRANSFER SUPPORT PLATE	21180-101
3	1	B21926-003	TRANSFER CONNECTING PLATE	21180-101



A	Aug-10-21	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY


THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .01 XX ± .005 XXX ± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		QUADREL LABELING SYSTEMS		SCALE: 1/1
		7670 JENTHER DRIVE		DATE: Aug-10-21
		MENTOR, OHIO 44060		DRW BY: TAZ
		(440) 602-4700		CHK BY: 05/29/2024-SEM
				APPR BY:
		7" END TRANSFER		
	MAT'L			21180-101







THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/1	
X ± .1 XX ± .01 XXX ± .005 ANGLES ± .00°		DATE: Aug-10-21	
SURFACE FINISH: 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		DRW BY: TAZ	
		CHK BY: 05/29/2024-SEM	
		APPR BY:	
		7" END TRANSFER	
		21180-101	

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	221152-005	ENCLOSURE, E-STOP W/ BUTTON	20789-000
2	1	241780-000	STRAIN RELIEF, CABLE	20789-000
3	1	241780-001	STRAIN RELIEF, CABLE PANEL	20789-000
4	1	A25719-000	CYLINDER MOUNTING ANGLE	20789-000



A	8-29-16	NEW DRAWING	TJS
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30°		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
SURFACE FINISH 125 BREAK ALL EDGES .005/0.15 CORNER RADIUS .010/0.50		SCALE: 1/1 DATE: 8-29-16 DRW BY: TJS CHK BY: 03/08/2024-SEM APPR BY:	
MAT'L		EMERGENCY STOP ASSEMBLY	
		20789-000	



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/1	
XX ± .01		DATE: 8-29-16	
XXX ± .005		DRW BY: TJS	
ANGLES ± .00°		CHK BY: 03/08/2024-SEM	
SURFACE FINISH: 125		APPR BY:	
BREAK ALL EDGES .005/ .015		EMERGENCY STOP ASSEMBLY	
CORNER RADIUS .010/ .030		MAT'L	
ALL ANGLES ARE 90°		20789-000	

QUADREL LABELING SYSTEMS

7670 JENTHER DRIVE

MENTOR, OHIO 44060

(440) 602-4700

1/1

8-29-16

TJS

03/08/2024-SEM

ASSEMBLY TITLE: HEAD SUPPORT ASSEMBLY

GENERAL FUNCTION:

The head support assembly keeps the labeling head in a “locked position” and prevents head vibration and wobbling as the label motor is engaged. The head support assembly is also used to set the camber or front/back tilt of the head.

SETUP AND ADJUSTMENTS:


HORIZONTAL ADJUSTMENT: To set the horizontal position of the labeling head, use the side mount wheel handle (some older systems may feature the ratcheted handle). Turn the handle clockwise to move the head towards the conveyor. Turn it counter clockwise to move the head away from the conveyor.

VERTICAL ADJUSTMENT: Using the lower wheel handle to set the vertical position of the labeling head. Turn the wheel clockwise to lower labeling head. Turn the wheel counter clockwise to raise the labeling head.

MAINTENANCE:




No scheduled maintenance is required for this assembly. Always keep the drive areas free of label flash and debris.

TROUBLESHOOTING: None this section.



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	22173-601-008-000	VERTICAL IGUS SLIDE, 17.5"	22530-84224R
2	1	729006-000	CAP INSERT FOR 2 X 4 TUBE	22530-84224R
3	1	792065-000	CAP INSERT FOR 4X4 TUBE (1/4WALL)	22530-84224R
4	1	793045-000	DIAMOND KNURL KNOB	22530-84224R
5	1	22173H-601-02-000	VERTICAL IGUS SLIDE, 17.5"	22530-84224R
6	1	22620Y-RHH	Q120 YOKE ASSEMBLY	22530-84224R
7	1	A26179-120	KNOB STUD	22530-84224R
8	1	C21306-000	HEAD SUPPORT BACKING PLATE	22530-84224R
9	1	C21349-120	ADJUSTMENT BLOCK	22530-84224R
10	1	D23570-125	HORIZONTAL MOUNTING FRAME	22530-84224R
11	1	D24433-160	HEAD SUPPORT RISER	22530-84224R
12	4	HCS173		22530-84224R
13	4	HHN002		22530-84224R

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 3/8	
XXX ± .01 XXX ± .005 ANGLES ± .90°		DATE: Oct-20-25	
SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		DRW BY: TAZ	
MENTOR, OHIO 44060 (440) 602-4700		CHK BY:	
QUADREL LABELING SYSTEMS		APPR BY:	
OPEN LINE Q120 HEAD SUPPORT			
MAT'L			
22530-84224R		22530-84224R	



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE

$X \pm .1$
 $XX \pm .01$
 $XXX \pm .005$
 ANGLES $\pm 30'$

SURFACE FINISH 125
 BREAK & EDGES .005/0.15
 CORNER RADII .0107-.030
 ALL ANGLES ARE 90°



QUADREL LABELING SYSTEMS

7670 JENTHER DRIVE
 MENTOR, OHIO 44060
 (440) 602-4700

SCALE: 1/2"

DATE: Oct-20-21

DRAW BY: TA

CHK BY:


APPR BY:


OPEN LINE Q120 HEAD SUPPORT





MAT'L	22530-84224R	22530-84224R
-------	--------------	--------------

SHEET 2 OF 2

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	22173-601-011-75	VERTICAL IGUS SLIDE, 17.5"	22530-84224L
2	1	729006-000	CAP INSERT FOR 2 X 4 TUBE	22530-84224L
3	1	792065-000	CAP INSERT FOR 4X4 TUBE (1/4WALL)	22530-84224L
4	3	793045-000	DIAMOND KNURL KNOB	22530-84224L
5	1	22173H-601-02-00	VERTICAL IGUS SLIDE, 17.5"	22530-84224L
6	1	22620Y-RHH	Q120 YOKE ASSEMBLY	22530-84224L
7	3	A26179-120	KNOB STUD	22530-84224L
8	1	C21306-000	HEAD SUPPORT BACKING PLATE	22530-84224L
9	1	C21348-120	ADJUSTMENT PLATE	22530-84224L
10	1	C21349-120	ADJUSTMENT BLOCK	22530-84224L
11	1	D23570-125	HORIZONTAL MOUNTING FRAME	22530-84224L
12	1	D24433-160	HEAD SUPPORT RISER	22530-84224L
13	4	HCS173		22530-84224L
14	4	HHN002		22530-84224L




		A	Oct-20-25	NEW DRAWING	TAZ
		REV	DATE	DESCRIPTION	BY
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XXX ± .005 ANGLES ± 30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030 ALL ANGLES ARE 90°		QUADREL LABELING SYSTEMS			SCALE: 1/4
		7670 JENTHER DRIVE			DATE: Oct-20-25
		MENTOR, OHIO 44060			DRW BY: TAZ
		(440) 602-4700			CHK BY:
					APPR BY:
MAT'L		OPEN LINE Q120 HEAD SUPPORT			
		22530-84224L			22530-84224L







THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/4	
XX ± .1		DATE: Oct-20-25	
XX ± .01		DRW BY: TAZ	
XX ± .005		CHK BY:	
ANGLES ± .00°		APPR BY:	
SURFACE FINISH .125		OPEN LINE Q120 HEAD SUPPORT	
BREAK ALL EDGES .005/.015		MAT'L	
CORNER RADIUS .010/.030		22530-84224L	
ALL ANGLES ARE 90°		22530-84224L	


ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	141172-000	SLEEVE BEARING, 1/20D. x 3/8ID. x 3/4LNG	22173-601
2	1	141177-000	SLEEVE BEARING, 5/80D. x 1/2ID. x 3/4LNG	22173-601
3	1	181079-000	BEARING, NEEDLE ROLLER	22173-601
4	2	181080-000	BEARING, THRUST WASHER	22173-601
5	2	181108-000	BEARING, NEEDLE ROLLER	22173-601
6	4	181111-000	THRUST WASHER	22173-601
7	1	361169-000	COLLAR, 1/2 IN. ID ONE-PIECE CLAMP	22173-601
8	1	362186-000	COLLAR, 3/8 IN. ID ONE-PIECE CLAMP	22173-601
9	1	791914-001_10	MYLAR SCALE, QUADREL LOGO	22173-601
10	4	792248-001	PILLOW BLOCK	22173-601
11	1	792354-000	DIGITAL POSITION INDICATOR	22173-601
12	1	792355-000	DRYLIN RAIL	22173-601
13	1	801080-000	6" HANDWHEEL	22173-601
14	1	A24077-000	BRONZE NUT, RH	22173-601
15	1	B20045-111	THREADED ROD	22173-601
16	1	B21346-000	BOTTOM BEARING PLATE	22173-601
17	1	B22005-012	BEARING PLATE	22173-601
18	1	C20626-000	STAND SLED	22173-601
19	1	HCS281		22173-601
20	1	SON022		22173-601



A	3-25-20	NEW DRAWING	ATT
REV	DATE	DESCRIPTION	BY
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .01 XX ± .01 XXX ± .005 ANGLES ± .30°		QUADREL LABELING SYSTEMS 7670 JENTER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		SCALE: 1/2 DATE: 3-25-20 DRW BY: ATT CHK BY: 03/02/24-SEM APPR BY:	
VERTICAL IGUS SLIDE, 17.5"			
MAT'L		22173-601	







THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
<div>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE</div> <div>XX ± .1 XXX ± .005 ANGLES ± .30°</div> <div>SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030 ALL ANGLES ARE 90°</div>		<div>QUADREL LABELING SYSTEMS</div> <div>7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700</div>	
		<div>SCALE: 1/2 DATE: 3-25-20 DRW BY: ATT CHK BY: 03/02/24-SEM APPR BY:</div>	
<div>MAT'L</div>		<div>VERTICAL IGUS SLIDE, 17.5"</div> <div>22173-000</div> <div>22173-601</div>	



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	141172-000	SLEEVE BEARING, 1/20D. x 3/8ID. x 3/4LNG	22173H-601
2	1	141177-000	SLEEVE BEARING, 5/80D. x 1/2ID. x 3/4LNG	22173H-601
3	2	181079-000	BEARING, NEEDLE ROLLER	22173H-601
4	4	181080-000	BEARING, THRUST WASHER	22173H-601
5	2	181108-000	BEARING, NEEDLE ROLLER	22173H-601
6	4	181111-000	THRUST WASHER	22173H-601
7	1	361169-000	COLLAR, 1/2 IN. ID ONE-PIECE CLAMP	22173H-601
8	1	362186-000	COLLAR, 3/8 IN. ID ONE-PIECE CLAMP	22173H-601
9	4	792248-001	PILLOW BLOCK	22173H-601
10	1	792354-000	DIGITAL POSITION INDICATOR	22173H-601
11	1	792355-000	DRYLIN RAIL	22173H-601
12	1	801080-000	HANDLE WHEEL, MODIFIED	22173H-601
13	1	A24077-000	BRONZE NUT, RH	22173H-601
14	1	B20045-111	THREADED ROD	22173H-601
15	1	B21346-000	BOTTOM BEARING PLATE	22173H-601
16	1	B22005-012	BEARING PLATE	22173H-601
17	1	C20626-000	STAND SLED	22173H-601
18	1	HCS281		22173H-601
19	1	SON022		22173H-601


A	2-24-20	NEW DRAWING	TJS
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .01 XX ± .005 XXX ± .005 ANGLES ± .30°		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		SCALE: 1/2 DATE: 2-24-20 DRW BY: TJS CHK BY: 03/02/24-SEM APPR BY:	
VERTICAL IGUS SLIDE, 17.5"		MATERIAL	
SHEET 1 OF 2		22173H-601	




THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/2	
XXX ± .01		DATE: 2-24-20	
XXX ± .005		DRW BY: TJS	
ANGLES ± 90°		CHK BY: 03/02/24-SEM	
SURFACE FINISH 125		APPR BY:	
BREAK ALL EDGES .005/ .015		VERTICAL IGUS SLIDE, 17.5"	
CORNER RADIUS .010/ .030		MAT'L	
ALL ANGLES ARE 90°		22173H-601	

A	2-24-20	NEW DRAWING	TJS
REV	DATE	DESCRIPTION	BY




**QUADREL LABELING SYSTEMS**
7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	801850-000	CLAMPING LEVER	22620Y-RHH
2	2	B21190-114	YOKE SIDE PLATE	22620Y-RHH
3	1	B21555-000	MTG YOKE BACK PLATE	22620Y-RHH



A	11-26-13	NEW DRAWING	ATT
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
<div>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030</div>	<div>QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700</div>	SCALE: 1/1 DATE: 11-26-13 DRW BY: ATT CHK BY: 03/07/2024-SEM APPR BY:	
		Q120 YOKE ASSEMBLY	
		MAT'L	
		22620Y-RHH	



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/2	
X ± .1		DATE: 11-26-13	
XX ± .01		DRW BY: ATT	
XXX ± .005		CHK BY: 03/07/2024-SEM	
ANGLES ± .00°		APPR BY:	
SURFACE FINISH: 125		Q120 YOKE ASSEMBLY	
BREAK ALL EDGES .005/ .015		MATERIAL	
CORNER RADIUS .010/ .030		22620Y-RHH	
ALL ANGLES ARE 90°			

7.4 PACING WHEEL / BELT ASSEMBLY

7.4.1 GENERAL INFORMATION

The pacing wheel/belt are an optional module that is generally placed at the entrance of the conveyor to allow adequate spacing of products as they travel towards the labeling head. The speed of the wheel/belt will vary how much spacing is created between the products. It is controlled by a DC motor and DC drive located in the electrical enclosure.

7.4.2 ADJUSTMENTS

The adjustments for both assemblies are fairly straight forward. The pacing wheel assembly has a pivoting in and out adjustment and height adjustment. The pivot in and out adjustment is made by loosening the ratcheting handle on the mount and rotating the assembly as needed.





The vertical adjustment for the pacing wheel is achieved by loosening the collar on the shaft then loosening the ratchet handle and manually pull up or push down as needed. The height is locked in place with the lock collar. Tighten the ratchet handle when finished.



CAUTION

Do not make any adjustments when assembly or conveyor are running.

The pacing belt assembly has both vertical and horizontal adjustments. To adjust vertically loosen the 2 3/8-16 bolts and pull up on the assembly. To adjust horizontally (in and out) loosen the 2 ratchet handles under the assembly and slide in and out as needed.



ASSEMBLY TITLE: PACING WRAP ASSEMBLY

DRAWING NO: D21938-000

GENERAL FUNCTION:

The product pacing wrap is offsets each product a variable distance from the preceding product and guarantees adequate product separation.

SETUP AND ADJUSTMENTS:

- Adjust the brackets so that the pacing **belt** slightly presses the product against the back rail. Lock into place using the adjustment knobs.
- The speed of the pacing **belt** is controlled by a potentiometer located in the remote enclosure mounted on the conveyor riser.

MAINTENANCE:

No scheduled maintenance is required for this assembly. Always keep the drive areas free of label flash and debris.

CAUTION:

Before performing any maintenance or cleaning make sure the system is powered down.


TROUBLESHOOTING:

PROBLEM:

WHAT TO DO:

- | | |
|--------------------------------|---|
| - Product spaced to close | - Reduce the speed of the pacing wheel. |
| - Product spaced too far apart | - Increase the speed of the pacing wheel. |









ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	111064-000	BEARING, BANDED THRUST BALL	21978-202
2	2	111075-000	BEARING, BALL	21978-202
3	2	151011-000	BEARING, THRUST WASHER	21978-202
4	2	151017-000	BEARING, THRUST WASHER	21978-202
5	1	193384-005	BELT, WRAP RUFTEX W/V-GUIDE	21978-202
6	1	411305-000	MOTOR, DC	21978-202
7	1	A21277-004	LOWER WRAP PLATE	21978-202
8	1	A21743-009	IDLER SHAFT	21978-202
9	1	A23731-000	MOTOR MTG. PLATE (MODULINE)	21978-202
10	2	A25302-225	SPACER	21978-202
11	1	B20776-001	DRIVE SHAFT	21978-202
12	1	B21200-008	UPPER WRAP PLATE	21978-202
13	1	B21968-001	DRIVE ROLL W/GROOVE	21978-202
14	1	B21969-002	IDLER ROLL W/GROOVE	21978-202
15	1	D21857-001	BACK-UP PLATE W/ V-GROOVE SLOT	21978-202

A	Jun-12-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30°		QUADREL LABELING SYSTEMS 7670 JENTER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030		SCALE: 7/16 DATE: Jun-12-25 DRW BY: TAZ CHK BY: 06/13/2025-SEM APPR BY:	
2 X 12 PACING BELT		MATERIAL	
		21978-202	



A	Jun-12-25	NEW DRAWING	TAD
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY	REV	DATE	DESCRIPTION	BY
--	-----	------	-------------	----

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE

$\begin{matrix} X \\ Y \end{matrix} \pm .01$

QUADREL LABELING SYSTEMS
7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

SCALE: 1" = 1/2"
DATE: Jun-12-20
DRW BY: JTA
CHK BY: 06/13/2025
APPR BY:

.XXX ± .005 ANGLES ± 30°	2 X 12 PACING BELT
-----------------------------	--------------------


SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030 ALL ANGLES ARE 90°	MAT'L	21978-202
--	-------	-----------

21978-202

7.5 WRAP STATION ASSEMBLY

7.5.1 GENERAL INFORMATION

The wrap station is generally positioned near the labeler and is made up of a belt/roller assembly activated by a DC motor (with encoder), and AC motor, or servo motor coupled to a gear box and adjusting plate. The wrap station paired with a foam back plate assembly is used for cylindrical products to ensure impression 360 degrees around the container. There are two wrap styles depending on your specific application. A triangle wrap station (pictured on the left) is used primarily in “flag and wrap” applications where the wrap station is positioned after the top hold down. Our direct wrap or rectangle wrap station (pictured on the right) is positioned directly after the peel plate. This wrap station comes with a dc motor with an encoder to ensure absolute synchrony with the labeling head.




7.5.2 ADJUSTMENTS

Depending on the height of your product and placement of your label you may need to adjust the height of the wrap station. Adjusting the height on your wrap station is very simple. On a triangle wrap station rotate the handwheel counter clockwise or clockwise to raise and lower the wrap station.



On a rectangle wrap station locate the handle on the mount for the wrap station. loosen the ratchet handle, then simply turn the knob on top of the wrap station clockwise and counter clockwise to raise and lower the wrap station. This is the only adjustment for the rectangle wrap station on this mount.



The triangle wrap station has the ability to travel in and out. This adjustment is used in applications with skinnier products, or a situation where you need to move the wrap out of the way. To achieve this adjustment loosen both ratchet handles and the wrap station. Tighten when in place.



CAUTION

Do not make this adjustment when the wrap station is running.



In more difficult applications such as tapered containers you may need to adjust the tilt of the wrap station to match the products taper (If the taper is too great other methods are used). To adjust the tilt or to square the wrap station to the conveyor or container locate the 4 set screws on the wrap mount loosen the jam nuts and tighten or loosen the set screws to tilt the wrap station as desired.



ASSEMBLY TITLE:**WRAP ASSEMBLY****GENERAL FUNCTION:**

- The wrap station is used in conjunction with a single labeling head to apply a label around a cylindrical product. The wrap station length will vary with respect to the maximum length of label being applied.

SET UP AND ADJUSTMENTS:

- The wrap station is attached to mounting blocks which clamp to mounting rails affixed to the conveyor side plate. The wrap station can be moved by loosening the locking levers holding the wrap station in place. Position as needed and retighten locking levers.
- Set the speed of the wrap station with the manual speed control. The final wrap speed should be set from 1.5 to 2 times the rate of the conveyor. All line compensation systems will automatically adjust the labeling head speed with respect to the speed of the wrap station.

MAINTENANCE:

- Keep the wrap belt free of label adhesive and debris. This will prevent jamming and web tears.
- Periodically check belt tension. Use the setscrew adjustment at each end to control belt tension.

CAUTION:


- **Before performing any maintenance or cleaning make sure the system is powered down.**

TROUBLESHOOTING:**PROBLEM**

- Belt not fully engaged
- Wrap station not feeding the label correctly
- Speed set incorrectly
- Belt Jam
- Tension too stiff





WHAT TO DO


- Increase tension on belt by adjusting tensioner set screws.
- Adjust wrap station inward.
- Reset speed as necessary.
- Speed set incorrectly, reset speed as necessary.
- Relieve tension.



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	111064-000	BEARING, BANDED THRUST BALL	84224W-000
2	2	111075-000	BEARING, BALL	84224W-000
3	2	151011-000	BEARING, THRUST WASHER	84224W-000
4	2	151017-000	BEARING, THRUST WASHER	84224W-000
5	1	193371-000	BELT, WRAP W/V-GUIDE	84224W-000
6	1	412173-000	GEARMOTOR; 3/8 HP 170RPM 3PH AC	84224W-000
7	1	A21277-000	LOWER PLATE (MODULINE WRAP)	84224W-000
8	1	A21743-000	IDLER SHAFT	84224W-000
9	1	A23731-000	MOTOR MTG. PLATE (MODULINE)	84224W-000
10	1	B20776-000	DRIVE SHAFT	84224W-000
11	1	B21200-011	UPPER PLATE (MODULINE WRAP)	84224W-000
12	1	B21968-000	DRIVE ROLL W/GROOVE	84224W-000
13	1	B21969-000	IDLER ROLL W/GROOVE	84224W-000
14	1	D21857-000	BACK-UP PLATE W/ V-GROOVE SLOT	84224W-000

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 15/32	
X ± .1 XX ± .01 XXX ± .005 ANGLES ± .00°		DATE: Oct-20-25	
SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		DRW BY: TAZ	
MENTOR, OHIO 44060 (440) 602-4700		CHK BY:	
4" X 12" WRAP, AC MOTOR, SHEPPARD BELT		APPR BY:	
MAT'L		AS NOTED	
84224W-000			



A	Oct-20-25	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
 UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE XXX ± .01 XXX ± .005 ANGLES ± .00° SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		SCALE: 1/2 DATE: Oct-20-25 DRW BY: TAZ CHK BY: APPR BY:	
		QUADREL LABELING SYSTEMS 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700	
		4" X 12" WRAP, AC MOTOR, SHEPPARD BELT	
		MAT'L 84224W-000	84224W-000

ASSEMBLY TITLE: WRAP MOUNTING ASSEMBLY

DRAWING: D22598-000

GENERAL FUNCTION:

The wrap station mounting is used in conjunction with a wrap assembly. The wrap station length will vary with respect to the maximum length of label being applied.

SET UP AND ADJUSTMENTS:

The wrap station is attached to mounting plate which clamp to mounting rails affixed to the conveyor side plate. The wrap station can be moved by loosening the locking levers holding the wrap station in place. Position as needed and retighten locking levers.

MAINTENANCE:

Keep the wrap belt free of label adhesive and debris. This will prevent jamming and web tears.

CAUTION:

Before performing any maintenance or cleaning make sure the system is powered down.


TROUBLESHOOTING:

PROBLEM

WHAT TO DO





Wrap station not feeding the label correctly

Adjust wrap station inward.



ITEM	QTY	PART NO.	DESCRIPTION
1	2	131113-000	FLANGED BEARING
2	2	131114-000	FLANGED BEARING
3	4	141193-000	SLEEVE BEARING
4	1	361183-000	COLLAR, 3/4 ID ONE PIECE- S.S.
5	1	791790-000	EXTERNAL RETAINING RING
6	1	801301-000	KNURLED HEAD SWIVEL
7	2	A20876-000	RETAINER BLOCK
8	2	A21367-000	RETAINER BLOCK
9	1	A21553-000	BEARING PLATE
10	1	A21891-001	BEARING MOUNTING BLOCK
11	2	A25367-000	PIVOT BLOCK
12	1	A25368-000	ADJUSTMENT ROD MOUNTING PLATE
13	1	A25373-000	GUIDE ROD WITH FLAT
14	1	A25374-000	GUIDE ROD
15	1	B22212-000	CONVEYOR MOUNTING PLATE
16	1	B22213-000	PIVOT SHAFT MOUNTING BLOCK
17	1	B22214-000	PIVOT PIN
18	1	B22218-000	VERTICAL ADJ. SCREW
19	1	B22387-000	PIVOT PLATE
20	1	C21157-000	THREADED ROD

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY		NEW DRAWING	
REV	DATE	DESCRIPTION	
A	11-10-08	NEW DRAWING	
SCALE:	7/16	DATE:	
UNLESS OTHERWISE SPECIFIED		DRW BY:	
DIMENSIONAL TOLERANCE		CHK BY:	
XX ± .01		APPR BY:	
XXX ± .005			
ANGLES ± 30°			
SURFACE FINISH 125			
BREAK ALL EDGES .005/.015			
CORNER RADIUS .010/.030			
QUADREL LABELING SYSTEMS		7670 JENTHER DRIVE	
		MENTOR, OHIO 44060	
		(440) 602-4700	
		WRAP TILT MOUNT	
		MAT'L	
		22267-000	
		D22598-000	



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 5/8	
XX ± .01		DATE: 11-10-08	
XXX ± .005		DRW BY: ATT	
ANGLES ± 30°		CHK BY:	
SURFACE FINISH 125		APPR BY:	
BREAK ALL EDGES .005/.015			
CORNER RADIUS .010/.030			
QUADREL LABELING SYSTEMS		WRAP TILT MOUNT	
7670 JENTHER DRIVE		MAT'L	
MENTOR, OHIO 44060		22267-000	
(440) 602-4700		D22598-000	

7.6 BACK UP PLATE ASSEMBLY

7.6.1 GENERAL INFORMATION

The back up plate assembly paired with the wrap station applies pressure to cylindrical containers to apply labels.

7.6.2 ADJUSTMENTS



The back up plate assembly has a variety of adjustments. To adjust vertically loosen the 2 ratchet handles in the main mounting blocks and pull up or push down. To make adjustments left or right loosen the 8 socket head bolts and slide the assembly along the black rail towards the infeed or outfeed of the conveyor.

Moving the back up plate assembly in and out is achieved by loosening the 2 ratchet handles on the top of the assembly and turning the knob clockwise or counter clockwise. To tilt the back up plate assembly to accommodate a tapered container loosen the 2 5/16-18 bolts at the end of the shafts tilt the plate as needed and retighten the bolts.



ASSEMBLY TITLE: BACK-UP PLATE ASSEMBLY

GENERAL FUNCTION:

The back up plate assembly is mounted opposite the wrap station. The assembly provides the pressure to rotate the product plus impression of the label to the product. The back up plate must cover the entire label width and length to ensure complete impression. Certain products may require the use of different size plates to impress into recessed areas of the product.

SET-UP AND ADJUSTMENTS:


The only adjustment necessary is to ensure the horizontal pressure is sufficient to rotate the product completely and provide complete impression of the label. Place three products in wrap station area, one in the center of the wrap station, the other two at the in-feed and out-feed ends. Loosen knobs and slide backup plate close to the wrap station in order to apply light pressure to products. Retighten knobs when correct pressure is achieved.

MAINTENANCE:

- Clean all the parts that may acquire labels or glue residue.
- Exercise caution when removing bad labels from foam. Careless removal can result in torn foam which may leave the labeler inoperable until the roller is replaced.

TROUBLESHOOTING:


- none this section







ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	141166-000	BEARING, SLEEVE	21485-002-S
2	1	141177-000	SLEEVE BEARING, 5/8OD. x 1/2ID. x 3/4LNG	21485-002-S
3	2	181079-000	BEARING, NEEDLE ROLLER	21485-002-S
4	4	181080-000	BEARING, THRUST WASHER	21485-002-S
5	2	362161-000	COLLAR, SETSCREW, 1/2 IN. ID	21485-002-S
6	1	792354-000	DIGITAL POSITION INDICATOR	21485-002-S
7	1	801320-000	HAND KNOB	21485-002-S
8	4	801805-000	CLAMPING LEVER	21485-002-S
9	2	A20688-000	LOCKING CLAMP	21485-002-S
10	2	A20689-000	LOCKING CLAMP	21485-002-S
11	2	A20844-000	GUIDE RAIL CLAMP BAR	21485-002-S
12	2	A20845-000	GUIDE RAIL CLAMP BAR	21485-002-S
13	2	A21691-000	MOUNTING BLOCK	21485-002-S
14	1	A23474-000	TRAVEL PLATE	21485-002-S
15	1	A23475-000	HORIZONTAL ADJUST ROD	21485-002-S
16	1	A23476-000	HORIZONTAL ADJUST ROD W/ FLAT	21485-002-S
17	1	A23477-003	ADJUSTMENT PLATE	21485-002-S
18	1	A23478-003	VERTICAL ADJUSTMENT ROD	21485-002-S
19	1	A23479-003	VERTICAL ADJUSTMENT ROD W/ FLAT	21485-002-S
20	2	A23483-000	MOUNTING PLATE	21485-002-S
21	1	A23490-004	THREADED ROD	21485-002-S
22	1	A23853-010	BACK-UP MOUNTING ANGLE	21485-002-S
23	1	A23853-011	BACK-UP MOUNTING ANGLE	21485-002-S
24	1	B22005-012	BEARING PLATE	21485-002-S
25	4	SYE612		21485-002-S

NOT SHOWN:

C20537-120 BACKUP PLATE ASSY, 1.50" X 14
C20537-046 BACKUP PLATE ASSY, 3" X 14

A		May-06-20		NEW DRAWING	
REV		DATE		DESCRIPTION	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY					
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .01 XX ± .01 XXX ± .005 ANGLES ± .30°		 7670 JENTER DRIVE MENTOR, OHIO 44060 (440) 602-4700		SCALE: 1/2	
				DATE: May-06-20	
				DRW BY: TJS	
				CHK BY: 03/09/2024-SEM	
				APPR BY:	
ADJUSTABLE BACK-UP PLATE ASSEMBLY W/SIKO					
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADII .010/.030		MAT'L		21485-002	
				21485-002-S	




THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY

UNLESS OTHERWISE SPECIFIED
DIMENSIONAL TOLERANCE

$x \pm .1$
 $xx \pm .01$
 $xxx \pm .005$
ANGLES $\pm .50^\circ$

SURFACE FINISH 125
BREAK ALL EDGES .005/ .015
CORNER RADIUS .010/ .030
ALL ANGLES ARE 90°

QUADREL LABELING SYSTEMS
7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700



SCALE: 1/2
DATE: May-06-20
DRW BY: 8CREO.CHK
CHK BY: TJS
APPR BY:

ADJUSTABLE BACK-UP PLATE ASSEMBLY W/SIKO

A	May-06-20	NEW DRAWING	TJS
REV	DATE	DESCRIPTION	BY

MAT'L 21485-002 21485-002-S

7.7 TOP HOLD DOWN ASSEMBLY

7.7.1 GENERAL INFORMATION

The top hold down module is a motor driven spring loaded belt that applies overhead pressure to the containers and enables the product to remain stable as the label is applied. This assembly is powered by an AC motor or servo motor. Ideal for front / back or single side applications.

7.7.2 ADJUSTMENTS

Adjusting the height of the top hold down is achieved by turning the hand wheel on the top of the assembly counter clockwise or clockwise.



ASSEMBLY TITLE:

TOP TRAP ASSEMBLY

GENERAL FUNCTION:

- As a product enters the label application area near the labeling head, it needs additional support to prevent it from being upset as a label is applied. A product hold down conveyor or more commonly known as a "top trap" is used to provide product support.

The speed of the top trap is set to match the speed of the conveyor and is encoder matched to follow conveyor speed changes.

SETUP AND ADJUSTMENTS:

- Place the product to be labeled under the top trap. Loosen clamp lever and turn the **hand wheel** so that the rubber belt of the top trap compresses the product slightly.
- When the desired height is achieved, tighten the clamp lever.
- **The top trap is spring loaded to accommodate products that vary in height slightly.**
- Top trap belt tension can be adjusted by tightening or loosening the set screws at the infeed end of the top trap.

MAINTENANCE:

- No maintenance is required except for an occasional belt replacement.

TROUBLESHOOTING:

PROBLEM


- Top trap jumping teeth
- Too much pressure on product
- Top trap not moving
- Top trap swaying under load.


WHAT TO DO





- Tighten top trap belt
- Raise top trap
- Check drive belts and replace if broken.
- Tighten clamp lever. Tighten pulleys and shafts.





ITEM	QTY	PART NO.	DESCRIPTION	
1	1	22867-01	TOP TRAP UPRIGHT ASSEMBLY, 7.5" W CONVEYORS	22878-00L
2	1	22868-01L	TOP TRAP BODY ASSEMBLY, 28 RPM MOTOR	22878-00L



A		03-OCT-2024		NEW DRAWING		CRT	
REV		DATE		DESCRIPTION		BY	
THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY							
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE XX ± .1 XXX ± .01 XXXX ± .005 ANGLES ± .30° SURFACE FINISH 125 BREAK ALL EDGES .005/ .015 CORNER RADIUS .010/ .030 ALL ANGLES ARE 90°		 7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700				SCALE: 3/8	
						DATE: 03-OCT-2024	
						DRW BY: CRT	
						CHK BY:	
						APPR BY:	
		TOP TRAP, 7-1/2"W-CONV. W/SIKO					
MAT'L		22878-00L					







THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
<div>UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE</div> <div>X ± .1 XX ± .01 XXX ± .005 ANGLES ± .00°</div> <div>SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030 ALL ANGLES ARE 90°</div>			
		<div>QUADREL LABELING SYSTEMS</div> <div>7670 JENTER DRIVE MENTOR, OHIO 44060 (440) 602-4700</div>	
MAT'L		TOP TRAP, 7-1/2"W-CONV. W/SIKO	
		22878-00L	



ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	1	141172-000	SLEEVE BEARING, 1/2OD. x 3/8ID. x 3/4LNG	22867-01
2	1	141177-000	SLEEVE BEARING, 5/8OD. x 1/2ID. x 3/4LNG	22867-01
3	2	181108-000	BEARING, NEEDLE ROLLER	22867-01
4	4	181111-000	THRUST WASHER	22867-01
5	1	362186-000	COLLAR, 3/8 IN. ID ONE-PIECE CLAMP	22867-01
6	2	729006-000	CAP INSERT FOR 2 X 4 TUBE	22867-01
7	4	792248-001	PILLOW BLOCK	22867-01
8	1	792354-002	DIGITAL POSITION INDICATOR	22867-01
9	1	793035-001	DRYLIN RAIL	22867-01
10	1	801080-000	HANDLE WHEEL, MODIFIED	22867-01
11	1	A24077-000	BRONZE NUT, RH	22867-01
12	1	B20045-200	THREADED ROD	22867-01
13	1	B21346-000	BOTTOM BEARING PLATE	22867-01
14	1	B22005-012	BEARING PLATE	22867-01
15	1	B22790-002	TOP TRAP CONNECTOR PLATE	22867-01
16	1	B22791-010	TOP TRAP SPACER	22867-01
17	1	B22791-011	TOP TRAP SPACER	22867-01
18	1	B22791-019_	TOP TRAP SPACER	22867-01
19	1	C21292-001	TOP TRAP RISER	22867-01
20	1	C21293-001	TOP TRAP MOUNTING PLATE	22867-01
21	2	C21293-700	TOP TRAP MOUNTING PLATE	22867-01


A	08/26/24	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .01 XXX ± .005 ANGLES ± .30°		SCALE: 0.313 DATE: 8/26/24 DRW BY: TAZ CHK BY: 08/26/2024-SEM APPR BY:	
SURFACE FINISH 125 BREAK ALL EDGES .005/0.15 CORNER RADIUS .010/0.50		TOP TRAP UPRIGHT ASSEMBLY, 7.5" W CONVEYORS	
MAT'L		22867-01	




THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED		SCALE: 0.250	
DIMENSIONAL TOLERANCE		DATE: 8/26/24	
XX ± .01		DRW BY: TAZ	
XXX ± .005		CHK BY: 08/26/2024-SEM	
ANGLES ± .30°		APPR BY:	
SURFACE FINISH 125		TOP TRAP UPRIGHT ASSEMBLY, 7.5" W CONVEYORS	
BREAK ALL EDGES .005/0.15		MAT'L	
CORNER RADIUS .010/0.50		22867-01	





A	8/26/24	NEW DRAWING	TAZ
REV	DATE	DESCRIPTION	BY

**QUADREL LABELING SYSTEMS**
7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

ITEM	QTY	PART NO.	DESCRIPTION	PARENT ITEM
1	2	111075-000	BEARING, BALL	22868-01L
2	2	151008-000	BEARING, THRUST WASHER	22868-01L
3	1	411391-000	MOTOR, 1/4HP 28 RPM 220VAC	22868-01L
4	22	791975-001	R-CLIP	22868-01L
5	1	793013-000	QUADREL Logo (3"x11")	22868-01L
6	22	811256-000	COMPRESSION SPRING	22868-01L
7	1	A21578-040	TOP TRAP COVER PLATE	22868-01L
8	1	A21578-041	TOP TRAP COVER PLATE	22868-01L
9	1	A21823-000	IDLER SHAFT	22868-01L
10	1	A21830-601	TIMING BELT,RED LINOTEX	22868-01L
11	1	A25122-600	DRIVE PULLEY	22868-01L
12	1	A25122-602	IDLER PULLEY	22868-01L
13	6	A26053-000	TOP TRAP SPACER	22868-01L
14	2	A26197-000	PULLEY FLANGE	22868-01L
15	1	B21769-000	TOP TRAP SPACER	22868-01L
16	22	B22784-000	SPRING BLOCK STEM	22868-01L
17	22	B22785-000	SPRING BLOCK PLATE	22868-01L
18	1	C21268-840	INSIDE TOP TRAP PLATE	22868-01L
19	1	C21268-841	INSIDE TOP TRAP PLATE	22868-01L
20	1	D24415-000	SPRING BLOCK MOUNTING CHANNEL	22868-01L
21	1	D24415-001	SPRING BLOCK MOUNTING CHANNEL	22868-01L




THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY		QUADREL LABELING SYSTEMS		SCALE: 5/16
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE XX ± .01 XXX ± .005 ANGLES ± .50°		7670 JENTHER DRIVE MENTOR, OHIO 44060 (440) 602-4700		DATE: 09/10/24
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030 ALL ANGLES ARE 90°		TOP TRAP BODY ASSEMBLY, 28 RPM MOTOR		DRW BY: SEM
SHEET 1 OF 2		MAT'L		CHK BY: &CREO.CHK
				APPR BY:
				22868-01L



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 3/8	
XX ± .01		DATE: 09/10/24	
XXX ± .005		DRW BY: SEM	
ANGLES ± .00°		CHK BY: 09/10/2024-SEM	
SURFACE FINISH: 125		APPR BY:	
BREAK: ALL EDGES .005/ .015		TOP TRAP BODY ASSEMBLY, 28 RPM MOTOR	
CORNER RADIUS .010/ .030		MAT'L	
ALL ANGLES ARE 90°		22868-01L	

A	09/10/24	NEW DRAWING	SEM
REV	DATE	DESCRIPTION	BYE

**QUADREL LABELING SYSTEMS**
7670 JENTHER DRIVE
MENTOR, OHIO 44060
(440) 602-4700

ASSEMBLY TITLE:**PRODUCT DETECT ASSEMBLY****GENERAL FUNCTION:**

The product detect signal is used to trigger the labeling cycle. Optimum placement and setup of the product detect sensor is critical to accurate and repeatable label placement.

SETUP AND ADJUSTMENTS:

Set the position of the product detect sensor at a point up-stream of the peel plate area. Set the vertical position of the sensor at a point on the product that provides a stable and repeatable sense area. Loosen the vertical adjustment knobs to move the assembly along the vertical axis.

Follow the manufactures data sheet for a particular set and calibration.

MAINTENANCE:

No scheduled maintenance is required for this assembly. Always keep the drive areas free of label flash and debris.


CAUTION: Before performing any maintenance or cleaning make sure the system is powered down.


TROUBLESHOOTING:**PROBLEM:**

- No label trigger or intermittent trigger.

WHAT TO DO:

- Product does not intersect sensor scan field. Adjust sensor position until sensor detects product.
- Sensor gain set is too low. Increase gain until sensor indicator displays ON status(with product in sensor field).



THIS IS A PRO-ENGINEER DOCUMENT AND MAY NOT BE MODIFIED MANUALLY			
UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE		SCALE: 1/1	
X ± .1 XX ± .01 XXX ± .005 ANGLES ± .30°		DATE: 07/18/2024	
SURFACE FINISH 125 BREAK ALL EDGES .005/.015 CORNER RADIUS .010/.030 ALL ANGLES ARE 90°		DRW BY: SEM	
		CHK BY: 07/18/2024-SEM	
		APPR BY:	
		QUADREL LABELING SYSTEMS	
		7670 JENTHER DRIVE	
		MENTOR, OHIO 44060	
		(440) 602-4700	
		CLEAR PRODUCT DETECT, PNP	
MAT'L		21560-002	21560-012

PZ-G Series

Instruction Manual

Read this manual thoroughly before using the product.
Keep this manual readily available for future reference.

Safety precautions

- Avoid running the PZ-G cable along with power and high voltage lines, as this may cause interference and/or permanent damage.
- When using a commercially available switching regulator, ground its chassis grounding and earth grounding terminals.
- Do not use in locations where direct ambient light or external light directly shines on the light receiving surface.
- With retro-reflective type sensors, when detecting highly reflective materials (such as mirrored surfaces), stabilization may be difficult. To correct this, change the angle of the sensor head, or adjust the sensitivity.
- Avoid using power which exceeds the specifications for ripple (10% max)
- Avoid using excess force when rotating the operation mode selector switch (Light-on, Dark-on) and the sensitivity adjustment trimmer.
- This product is just intended to detect the object(s). Do not use this product for the purpose to protect a human body or a part of human body.
- This product is not intended for use as explosion-proof product. Do not use this product in a hazardous location and/or potentially explosive atmosphere.

Precautions on Regulations and Standards

UL Certificate

This product is an UL/C-UL Listed product.


- UL File No. E301717
- Category NRKH,NRKH7
- Enclosure Type 1 (Based on UL50)

Be sure to consider the following specifications when using this product as an UL/C-UL Listed Product.


- Use the power supply with Class 2 output defined in NFPA70 (NEC: National Electrical Code).
- Power supply/ Control input/ Control output circuits shall be connected to a single Class 2 source only.
- Use with the over current protection device which is rated 30V or more and not more than 1A.

Part Names


PZ-G5xN/G5xP




PZ-G5xB



PZ-G4xN/G4xP/G10xN/G10xP/G6xN/G6xP



PZ-G4xB/G10xB/G6xB




* The model name with "C" (PZ-GxxCx) is the connector type, and the model name with "E" (PZ-GxxEx) is the pigtail quick disconnect type.


Mounting Method

Side Mounting (Prepare M3 screws)

Tightening torque: 0.5 N·m or less




Tightening torque: 0.5 N·m or less



Mounting with the M18 nut (includes nut type)


The M18 nut is also available separately as OP-84225 (2 pcs. supplied).
Tightening torque: 1.0 N·m or less

Panel (5 mm or less)



Panel cut size

$\phi 18.5 \pm 0.2$ mm



Note


- Mount the M18 nut (supplied) straight in. If mounted at an angle it cannot be tightened properly.
- When tightening the M18 nut (supplied), firmly hold the main body down. The case of the main body may be damaged if held in place with a tool such as pliers.
- When tightening the M18 nut (supplied), if excess force is applied to the nut with a tool such as pliers, it may bend it out of shape. Therefore, do not apply excess force.

Sensitivity Adjustment Method

Caution



Avoid using excess force when rotating the sensitivity adjustment trimmer and operation mode selector switch as it may cause damage.



Operation mode selector switch

With the operation mode selector switch, you can select either the LIGHT-ON mode (L) or the DARK-ON (D) mode.



LIGHT-ON setting



DARK-ON setting

Reflective type (PZ-G41/G42/G101/G102/G10R/G10G/G10B Series)

The following assumes LIGHT-ON (L) is set.

Sequence	Adjustment method	Sensitivity adjustment trimmer
①	Position target in place. Slowly rotate the sensitivity trimmer from the MIN position towards the MAX position until the (orange) output indicator turns on (Position "A"). If the output indicator does not turn off, even at MIN, then MIN is considered Position "A".	
②	Remove the target. Adjust the sensitivity trimmer from MIN towards MAX until the (orange) output indicator turns on (Position "B"). If the output indicator does not light up, the MAX position is considered Position "B".	
③	Adjust the sensitivity trimmer to the midpoint between "A" and "B". Verify that the (green) stable operation light turns on with and without a target in place.	

Reference To use the sensor in DARK-ON mode, adjust the mode selector switch to "D".

Thrubeam type (PZ-G51/G52 Series) / Retro-reflective type (PZ-G61/G62 Series)


The following assumes DARK-ON (D) is set.

Sequence	Adjustment method	Sensitivity adjustment trimmer
①	Remove the target. Adjust the sensitivity trimmer to MAX. Mount the sensor heads in place so the (orange) output indicator turns off (on thrubeam models, the red light on the receiver face will turn on).	
②	Position target in place. Verify that the orange output indicator turns on (on thrubeam models, the red light on the receiver face will turn off). Adjust sensitivity lower if the output indicator does not turn on (or if the red light on the receiver face does not turn off on thrubeam models).	


Reference To use the sensor in LIGHT-ON mode, adjust the mode selector switch to "L".

I/O Circuit Diagram


PZ-G5xN/G5xP/G5xB (Transmitter side)




PZ-G5xN (Receiver side)/ G4xN/G10xN/G6xN



PZ-G5xP (Receiver side)/ G4xP/G10xP/G6xP



PZ-G5xB (Receiver side)/ G4xB/G10xB/G6xB




* The pin numbers represent those of the connector type / pigtail quick disconnect type.
The model name with "C" (PZ-GxxCx) is the connector type, and the model name with "E" (PZ-GxxEx) is the pigtail quick disconnect type.

[PZ-GxxCN/GxxCP..... M8 connector
PZ-GxxCB/GxxEN/GxxEP..... M12 connector]

Indicators

The following describes each ON/OFF condition of indicator when LIGHT-ON (L) is set.

When the DARK-ON (D) is set, the output indicator ON/OFF will reverse.



* For PZ-G62, the upper limit is 107% and the lower limit is 93%.

If the stable operation indicator turns off during operation, readjust or fine-adjust the sensitivity.

Mutual interference

- For reflective type / retro-reflective type sensors, mutual interference protection can be set for up to 2 units. However, when the sensors are mounted facing each other, change the angle of the sensor head to prevent light being emitted into each unit. (The mark detection type does not include the mutual interference function.)
- Mutual interference prevention can be set when mounting a polarizing filter attachment (optional with thru-beam type sensors). (If operation is unstable even after mounting the polarizing filter, slightly lower the sensitivity.)
- For more detailed information about mutual interference or attachment, see the PZ-G Series catalog or contact your nearest KEYENCE office.

Specifications

Type			Thru-beam		Reflective				Retro-reflective		Mark detection			
Configuration	Cable shape	Output mode	Normal	High-power	Diffuse-reflective Long-detecting distance	Diffuse-reflective Short-detecting distance	Narrow-view reflective	Definite reflective	Long detecting distance (with P.R.O. function)	Transparent target detection (without P.R.O. function)	Red	Green	Blue	
Rectangular	Cable	NPN	PZ-G51N	PZ-G52N	PZ-G41N	PZ-G42N	PZ-G101N	PZ-G102N	PZ-G61N	PZ-G62N	-			
		PNP	PZ-G51P	PZ-G52P	PZ-G41P	PZ-G42P	PZ-G101P	PZ-G102P	PZ-G61P	PZ-G62P				
	M8 connector	NPN	PZ-G51CN	PZ-G52CN	PZ-G41CN	PZ-G42CN	PZ-G101CN	PZ-G102CN	PZ-G61CN	PZ-G62CN	PZ-G10RCN	PZ-G10GCN	PZ-G10BCN	
		PNP	PZ-G51CP	PZ-G52CP	PZ-G41CP	PZ-G42CP	PZ-G101CP	PZ-G102CP	PZ-G61CP	PZ-G62CP	PZ-G10RCP	PZ-G10GCP	PZ-G10BCP	
	M12 pigtail quick disconnect	NPN	PZ-G51EN	PZ-G52EN	PZ-G41EN	PZ-G42EN	PZ-G101EN	PZ-G102EN	PZ-G61EN	PZ-G62EN	-			
		PNP	PZ-G51EP	PZ-G52EP	PZ-G41EP	PZ-G42EP	PZ-G101EP	PZ-G102EP	PZ-G61EP	PZ-G62EP				
Nut	Cable	Bipolar	PZ-G51B	PZ-G52B	PZ-G41B	PZ-G42B	PZ-G101B	PZ-G102B	PZ-G61B	PZ-G62B	-			
	M12 connector	(NPN+PNP)	PZ-G51CB	PZ-G52CB	PZ-G41CB	PZ-G42CB	PZ-G101CB	PZ-G102CB	PZ-G61CB	PZ-G62CB				
Detecting distance*1			20 m	40 m	1 m (30 × 30 cm white mat paper)	300 mm (10 × 10 cm white mat paper)	200 mm	5 to 45 mm	0.1 to 4.2 m (when R-2L reflector is used)	0.1 to 1 m (when R-2L reflector is used)	8 to 15 mm			
Spot diameter			-	-	-	-	Approx. φ 5 mm (when the detecting distance is 100 mm)	Approx. φ 2 mm (when the detecting distance is 40 mm)	-	-	Approx. 1.5 × 4 mm (when the detecting distance is 10 mm)			
Light source (LED)			Red LED	Infrared LED × 2	Red LED					Infrared LED	Red LED	Green LED	Blue LED	
Sensitivity adjustment			1-turn trimmer (230 degrees)											
Response time			500 μs									50 μs		
Operation mode			LIGHT-ON/DARK-ON, trimmer-selectable											
Indicator (LED)			Transmitter: power (orange) Receiver: output (orange), stable operation (green), light (red)		Output (orange), stable operation (green)									
Control output			Open-collector 100 mA max. (30 V max.), Residual voltage 1 V max.											
Protection circuit			Reverse-polarity protection, over-current protection, output surge absorber											
Ratings	Power voltage		10 to 30 VDC, Ripple (P-P): ±10% max, Class 2.											
	Current consumption		Transmitter: 20 mA max. Receiver: 28 mA max.	Transmitter: 25 mA max. Receiver: 28 mA max.	34 mA max.									
Environmental resistance	Enclosure rating		IEC/JEM: IP67 / NEMA: 4X,6,12 / DIN: IP69K											
	Ambient light		Incandescent lamp: 5,000 (lx) max, Sunlight: 20,000 (lx) max.											
	Ambient temperature		-20 °C to +55°C (No freezing)											
	Relative humidity		35 to 85 % RH (No condensation)											
	Vibration resistance		10 to 55 Hz, 1.5 mm double amplitude in X, Y, Z directions, 2 hours each											
	Shock resistance		1000 m/s ² in X, Y, Z directions, 6 times each											
Interference prevention			2 units (when polarizing filter attachment is used)		2 units (with the automatic different cycle function)						-			
Material			Case, M18 nut (nut type only): reinforced glass polybutylene terephthalate (PBT), Trimmer: reinforced glass polyamide (PA) Cable (Cable type / pigtail quick disconnect type only): Polyvinyl chloride (PVC), Screw (Case connection): Steel, zinc-nickel plated, Packing (Case connection): Nitrile-butadiene rubber (NBR) Connector (pigtail quick disconnect type only): Brass-nickel plated, Polybutyleneterephthalate (PBT), Polyvinyl chloride (PVC)											
	Lens cover		Polyarylate (PAR)						Acrylic plastic (PMMA)		Polyarylate (PAR)			
Tightening torque			Rectangular type (side screw part): 0.5 N·m max. Nut type (front M18 part): 1.0 N·m max., (side slot part): 0.5 N·m max.											
Accessory*2			Instruction manual, M18 nut × 2 (nut thru-beam type), M18 nut × 1 (other nut types)											
Weight			Rectangular cable type: Approx. 60 g (Approx. 50 g for thru-beam transmitter), Rectangular M8 connector type: Approx. 10 g, rectangular M12 pigtail quick disconnect type: Approx. 30 g Nut type cable type: Approx. 65 g (Approx. 55 g for thru-beam transmitter), Nut type M12 connector type: Approx. 15 g											

*1 The detection distance is measured with the maximum sensitivity.

*2 The cable for the connector type / pigtail quick disconnect type is sold separately. The reflector for the retro-reflective type is sold separately.

WARRANTY

KEYENCE products are strictly factory-inspected. However, in the event of a failure, contact your nearest KEYENCE office with details of the failure.

1. WARRANTY PERIOD

The warranty period shall be for one year from the date that the product has been delivered to the location specified by the purchaser.

2. WARRANTY SCOPE

- (1) If a failure attributable to KEYENCE occurs within the abovementioned warranty period, we will repair the product, free of charge. However, the following cases shall be excluded from the warranty scope.
- Any failure resulting from improper conditions, improper environments, improper handling, or improper usage other than described in the instruction manual, the user's manual, or the specifications specifically arranged between the purchaser and KEYENCE.
 - Any failure resulting from factors other than a defect of our product, such as the purchaser's equipment or the design of the purchaser's software.
 - Any failure resulting from modifications or repairs carried out by any person other than KEYENCE staff.
 - Any failure that can certainly be prevented when the expendable part(s) is maintained or replaced correctly as described in the instruction manual, the user's manual, etc.
 - Any failure caused by a factor that cannot be foreseen at a scientific/technical level at the time when the product has been shipped from KEYENCE.
 - Any disaster such as fire, earthquake, and flood, or any other external factor, such as abnormal voltage, for which we are not liable.
- (2) The warranty scope is limited to the extent set forth in item (1), and KEYENCE assumes no liability for any purchaser's secondary damage (damage of equipment, loss of opportunities, loss of profits, etc.) or any other damage resulting from a failure of our product.

3. PRODUCT APPLICABILITY

KEYENCE products are designed and manufactured as general-purpose products for general industries.

Therefore, our products are not intended for the applications below and are not applicable to them. If, however, the purchaser consults with us in advance regarding the employment of our product, understands the specifications, ratings, and performance of the product on their own responsibility, and takes necessary safety measures, the product may be applied. In this case, the warranty scope shall be the same as above.

- Facilities where the product may greatly affect human life or property, such as nuclear power plants, aviation, railroads, ships, motor vehicles, or medical equipment
- Public utilities such as electricity, gas, or water services
- Usage outdoors, under similar conditions or in similar environments

E 1040-1

KEYENCE CORPORATION

1-3-14, Higashi-Nakajima, Higashi-Yodogawa-ku,
Osaka, 533-8555, Japan

PHONE: +81-6-6379-2211 www.keyence.com

Specifications are subject to change without notice.

A7WW1-MAN-0069

Copyright (c) 2010 KEYENCE CORPORATION. All rights reserved.

11227E 1070-1 96M11227


Printed in Japan



* 9 6 M 1 1 2 2 7 - 1 *

Electronics

--	222265-001	1	Enclosure, 36EL3010
--	222267-000	1	Panel, SCE-36P30
--	241085-001	1	Fuse, 10A, 1.25 x .25
--	241138-000	5	Fuse, 20A, CC
--	241060-000	12	Fuse, 5A, 1.25 x .25
--	262822-001	3	Ethernet Cable, 3 ft
--	251799-000	3	End Cover
--	251798-000	3	Partition Plate
--	251859-000	4	10-Pole Jumper
--	251855-000	6	2-Pole Jumper
--	251795-000	8	Phoenix Contact End Terminal
--	251854-000	18	Phoenix Contact Ground Terminal, ST1.5
--	251853-000	110	Phoenix Contact Terminal Block, ST1.5
23	221678-000	1	Regeneration Clamp
22	211548-003	1	Power Supply, 48V, 10A
21	202628-000	3	Relay, 24V
20	221620-001	1	Analog Output Module, 5069-OF4
19	221486-001	1	Output Expansion Module, AB 5069-OB16
18	221489-001	1	Input Expansion Module, AB 5069-IB16
17	221616-005	1	PLC, AB CompactLogix 5069-L306ER
16	221713-003	1	Gateway, Weintek cMT-G01
15	221683-000	1	Ethernet Switch, 8 Port
14	221650-005	1	Phoenix 1301402 Safety Relay
13	211534-001	1	Keyence MS2-H100 Power Supply, 24V, 4.5A
12	263824-000	1	Connector, 2 Pin, DC Inhibit
11	411457-000	1	Minarik MM23001C Drive, DC
10	411458-000	3	AC Drive, Fuji Mini, 220V, 1/2 HP, 2.5A
9	202620-000	1	Auxillary Contact, 2 Normally Open
8	202607-000	3	Altech Contactor Surge Suppressor
7	202604-000	3	Altech GMD-12M-10-DC24V Contactor, 24V, 12A
6	251788-001	13	Fuse Holder, 1.25 x .25
5b	251801-000	2	2 Pole Jumper, ST2.5
5a	251804-000	2	5 Pole Jumper, ST2.5
4	251797-000	12	Phoenix Contact Terminal Block 3031212, ST2.5
3	272117-003	1	Non-Fused Disconnect, 25A
2	241285-000	5	Fuse Holder, CC
1	251830-002	1	Ground Bar
NO	PART NO	QTY	DESCRIPTION



1" Wireway Unless Noted
Component Hardware: 8-32 SHCS
Wireway/Din Rail Hardware: 8-32 BHCS




UNLESS OTHERWISE SPECIFIED DIMENSIONAL TOLERANCE X ± .XTOL XX ± .XXTOL XXX ± .XXXTOL ANGLES ± .ANGTOL SURFACE FINISH FINISHTOL BREAK ALL EDGES .005/.015	<div>QUADREL LABELING SYSTEMS</div> <div>7670 Jennifer Drive Mentor, Ohio 44060 (440) 602-4700</div>		SCALE: 1:1
			DATE: 03OCT2021
			DRAWN BY: CMT
			REVISED:
			Layout, PLC Techline
MAT'L	84224E1-000	RR19221.00001	

PLC TECHLINE
220VAC SINGLE PHASE, 15A
COMPACTLOGIX PLC
APPLIED MOTION TXM STEPSERVOS
FUJI C2 INVERTERS

- Page Listing:
- 1: Main AC
 - 2: Safety Relay
 - 3: Conveyor & Top Trap
 - 4. Wrap & Pacing
 - 5. Labelers
 - 6: PLC, Ethernet
 - 7: Operator Enclosure
 - 8: Sensors

WIRE SIZE/COLOR TABLE (UNLESS OTHERWISE NOTED)


120,240VAC:14AWG BLACK
24VDC/SIGNAL: 18AWG BLUE
0VDC: 18AWG WHITE/BLUE
EARTH GROUND WIRES: 14 AWG GREEN/YELLOW
AC MOTOR WIRES: 4-16AWG

-  : Terminal Block
-  : 2 Jumpered Terminal Blocks
-  : 3 Jumpered Terminal Blocks, etc




QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
	-	Release	CMT	15OCT2025
Drawn By: CMT	REV	DESCRIPTION	BY	DATE
Title				
TECHLINE LABELING SYSTEM				
Schematic #				Rev
SB84224-000				-
Date: Wednesday, October 15, 2025		Sheet 00 of 08		

208/220VAC 1PH. 20AMP

MAIN AC TERMINALS: 6/EA





WIRES RUN INDIVIDUALLY TO BREAKERS / FUSES FROM
TERMINAL BLOCKS



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use



QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060							
Drawn By: CMT				Release	CMT	15OCT2025	
Title				REV	DESCRIPTION	BY	DATE
POWER							
Schematic #				Rev			
SB84224-000				-			
Date: Wednesday, December 03, 2025				Sheet 01 of 08			



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use

QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
Drawn By: CMT	REV	Release	CMT	15OCT2025
Title		SAFETY RELAY		
Schematic #		SB84224-000		
Date: Wednesday, October 15, 2025		Sheet 02 of 08		




Analog Signal Jumped
From DR1 Conveyor Drive

COLOR	TECHNICIAN	DATE


For Quadrel Assembly Use

QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
Drawn By: CMT	REV	Release	CMT	15OCT2025
Title				
CONVEYOR, TOP TRAP				
Schematic #				Rev
SB84224-000				-
Date: Wednesday, October 15, 2025				
Sheet 03 of 08				

Analog Signal Jumped
From DR2 Top Trap Drive





Pacing



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use


QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
Drawn By: CMT	REV	Release	CMT	15OCT2025
Title				
WRAP, PACING				
Schematic #				Rev
SB84224-000				-
Date: Monday, November 24, 2025				
Sheet 04 of 08				



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use




QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
Drawn By: CMT	REV	Release	CMT	15OCT2025
Title				
LABELERS				
Schematic #				Rev
SB84224-000				-
Date: Wednesday, October 15, 2025				
Sheet 05 of 08				



COLOR	TECHNICIAN	DATE

QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060			
Drawn By: CMT	Release	CMT	15OCT2025
Title			
PLC, ETHERNET			
Schematic #			Rev
SB84224-000			-
Date: Monday, November 24, 2025			
Sheet 06 of 08			

For Quadrel Assembly Use





COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use


QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
Drawn By: CMT	REV	DESCRIPTION	CMT	DATE
Title				
OP. ENCLOSURE				
Schematic #				Rev
SB84224-000				-
Date: Monday, November 24, 2025		Sheet 07 of 08		

Labeler Junction Block




Typical Colors


Typical Sensor Wiring Example




Jog Button in Remote Enclosure




Solenoid Example



Encoder




Labeler Junction Block



Ports 7 and 8 not Wired/Used

Sensor	Labeler #1	Labeler #2
Label Detect	507	607
Spare		
Spare		
Spare		
Jog Button	1-1:1/07	1-1:1/08



COLOR	TECHNICIAN	DATE

For Quadrel Assembly Use

QUADREL LABELING SYSTEMS 7670 JENTHER DR. MENTOR, OH 44060				
Drawn By: CMT	REV	Release	CMT	15OCT2025
Title				
SENSORS				
Schematic #				Rev
SB84224-000				-
Date: Tuesday, October 28, 2025				
Sheet 08 of 08				

9 MAINTENANCE

9.1 GENERAL INFORMATION

This labeler has been designed with the minimal maintenance requirement possible. There are however some things to take into consideration.

The system is built to perform in humid conditions, but must not be pressure washed. In case of wash down conditions, it is recommended to cover each labeling head with a plastic tarp.

For the overall cleaning, it is recommended to use compressed air and clean, damp wipes.

Always turn off the system before proceeding with cleaning and maintenance.

The following section explains the preventive maintenance for each section

After every 100 hours of operation, a visual inspection of the system should be done and where it is necessary, lubricate and cleaning should be performed.



CAUTION

WEAR PROTECTIVE EYEWEAR when performing any maintenance on this equipment.



CAUTION

To reduce risk of fire, electrocution or other personal Injury when operating or maintaining the labeling head, follow basic safety precaution, including the following:

DO NOT perform any servicing or maintenance with the power ON.

Always disconnect the electrical plug from the wall socket

Make sure that the power is OFF or that the available E-stop buttons have been activated.

LABELING SYSTEM

This labeling system is reliable, versatile and durable. It will operate for years with very light maintenance if it is performed regularly. Most of the maintenance takes only a few minutes and substantially increases the operational life of the system and maintains label placement accuracy.

Not all sections may apply to your equipment.

Daily:	D
Weekly:	W
Monthly	M
Quarterly	Q
Semi-Annually	S

ASSEMBLY TITLE: LABELING HEAD ASSEMBLY

D- Remove glue residue and labels from all rollers and idler. DO NOT use a knife or other tool to scrape the rollers. Adhesive Remover such as Goo-Gone or 3M Adhesive Remover is recommended. DO NOT use an adhesive remover that reacts with plastics or sensor lenses will be damaged.

M- Check for loose idlers and components and tighten as needed.

S – Lubricate all idler rollers shafts using 80w-90w gear lube on the white bearings where they contact the axle.

ASSEMBLY TITLE: UNWIND ASSEMBLY

S- Check and adjust dancer spring. If final spring tension is too soft then replace.

S- Check and inspect band brake. Replace if torn

ASSEMBLY TITLE: REWIND ASSEMBLY

S- Check and inspect friction disc (if applicable), Replace when worn out.

S- Check Kinetrol (if applicable) for leaks, Replace if necessary.

ASSEMBLY TITLE: BRAKE BRUSH ASSEMBLY

S- Reverse brake brush direction

S- Inspect Brake brush when brush body contour no longer viable or bristles are worn down. Replace

ASSEMBLY TITLE: SLOT SENSOR ASSEMBLY

D- Keep the sensor optical area clean from label and glue residue

ASSEMBLY TITLE: SIDE PLATE ASSEMBLY

S- Lubricate all idler rollers shafts using 80w-90w gear lube on the white bearings where they contact the axle.

ASSEMBLY TITLE: PEEL PLATE ASSEMBLY

D- Clean all the parts that may acquire labels or glue residue. DO NOT use a knife or other tool to scrape the rollers. Adhesive removers are recommended.

W- Inspect Teflon tape on peel plate tip. Replace if the steel is exposed.

S – Lubricate all idler rollers shafts 80w-90w gear lube

ASSEMBLY TITLE: DRIVE AND PINCH ROLL ASSEMBLY

D- Remove glue residue and labels from drive roller. DO NOT use a knife or other tool to scrape the rollers. Isopropyl alcohol and adhesive removers are recommended.

W- Clean the knurled roll with a soft brass brush and adhesive remover.

M- Check and inspect drive roll. No play should be present when powered up. If there is a groove the width of the label liner, replace the worn roller.

M – Lubricate knurled roll shafts using 80w-90w gear lube.

S- Inspect and Lubricate, springs and slugs.

ASSEMBLY TITLE: ROLLER/BRUSH IMPRESSER

D- Check the rollers/brushes. They should be free of label flash, glue and debris. This will prevent jamming and web tears.

W- Check the foam rollers. If foam wear is noticeable, replace as necessary.

NOTE: Exercise caution when removing bad labels from foam. Careless removal can result in torn foam which may leave the labeler inoperable until the roller is replaced!

ASSEMBLY TITLE: OPERATOR PANEL

-No maintenance is required for the operator panel

-Occasionally, the keypad may be cleaned with any non-solvent based cleaning solution. Glass cleaner on a clean towel then wipe the membrane.

ASSEMBLY TITLE: ELECTRICAL

W- Check the foam filter for the fan. Clean or replace.

ASSEMBLY TITLE: CONVEYOR

D – Inspect conveyor chain for broken flights of table top chain

W – Inspect conveyor for labels / adhesive and remove as needed

S – Check gearbox oil levels and add as needed.

American Lubricants SHC-90W oil.

ASSEMBLY TITLE: FEEDSCREW

W – Remove glue residue and labels from feed screws

W – Lubricate internal feedscrew drive assembly, with multi-purpose grease.

S – Lubricate grease fittings / chains / bearings with quality multi-purpose grease – as needed

ASSEMBLY TITLE: VERTICAL ROLLER

W – Remove labels from rollers with adhesive remover / cleaner

W – Lubricate chains with food grade grease.

ASSEMBLY TITLE: EJECT STATION

D – Clean all parts that have acquired label or glue residue

ASSEMBLY TITLE: INFEEED / OUTFEED BANK SENSOR

W – Clean and glue residue or labels off sensor and/or reflectors

ASSEMBLY TITLE: SLEEVE

M – Drive rollers – Inspect for wear and clean with a citrus based adhesive removal

M – Inspect tension belts for cutter blade and cutter assembly for wear. Replace as needed.

M – Inspect cutter blades and bearings for wear. Replace as needed

M – Inspect perforation blades / bearings for wear and free of debris. Replace as needed.

S – Check, inspect, and grease all lead screws (threaded rods)

S – Inspect mandrel and bearings for wear. Ensure they spin freely
Replace as needed.

NOTES:

GENERAL PURPOSE FEEDSCREW LUBRICATION GUIDE

During your weekly maintenance of your Quadrel Labeling Systems equipment follow the steps below to ensure proper lubrication of the internal drive system for your feedscrew assembly.




Step 1 – Your dual feedscrews are connected inside the conveyor with a spline shaft assembly. First remove the chain so you have easy access to the this.



Step 2 – Open your feedscrews to your largest product. This will expose the spline assembly shaft that you will be applying the multi-purpose grease to.




Step 3 – Apply multi-purpose grease to the now exposed spline shaft assembly. Ensure to apply multi-purpose grease all the way around the spline shaft– Top, bottom and sides



Step 4 – Slowly move the feedscrews in and out to so the grease can spread evenly over the length of entire spline shaft assembly.


Step 5 – Reconnect conveyor chain

Setup procedure for Powered rewind using MGC403-11-00MD drive




Upon receiving drive set the following **BEFORE** installing in the machine.

1. Dip switches - set all switches to the off position. This is the Light blue row of switches shown in the image below




- a.
2. Set Jumpers on drive based on electrical schematic for your machine
 - a. SIG1 – VDC
 - b. SIG2 – VDC
 - c. J504 – A90
 - d. AMP CURRENT – 1.7A – This located near the 10 pin green connector that



i.


3. Using a small flat blade / Slot screwdriver adjust the following pots as indicated in the image below:



- a.
- i. Top row **OFS1** – WILL BE ADJUSTED AT LATER STEP
 - ii. Top row – **FACC** - turn counter clockwise until it stops.
 - iii. Top row **FWCL** – set to half way point – midpoint
 - iv. Middle row - **OFS2** – turn counter clockwise until it stops. This turns the pot OFF
 - v. Middle row – **RACC** - turn counter clockwise until it stops
 - vi. Middle row – **RVCL** – set to half way point – midpoint
 - vii. Bottom row – **MAX** – Set to 3/4 point
 - viii. Bottom row – **Leave other 2 pots at factory setting – DO NOT ADJUST**



4. Install drive in machine then proceed to next steps

5. Set the Cam on the rewind dancer per image below when the dancer arm is at rest. Rest is when the arm is all the way back against the rubber bumper as shown






6. On the HMI go to into labeling head service menu. You will be looking at the REWIND PROX VOLTAGE (example below)



7. Adjust the sensor gap at the cam by loosening the bolt using an allen key so that the sensor can be moved forward or backward. The bolt does NOT touch the sensor. Loosening it opens the clamp so you can adjust.
8. Set the gap so the REWIND PROX VOLTAGE on the HMI reads **.90 it must be under 1 volt.**
 - a. **Retighten screw so the clamp sensor no longer moves**



b.

9. Test by moving the rewind dancer arm forward. When doing this you should see the rewind prox voltage on the HMI increase up to 9 volts

a. If you do not see the voltage increase steadily, recheck cam sensor gap in step 7

10. Turn on rewind switch on the back of the labeler. This will engage / turn on the motor.
11. Move the rewind dancer arm forward the rewind hub should start to turn clockwise. It will slow then stop as you move forward. Rewind hub should ALWAYS be turning clockwise. If it moves counter clockwise move to **step 11a**
 - a. While holding the arm in the position where it started to run counter clockwise, it MUST be running counter clockwise, you will adjust **OFS1** until the rewind hub stops moving.



i.


- b. This adjustment may need to be done multiple times until it no longer moves counter clockwise when rewind arm is all the forward and at rest.

9.2 BELTS


Monthly, a visual inspection of the rewind belt and timing belt, to do this depending on the labeling head you may need to remove the bottom cover on the head.

Refer to photos below.

Servo labeling head.



Stepping labeling head.





CAUTION

DO NOT ATTEMPT doing this with the equipment under tension (with power on).

The visual inspection should consist of looking for cracks or defects in the belts. If this is the case, change the belts that are defective. Refer to the parts listing in the labeling head section of this manual.

The brake band mechanism requires a monthly visual inspection as well. Also once every 12 months you should consider replacing the belt (it is possible that you may need to change it later or earlier than 12 months depending the usage of the labeling head).

The brake band belt assembly is located at the base of the unwind assembly. See images below for reference.





For replacement parts see the unwind assembly drawing for your labeling head in this manual.

9.3 ROLLERS

It is important that your labeler is as clean as possible in its environment in order for it to perform properly. Daily, it is suggested to clean all the rollers including the drive roller (the rubber roller), the pressure shoe and peel plate using a damp cloth with alcohol. Make sure those parts have no glue or labels on it.

Weekly, spray a silicone base lubricant on each end of the plastic bearing.



9.4 SENSORS



The sensors all have an electronic eye called a photocell; these must be free of lint or dirt. Since the photocells are generally made with glass or plastic lenses. They naturally attract substances which could easily trigger the sensor, use a cotton swap to gently clean the eye of the sensor as you would any lens, in a circular motion.

9.5 CONVEYOR

Always keep the belt or (chain) clean. To clean it simply use compressed air with an osha approved nozzle and/or damp wipes. If necessary, a soft cleaning agent can be used.

9.5.1 CLEANING

To clean the under carriage portion of the conveyor, simply remove the belt using an punch or similar tool and hammer to tap out the retaining belt link pin. (see images below, the chain has an orientation to the pins, you must tap it out from the narrow diameter) Clean the desired portion with a damp cloth and replace the pin to the belt. The pin will be tapped in the opposite side you tapped it out. *You can also lift the chain and wipe under it.



10 CLEARING A JAM

In the event a jam occurs on your Quadrel Labeler reference the following steps to clear.

1. Press the conveyor stop button or the emergency stop if you are unable to reach the stop button.
2. Clear the jam manually in the affected area of the equipment where jam is located
3. Once jam is cleared reenergize the estop, if pressed, and press the reset button (where applicable) to clear faults.
4. Put equipment back into "run" and press start to turn the system back online to continue labeling

11 WARRANTY

The standard warranty period for Quadrel equipment is 12 months following invoicing. The warranty covers all parts with consideration taken towards reasonable use and normal wear and tear. Not covered by warranty are parts that have a limited wear factor, any required labor by Quadrel. Prior to return to Quadrel, parts must be verified defective.

Return of defective parts

To return a defective part, you will need to get an RMA number from Quadrel. All RMA's are issued through our parts department. Please specify the serial number of the equipment, the client's name, address, phone number, contact name and the nature of the problem. To get a replacement part, a purchase order is required. You will be billed for the new part and credited for the defective part after return and evaluation. If the part is determined to be defective due to improper use, no credit will be issued.

Appropriate Use of Equipment

The equipment supplied to the end user by Quadrel are to be used for the sole purpose for which they were intended and must follow Quadrel's specifications on usage as well as appropriate functions. Quadrel will not assume any responsibility for any inappropriate use or modifications to the said equipment other than for the use it was initially built for.

The warranty will cease to apply forthwith, in Quadrel's opinion, the equipment has been used abnormally or in an abusive manner, if it has not been properly maintained, if it has not been carried on a truck equipped with an air-ride suspension when required by Quadrel or if it has been used, or maintained contrary to the owners manual provided by Quadrel.

Responsibility Limits

The solution put forth has been prepared with the information that has been provided to Quadrel by the end user. Subsequently, Quadrel cannot assume any responsibility for the exactitude, precision, and the validity of the information which was supplied. Moreover, Quadrel cannot be responsible for (a) any damages, direct or indirect, secondary, or

accessory, including without limitations, the loss of profit, workflow interruption, loss of production, loss of profits and other; (b) any and all damages claimed against the end user by a third party; (c) any or all damages caused to the property of end user or any other third party; (d) any or all resulting in an act from the end user or third party, major force, or act of god, unforeseen cause, or event.

With all reservation, in the eventuality where the responsibility is that of Quadrel relative to any defect of quality of said equipment or proposed solution Quadrel would be able to accept the responsibility, to its entire discretion, with the replacement of part of the said equipment or solution. By a compatible or identical equipment or solution or by a reimbursement of value agreed upon. In no case can Quadrel's responsibility exceed the total monetary sums received for the said defective equipment or solution.